PRODUCT DATA SHEET

Stationary Ultrasonic Flowmeter

LF810

TOSHIBA INTERNATIONAL CORPORATION

1. Outline

- 1) Transit times of ultrasonic pulses transmitted in a liquid vary with the flow velocity of the liquid and ultrasonic flowmeters utilize this characteristic to measure flow.
- 2) Regardless of whether the liquid is electrically conductive or non-conductive, ultrasonic flowmeters can measure various types of liquids such as potable water, river water, industrial water, agricultural water, wastewater, seawater, and pure water.
- 3)

Transducers are clamped on to the outside of the pipe so it is not necessary to cut pipes or stop flow for installation and there is no pressure loss.

- Flow measurements are possible over a wide range, -30m/s to +30m/s.
- Economical measurements of flow from 25mm (1") to 600mm (24") can be obtained.
- Easy Operation through PC configuration software. Through graphical user interface, it is very simple and useful for everyone to input all data.



2. Features

1) Graphical PC configuration "EZ-wizard"

Through EZ-wizard, all required parameters can be input. Mounting position of transducers will be calculated by input parameters automatically.

2) Emergency Redundancy System (Automatic Logging System)

1 minute interval for 1-month of data will be logged internally and automatically with all events data.

A Total of 64000 points data logging capability.

3) Echo-wave monitor

Receiving echo will be indicated on the PC configuration software. This feature helps to identify ideal mounting positions of transducers.

4) Variety I/O port

Analog output (Std.), Totalizing output (Std.), Digital port (Std.), and Digital port / RS-485 MODBUS (Option) are available.

5) Extra A-IN available

By using optional card, 1 port for passive analog input (option) can be available.

This information will be stored as internal logged data automatically.

6) Site Check mode

Any Error will be indicated on the LCD without PC or any software.

7) EZ-Translation


Any languages are configurable on the PC locally.

3. Configuration

Flowmeter components

Component	Model	Quantity	Description
1. Main unit	LF810	1 pc	Flowmeter main unit
2. Transducers	1MHz Transducer for 1" – 24" Pipe	2 pcs	Ultrasonic transmit and receiving transducers and pipe-mounting fixtures for transducer
3. Coaxial cables (*)	RG-223/U	2 pcs	Connection cable between converter and transducers (includes 33ft.of cable) (max. cable length: 30m)

Components	Quantity	Material	Weight (approx.)
1. Transducer	1pair (2pcs)	Case : PBT (Plastic)	180g / 2pcs
2. Holder	2pcs	PBT (Plastic)	160g / pc
3. Fastening Fixture	10pcs	SUS304	20g / pc
4. Stainless Band	15 m	SUS430	24g / m
5. Clamp	2sets	SUS304	55g / set
6. Thumb Screw (for Z-method)	4pcs	SUS303	16g / pc
7. Installation Outfit	1set		



4. Specifications 4-1. Overall Specifications

Measurement	Fluids	Homogeneous and ultrasonically conductive fluids (Clean water, waste water, industrial water, river water, sea water, pure water, etc.)
	Temperature range	 -4 to 140°F (-20 to 60°C) Note: 1) above also applicable to ambient temperature 2) For main unit, 14 to 122°F (-10 to 50°C)
	Turbidity	10000 mg/L or less Note) No air bubbles
Pipes	Material	Pipes made of materials that allow stable transmission of ultrasonic waves, such as steel, stainless steel, cast iron, ductile cast iron, PVC, FRPM, etc. Note) Applicable pipe bores may vary depending on the pipe material and condition.
	Diameters	1" – 24" (DN25mm to DN600mm)
	Lining	None, tar epoxy, mortar, etc. Note) Linings must be closely adhered to the base pipe.
Measurement range	Converted to flow vel	ocity: -30 m/s to +30 m/s
Number of measurement paths	1 measurement path	
Measurement cycle	1 s	
Measurement Performance	1"-1.75" (DN 25 ~ 40mm) 2" - 3.5"	±2.5%(*) of reading, however ±0.025(*) m/s for flow velocities less than 1 m/s (*) Depending on calibration
	(DN 50 ~ 90mm)	$\pm 2.0\%$ of reading, however ± 0.020 m/s for flow velocities less than 1 m/s
	4" – 10" (DN 100 ~ 250mm)	$\pm 1.5\%$ of reading, however ± 0.015 m/s for flow velocities less than 1 m/s
	12" – 24" (DN 300 ~ 600mm)	$\pm 1.0\%$ of reading, however ± 0.010 m/s for flow velocities less than 1 m/s
	Repeatability	±0.5%
	Range ability	1:300
	Note: 1) For volumetric flow rat	otationally symmetrical flow profile required.
Measurement method		sit time difference method
European		

European	
compliance	Safety: IEC61010-1 2nd Edition
(CE marking)	EMC: EN61326-1:2006 + EN61326-2-3:2006

4-2. Main Unit

Analog	Std / Option	Standard
output	Number of	1
	channels	1
	Output contents	Instantaneous flow rate
	Output pattern	Single system
		4 – 20mA, Burnout 20.8mA (when "no echo received" or during
	Output format	"failure warning" output available)
	Output format	Max. allowable load resistance 600ohm
		Insulated outputs, 10-bit equivalent accuracy
	Update cycle	125ms (8Hz)
	Terminal panel	Screw less Terminal (0.08~2.5mm ² cable applicable)

Contact	Std / Option	Standard
point output	Number of channels	1
	Output	 Selectable from: 1. Forward flow totalized pulse 2. Backward flow totalized pulse 3. No echo received warning (ROFF) 4. Equipment failure warning 5. No echo received warning or Equipment failure 6. Hi-Limit alarm 7. Lo-Limit alarm 8. Forward flow identification 9. Always open 10. Always closed
	Pulse Width	Pulse width of contact is selectable from 1000,500,100 or 20ms. Note: 1) But not for both forward and backward.
	Output format	Photo coupler (insulated)
	Contact point capacity	DC48V, 0.4A
	Terminal panel	Screw less Terminal (0.08~2.5mm ² cable applicable)

USB	Std / Option	Standard
communication	Number of channels	1
	USB Cable length	Up to 3m
	Functions	Flowmeter programming, measurement value display, received signal waveform display, and log data readout using dedicated software*1 *1 Compatible with Windows 7, Vista and XP
	Connector	USB-B terminal, hot plug possible

RS-485	Std / Option	Option
communication	Number of channels	1
	Output format	RS-485 (insulated type)
	Protocol	MODBUS-RTU compatible
	Transmission Length	Up to 1km (depending on cable and communication speed)
	Data	Forward flow totalized value, backward flow totalized value, instantaneous flow rate, instantaneous flow velocity, equipment status, etc.
	Baud rate	4800, 9600, 19200, 38400 bps (Selectable)
	Parity	None, Even, Odd (Selectable)
	Data bit length	8 bit /1 stop bit
	Terminal panel	Screw less Terminal (0.08~2.5mm ²)

Analog input	Std / Option	Option
	Number of channels	1
	Output format	Insulated inputs, passive method
	Input range	4-20mA
	Input lange	Input resistance 300 Ohm or less
	Accuracy	8-bit equivalent
	Sampling cycle	1 s
	Input contents	Selectable from current ratio (%) or current value (mA)
	Terminal panel	Screw less Terminal (0.08~2.5mm ²)

Log function	Std / Option	Standard
	Contents	Log contents: Date and time, instantaneous flow rate, instantaneous flow velocity, forward flow totalized value, backward flow totalized value, analog input value, measurement status, error status
	Number of log entries	68000 entries
	Log method	Ring buffer method
	Log cycle	Initial value: 60 s, setting range: 0 to 3600 s 1.5 months or more at a 60 s cycle (60 entries x 24 hours x 45 days = 64800 data) 1 year or more at a 600 s cycle
	Data retrieval	USB communication using dedicated software "UFW Config" or MODBUS communication (option)
	Data retention	Data is held for approximately 5 years in the power OFF status. ^{*1} The battery can be replaced. *1 When the internal lithium battery is fully charged.

Data setting	Setting method	LCD 4-keys entry or USB communication setting through PC
		with dedicated software "UFW Config"

Warnings can be selected. • Instantaneous flow rate and units • Instantaneous flow value and units • Instantaneous flow totalized value and units • Forward flow totalized value and units • Backward flow totalized value and units • Error code • Status (Out of full scale, No receiving echo warning, Disturband detected, Signal Saturation, Check mode and Low battery) • Analog input value (*Option) • ROFF counter value • Upside gain amplitude • Display digits Instantaneous flow relean anylitude • Date & Time Instantaneous flow relean anylitude • Display digits Instantaneous flow relean anylitude • Display digits Instantaneous flow relean anylitude • Date & Time Instantaneous flow relean anylitude • Date & Time Symbols are displayed at the right side of the LCD. • "R": No echo signal received. (upper line of the LCD) • "S": Receiving echo signal saturated. (upper line of the LCD) • "S": Low voltage of coin battery (lower line of the LCD) • "E": Error occurred by equipment failure. (upper line of the LCD) • "E": Error occurred by equipment failure. (upper line of the LCD)<	Display	Display method	LCD (16 chara	acter x 2 lines), with backlight			
Warnings Instantaneous flow rate and units Instantaneous flow velocity value and units Forward flow totalized value and units Backward flow totalized value and units Error code Status (Out of full scale, No receiving echo warning, Disturband detected, Signal Saturation, Check mode and Low battery) Analog input value (*Option) ROFF counter value Dis, counter value Dis, counter value Dis, counter value Display digits Instantaneous flow amplitude Downside gain amplitude Downside gain attraction 3 digits fixed Totalized flow 8 digits including decimal point Instantaneous flow rate instantaneous sign section 1 digit, integer section 2 digits flow relocity: and decimal fraction 3 digits fixed Totalized flow: Totalized flow 8 digits including decimal point "S": No echo signal received. (upper line of the LCD) "D': Disturbance detected. (upper line of the LCD) "S": Receiving echo signal saturated. (upper line of the LCD) "C": CHECK function is active. (upper line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E":			The following i	The following items displayed in the upper and lower lines on LCD			
Warnings Instantaneous flow velocity value and units Forward flow totalized value and units Backward flow totalized value and units Error code Display content Forward flow totalized value and units Backward flow totalized value and units Error code Status (Out of full scale, No receiving echo warning, Disturband detected, Signal Saturation, Check mode and Low battery) Analog input value (*Option) ROFF counter value Upside gain amplitude Downside gain amplitude Downside gain amplitude Downside gain amplitude Date & Time Instantaneous flow velocity: and decimal fraction 3 digits fixed Totalized flow: Totalized flow 8 digits including decimal point flow velocity: and decimal fraction 3 digits fixed Warnings Warnings Warnings			can be selected.				
Warnings • Forward flow totalized value and units • Backward flow totalized value and units • Backward flow totalized value and units • Backward flow totalized value and units • Error code • Status (Out of full scale, No receiving echo warning, Disturband detected, Signal Saturation, Check mode and Low battery) • Analog input value (*Option) • ROFF counter value • Dis, counter value • Dis, counter value • Display digits Instantaneous flow rate : Instantaneous flow rate : Instantaneous flow rate : Instantaneous flow rate : Instantaneous flow value and decimal fraction 3 digits fixed Totalized flow : Totalized flow : Totalized flow : Totalized flow : * RC*: No echo signal received. (upper line of the LCD) • "R*: No echo signal received. (upper line of the LCD) • "S": Receiving echo signal saturated. (upper line of the LCD) • "S": Receiving echo signal saturated. (upper line of the LCD) • "C*: CHECK function is active. (upper line of the LCD) • "S": Error occurred by equipment failure. (upper line of the LCD) (During exceeding the maximum flow rate of measurement range, indication would be alternated f			 Instantaneou 	is flow rate and units			
Warnings Backward flow totalized value and units Error code Status (Out of full scale, No receiving echo warning, Disturband detected, Signal Saturation, Check mode and Low battery) Analog input value (*Option) ROFF counter value Upside gain amplitude Downside gain amplitude Downside gain amplitude Date & Time Display digits Instantaneous flow rate : Instantaneous flow rate : Instantaneous flow rate : Instantaneous flow rate : Instantaneous sign section 1 digit, integer section 2 digits flow velocity : and decimal fraction 3 digits fixed Totalized flow : Totalized flow 8 digits including decimal point Symbols are displayed at the right side of the LCD. "R": No echo signal received. (upper line of the LCD) "D": Disturbance detected. (upper line of the LCD) "C": CHECK function is active. (upper line of the LCD) "S": Receiving echo signal saturated. (upper line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "D: The priority between the above symbols (indicated at the same po			 Instantaneous flow velocity value and units 				
Display content Error code Status (Out of full scale, No receiving echo warning, Disturband detected, Signal Saturation, Check mode and Low battery) Analog input value (*Option) ROFF counter value DIS, counter value Upside gain amplitude Downside gain amplitude Date & Time Instantaneous flow rate : Instantaneous flow rate : Instantaneous sign section 1 digit, integer section 2 digits flow velocity : and decimal fraction 3 digits fixed Totalized flow : Totalized flow 8 digits including decimal point Symbols are displayed at the right side of the LCD. "R": No echo signal received. (upper line of the LCD) "S": Receiving echo signal saturated (upper line of the LCD) "S": Receiving echo signal saturated (upper line of the LCD) "S": Error occurred by equipment failure. (upper line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": From occurred by equipment failure. (upper line of the LCD) "E": From occurred by equipment failure. (upper line of the LCD) "E": From occurred by equipment failure. (upper line of the LCD) "E": Error occurred by equipment failure. "Encorred by equipment failure. "The priority between the above symbols (indicated at the same position) as follow E > C > R > D > S Note: The priority between the above symbols (indicated at the same position) as follow E > C > R > D							
Display content Status (Out of full scale, No receiving echo warning, Disturband detected, Signal Saturation, Check mode and Low battery) Analog input value (*Option) • ROFF counter value • Display digits • Diss. counter value Instantaneous • Optication amplitude • Display digits Instantaneous Instantaneous flow rate : Instantaneous instantaneous flow valoeiy : and decimal fraction 3 digits fixed Totalized flow : Totalized flow 8 digits including decimal point Symbols are displayed at the right side of the LCD. • "R": No echo signal received. (upper line of the LCD) • "S": Receiving echo signal saturated. (upper line of the LCD) • "S": Receiving echo signal saturated. (upper line of the LCD) • "F.S.": Full Scale (Upper line of the LCD) • "F.S.": Full Scale (Upper line of the LCD) • "F.S.": Full Scale (Upper line of the LCD) • "F.S.": Full Scale (Upper line of the LCD) • "Distrument range" and "F.S." symbol at the upper & left side of LCD.) Note: • The priority between the above symbols (indicated at the same position) as follow E> C > R > D > S			 Backward flo 	w totalized value and units			
Display content detected, Signal Saturation, Check mode and Low battery) Analog input value (*Option) • ROFF counter value • DIS. counter value • Upside gain amplitude • Downside gain amplitude • Downside gain amplitude • Date & Time Instantaneous flow rate : Instantaneous flow rate : Instantaneous sign section 1 digit, integer section 2 digits flow velocity : Instantaneous flow rate : Totalized flow : Totalized flow : Totalized flow 8 digits including decimal point Symbols are displayed at the right side of the LCD. • "R": No echo signal received. (upper line of the LCD) • "D": Disturbance detected. (upper line of the LCD) • "S": Receiving echo signal saturated. (upper line of the LCD) • "B": Low voltage of coin battery (lower line of the LCD) • "F.": Fill Scale (Upper line of the LCD) • "E": Error occurred by equipment failure. (upper line of the LCD) • "E": Error occurred by equipment failure. (upper line of the LCD) • "E": Fill Scale (Upper line of the LCD) • "E": Fill Scale (Upper line of the LCD) • "B": Low voltage of coin battery (lower line of the LCD) • "E": Error occurred by equipment failure. (upper line of the LCD) • "B": Low voltage of coin battery (lower line of the LCD) • "E": Error occurred by equipment failure. (upper line of the LCD) • Upring							
Warnings Warnings Warnings Warnings Analog input value (*Option) Analog input value (*Option) ROFF counter value Display digits Instantaneous flow rate : Max. 7 digits including sign and decimal point flow rate : Instantaneous flow rate : Instantaneous sign section 1 digit, integer section 2 digits flow relocity :		Display content					
Warnings Analog input value (*Option) ROFF counter value DIS. counter value Upside gain amplitude Downside gain amplitude Downside gain amplitude Downside gain amplitude Downside gain amplitude Date & Time Display digits Max. 7 digits including sign and decimal point flow rate : Instantaneous flow rate : Instantaneous flow rate : Instantaneous sign section 1 digit, integer section 2 digits flow velocity :				-			
• ROFF counter value • DIS. counter value • Upside gain amplitude • Downside gain amplitude • Date & Time Instantaneous flow rate : Instantaneous flow rate : Instantaneous flow velocity : and decimal fraction 3 digits fixed Totalized flow : 'D': Disturbance detected. (upper line of the LCD) ''D': Disturbance detected. (upper line of the LCD) <tr< td=""><td></td><td></td><td>• /</td><td></td></tr<>			• /				
• DIS. counter value • Upside gain amplitude • Downside gain amplitude • Date & Time Instantaneous flow rate : Instantaneous flow rate : Instantaneous flow rate : Instantaneous flow rate : Instantaneous flow velocity : and decimal fraction 3 digits fixed Totalized flow : Totalized flow 8 digits including decimal point Symbols are displayed at the right side of the LCD. • "R": No echo signal received. (upper line of the LCD) • "D": Disturbance detected. (upper line of the LCD) • "S": Receiving echo signal saturated. (upper line of the LCD) • "S": Receiving echo signal saturated. (upper line of the LCD) • "S": Receiving echo signal saturated. (upper line of the LCD) • "S": Receiving echo signal saturated. (upper line of the LCD) • "S": Fill Scale (Upper line of the LCD) • "B": Low voltage of coin battery (lower line of the LCD) • "F.S.": Full Scale (Upper line of the LCD) (During exceeding the maximum flow rate of measurement range, indication would be alternated flickering "the maximum value of measurement range" and "F.S." symbol at the upper & left side of LCD.)							
Warnings • Upside gain amplitude • Downside gain amplitude • Date & Time Instantaneous flow rate : Instantaneous flow rate : Instantaneous flow rate : Instantaneous sign section 1 digit, integer section 2 digits flow velocity : Instantaneous flow velocity : and decimal fraction 3 digits fixed Totalized flow : Totalized flow 8 digits including decimal point Symbols are displayed at the right side of the LCD. • "R": No echo signal received. (upper line of the LCD) • "D": Disturbance detected. (upper line of the LCD) • "S": Receiving echo signal saturated. (upper line of the LCD) • "B": Low voltage of coin battery (lower line of the LCD) • "B": Low voltage of coin battery (lower line of the LCD) • "F": Error occurred by equipment failure. (upper line of the LCD) • "F": Error occurred by equipment failure. (upper line of the LCD) • "B": Low voltage of coin battery (lower line of the LCD) • "F": Error occurred by equipment failure. (upper line of the LCD) • "B": Low voltage of coin battery (lower line of the LCD) • "F": Error occurred by equipment failure. (upper line of the LCD) • Uuring exceeding the maximum flow rate of measurement range, indication would be alternated flickering "the maximum value of measurement range" and "F.S." symbol at the upper & left side of LCD.) Note: 1) The priority between the above symbols (indicated at the same position) as foll							
• Downside gain amplitude • Date & Time Instantaneous flow rate : Instantaneous flow rate : Instantaneous flow rate : Instantaneous sign section 1 digit, integer section 2 digits flow velocity : Instantaneous flow velocity : and decimal fraction 3 digits fixed Totalized flow : Totalized flow 8 digits including decimal point Symbols are displayed at the right side of the LCD. "R": No echo signal received. (upper line of the LCD) • "D": Disturbance detected. (upper line of the LCD) "S": Receiving echo signal saturated. (upper line of the LCD) • "S": Receiving echo signal saturated. (upper line of the LCD) "G": CHECK function is active. (upper line of the LCD) • "F.S.": Full Scale (Upper line of the LCD) "F.S.": Full Scale (Upper line of the LCD) • "F.S.": Full Scale (Upper line of the LCD) "G": State of the LCD) • "F.S.": Full Scale (Upper line of the LCD) "G": State of the LCD) • "F.S.": Full Scale (Upper line of the LCD) "G": State of the LCD) • "During exceeding the maximum flow rate of measurement range, indication would be alternated flickering "the maximum value of measurement range" and "F.S." symbol at the upper & left side of LCD.) Note: 1) The priority between the above symbols (indicated at the same position) as follow E > C > R > D > S							
• Date & Time Display digits Instantaneous flow rate : Max. 7 digits including sign and decimal point Display digits Instantaneous flow rate : Max. 7 digits including sign and decimal point Display digits Instantaneous flow velocity : and decimal fraction 3 digits fixed Totalized flow : Totalized flow 8 digits including decimal point Symbols are displayed at the right side of the LCD. "R": No echo signal received. (upper line of the LCD) "Disturbance detected. (upper line of the LCD) "S": Receiving echo signal saturated. (upper line of the LCD) "S": Receiving echo signal saturated. (upper line of the LCD) "G": CHECK function is active. (upper line of the LCD) "B": Low voltage of coin battery (lower line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": S.": Full Scale (Upper line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": S.": Full Scale (Upper line of the LCD) (During exceeding the maximum flow rate of measurement range, indication would be alternated flickering "the maximum value of measurement range" and "F.S." symbol at the upper & left side of LCD.) Note: 1) The priority between the above symbols (indicated at the same position) as follow E > C > R > D > S							
Warnings Instantaneous flow rate : Max. 7 digits including sign and decimal point Warnings Instantaneous flow rate : Sign section 1 digit, integer section 2 digits and decimal fraction 3 digits fixed Warnings Totalized flow : Totalized flow 8 digits including decimal point Warnings Symbols are displayed at the right side of the LCD. "R": No echo signal received. (upper line of the LCD) "B": Low ocho signal received. (upper line of the LCD) "S": Receiving echo signal saturated. (upper line of the LCD) "B": Low voltage of coin battery (lower line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": Fror occurred by equipment failure. (upper line of the LCD) "F.S.": Full Scale (Upper line of the LCD) "B": Low voltage of coin battery (lower line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "Uning exceeding the maximum flow rate of measurement range, indication would be alternated flickering "the maximum value of measurement range" and "F.S." symbol at the upper & left side of LCD.) Note: 1) The priority between the above symbols (indicated at the same position) as follow E > C > R > D > S E			-				
Max. 7 digits including sign and decimal point flow rate : Instantaneous flow velocity : and decimal fraction 3 digits fixed Totalized flow : Totalized flow 8 digits including decimal point Symbols are displayed at the right side of the LCD. • "R": No echo signal received. (upper line of the LCD) • "B": Disturbance detected. (upper line of the LCD) • "C": CHECK function is active. (upper line of the LCD) • "B": Low voltage of coin battery (lower line of the LCD) • "F.S.": Full Scale (Upper line of the LCD) • "F.S.": Full Scale (Upper line of the LCD) (During exceeding the maximum flow rate of measurement range, indication would be alternated flickering "the maximum value of measurement range" and "F.S." symbol at the upper & left side of LCD.) Note: 1) The priority between the above symbols (indicated at the same position) as follow							
Biopicy argits flow velocity : and decimal fraction 3 digits fixed Totalized flow : Totalized flow 8 digits including decimal point Symbols are displayed at the right side of the LCD. "R": No echo signal received. (upper line of the LCD) "D": Disturbance detected. (upper line of the LCD) "S": Receiving echo signal saturated. (upper line of the LCD) "C": CHECK function is active. (upper line of the LCD) "B": Low voltage of coin battery (lower line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "E": Fruit Scale (Upper line of the LCD) "F.S.": Full Scale (Upper line of the LCD) "During exceeding the maximum flow rate of measurement range, indication would be alternated flickering "the maximum value of measurement range" and "F.S." symbol at the upper & left side of LCD.) Note: 1) The priority between the above symbols (indicated at the same position) as follow E > C > R > D > S				Max. 7 digits including sign and decimal point			
flow velocity : and decimal fraction 3 digits fixed Totalized flow : Totalized flow 8 digits including decimal point Symbols are displayed at the right side of the LCD. "R": No echo signal received. (upper line of the LCD) "D": Disturbance detected. (upper line of the LCD) "S": Receiving echo signal saturated. (upper line of the LCD) "C": CHECK function is active. (upper line of the LCD) "B": Low voltage of coin battery (lower line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "F.S.": Full Scale (Upper line of the LCD) "F.S.": Full Scale (Upper line of the LCD) "Totalized flickering "the maximum value of measurement range, indication would be alternated flickering "the maximum value of measurement range" and "F.S." symbol at the upper & left side of LCD.) Note: 1) The priority between the above symbols (indicated at the same position) as follow E > C > R > D > S E		Display digits	Instantaneous	sign section 1 digit, integer section 2 digits			
Warnings Symbols are displayed at the right side of the LCD. "R": No echo signal received. (upper line of the LCD) "B": Disturbance detected. (upper line of the LCD) "S": Receiving echo signal saturated. (upper line of the LCD) "S": CHECK function is active. (upper line of the LCD) "B": Low voltage of coin battery (lower line of the LCD) "E": Error occurred by equipment failure. (upper line of the LCD) "F.S.": Full Scale (Upper line of the LCD) (During exceeding the maximum flow rate of measurement range, indication would be alternated flickering "the maximum value of measurement range" and "F.S." symbol at the upper & left side of LCD.) Note: 1) The priority between the above symbols (indicated at the same position) as follow E > C > R > D > S			flow velocity :	and decimal fraction 3 digits fixed			
• "R": No echo signal received. (upper line of the LCD) • "D": Disturbance detected. (upper line of the LCD) • "S": Receiving echo signal saturated. (upper line of the LCD) • "C": CHECK function is active. (upper line of the LCD) • "B": Low voltage of coin battery (lower line of the LCD) • "E": Error occurred by equipment failure. (upper line of the LCD) • "F.S.": Full Scale (Upper line of the LCD) (During exceeding the maximum flow rate of measurement range, indication would be alternated flickering "the maximum value of measurement range" and "F.S." symbol at the upper & left side of LCD.) Note: 1) The priority between the above symbols (indicated at the same position) as follow E > C > R > D > S			Totalized flow :	Totalized flow 8 digits including decimal point			
Warnings • "D": Disturbance detected. (upper line of the LCD) • "S": Receiving echo signal saturated. (upper line of the LCD) • "C": CHECK function is active. (upper line of the LCD) • "B": Low voltage of coin battery (lower line of the LCD) • "E": Error occurred by equipment failure. (upper line of the LCD) • "F.S.": Full Scale (Upper line of the LCD) (During exceeding the maximum flow rate of measurement range, indication would be alternated flickering "the maximum value of measurement range" and "F.S." symbol at the upper & left side of LCD.) Note: 1) The priority between the above symbols (indicated at the same position) as follow E > C > R > D > S			Symbols are displayed at the right side of the LCD.				
Warnings • "S": Receiving echo signal saturated. (upper line of the LCD) • "C": CHECK function is active. (upper line of the LCD) • "B": Low voltage of coin battery (lower line of the LCD) • "E": Error occurred by equipment failure. (upper line of the LCD) • "F.S.": Full Scale (Upper line of the LCD) (During exceeding the maximum flow rate of measurement range, indication would be alternated flickering "the maximum value of measurement range" and "F.S." symbol at the upper & left side of LCD.) Note: 1) The priority between the above symbols (indicated at the same position) as follow $E > C > R > D > S$			• "R": No echo signal received. (upper line of the LCD)				
Warnings • "C": CHECK function is active. (upper line of the LCD) • "B": Low voltage of coin battery (lower line of the LCD) • "E": Error occurred by equipment failure. (upper line of the LCD) • "F.S.": Full Scale (Upper line of the LCD) (During exceeding the maximum flow rate of measurement range, indication would be alternated flickering "the maximum value of measurement range" and "F.S." symbol at the upper & left side of LCD.) Note: 1) The priority between the above symbols (indicated at the same position) as follow E > C > R > D > S							
Warnings • "B": Low voltage of coin battery (lower line of the LCD) • "E": Error occurred by equipment failure. (upper line of the LCD) • "F.S.": Full Scale (Upper line of the LCD) (During exceeding the maximum flow rate of measurement range, indication would be alternated flickering "the maximum value of measurement range" and "F.S." symbol at the upper & left side of LCD.) Note: 1) The priority between the above symbols (indicated at the same position) as follow E > C > R > D > S							
Warnings • "E": Error occurred by equipment failure. (upper line of the LCD) • "F.S.": Full Scale (Upper line of the LCD) (During exceeding the maximum flow rate of measurement range, indication would be alternated flickering "the maximum value of measurement range" and "F.S." symbol at the upper & left side of LCD.) Note: 1) The priority between the above symbols (indicated at the same position) as follow E > C > R > D > S			,				
 • "F.S.": Full Scale (Upper line of the LCD) (During exceeding the maximum flow rate of measurement range, indication would be alternated flickering "the maximum value of measurement range" and "F.S." symbol at the upper & left side of LCD.) Note:							
 (During exceeding the maximum flow rate of measurement range, indication would be alternated flickering "the maximum value of measurement range" and "F.S." symbol at the upper & left side of LCD.) Note: 1) The priority between the above symbols (indicated at the same position) as follow E > C > R > D > S 		Warnings					
 indication would be alternated flickering "the maximum value of measurement range" and "F.S." symbol at the upper & left side of LCD.) Note: 1) The priority between the above symbols (indicated at the same position) as follow E > C > R > D > S 		-					
measurement range" and "F.S." symbol at the upper & left side of LCD.) Note: 1) The priority between the above symbols (indicated at the same position) as follow E > C > R > D > S							
Note: 1) The priority between the above symbols (indicated at the same position) as follow E > C > R > D > S			_				
1) The priority between the above symbols (indicated at the same position) as follow E > C > R > D > S							
E>C>R>D>S				veen the above symbols (indicated at the same position) as follows			
EITOI CODE ERR-01 LO ERR-03 DISPIAYED DURING EQUIPMENT TAILURE.		Error code		ERR-63" displayed during equipment failure.			

Units	Flow rate units	 Multiplier u (x10⁻⁶), m (x10⁻³), x1, k (x10³), M (x10⁶) Flow volume units L/, m³/, g/, t/, ft³/, bbl/, gal/, acf/ Flow time units /s, /min, /h, /D
	Totalizing units	 Multiplier u (x10⁻⁶), m (x10⁻³), x1, k (x10³), M (x10⁶) Decimal point position ******* (x1), ******.** (x0.1), *****.** (x0.01) Units L, m³, g, t, ft³, bbl, gal, acf

Function		Cute (Zeree) flow when flow falls helps proceeribed instantaneous
	Low flow out	Cuts (Zeros) flow when flow falls below prescribed instantaneous
	Low flow cut	flow rate. Used in order to avoid output of flow values other than 0
		when measurement value during still flow becomes irratic.
		If measurement cannot be made when no echo is received
		continuously over the setting time (determined transition time), status is
	No Echo receiving	changed to
	warning	- Display "R" on LCD.
		 Selected output operation (Analog & LCD)
		- Contact output of warning if set.
		 Count up as history on ROFF counter
		Check whether processing values are measured properly or not
	Disturbance	and if determined to be disturbed conditions then measuring
	detection	values are eliminated.
	detection	- Display "D" on the display
		- Count up as history on DIS. counter
	Zero point	Zero point can be independently compensated (shifted) for flow
	correction	rate.
	Span correction	Slope of span line can be corrected for flow rate.
		Rapid flow rate changes would be smoother by this filter.
	Output Filter	Note: This value is meaning the time until measuring flow rate reaches 90%
		by step-up increment.
		If failure is diagnosed on following items, transitions to be
		selected status.
		Diagnostic checks:
		1) Transmitting and receiving circuit
		2) CPU
	Self-diagnostics	3) DSP
	and	4) Internal clock
	failure processing	5) Memory Area (for setting parameter)
		6) Parameters
		- Selected analog output transition status as follows.
		0% (4mA), hold, 100% (20mA), burnout (20.8mA)
		- Display "ERR-**" on LCD. (** is error number.)
		- Contact output of warning if set.
		Totalized flow values and all setting parameters are retained in
		memory with lithium battery even if power failure.
		Note:
	Data rotantian	1) Setting Parameters are retained in nonvolatile memory.
	Data retention	2) Totalized flow value, Logged data and ROFF/DIS. counters are retained in
		memory which held by the battery.
		 Data retained in memory which held by the battery clears if battery removed without power supply.
		4) 5 year life at room temperature.
		5) No battery recharging function.
		- Simulated flow check mode
	Check Function	- Analog output check mode
		- Totalized pulse output check mode

Function (cont.)	Automatic gain control (AGC Function)	Receiver gain is automatically adjusted to the optimum level in response to changes in receiver sensitivity during measurement.
	Totalized value	Totalized values can be freely preset.
	preset	Preset Range: 0 to 99999999
	Error historic	Count "No Echo receiving warning" & "Disturbance detection"
	counter	when it occurred.

Power	$AC100 \text{ to } 230V/\pm/10\%/(50/60 \text{ Hz} \pm 2\text{ Hz})$							
	AC100 to 230V +/-10% (50/60 Hz ±2Hz) Option: DC24V±20% (This option must be pre-selected.)							
supply								
	Momentary outage AC input: 20ms							
Devver	DC input: 0ms							
Power	AC100V: 19VA / AC200V: 23VA							
consumption	DC24V: 9W (Option)							
Fuse	AC: <u>IEC 60127-2 SS5</u>							
	Cartridge fuse-links, φ5.2x20 mm, Rating 2A/250V, Time-lag							
	and High Breaking Capacity (1500A)							
	DC: <u>IEC 60127-2 SS5</u>							
	Cartridge fuse-links, φ5.2x20 mm, Rating 4A/250V, Time-lag							
	and High Breaking Capacity (1500A)							
Rush	Less than 15A at AC100V / Less than 25A at AC200V							
Current	Less than 15A at DC24V (Option)							
Operating								
temperature	14 to 122°F (-10 to +50°C)							
range								
Storage								
temperature	-4 to 140°F (-20 to +60°C)							
range								
Operating	Less than 90% RH, non-condensation							
humidity range								
Main unit	Protection Degree IP65 (IEC 60529)							
construction								
Wiring	I/O and power ports: PG13.5 x 3, applicable cable diameter 7 to 12.5 mm							
Connection	Sensor ports: PG9 x 2, applicable cable diameter 4.5 to 8 mm							
port	Other: USB-B female type for USB communication x 1							
Case	ABS (Color: White gray)							
material								
Weight	Approximately 5 lbs. (2.1 kg)							
Dimensions	210mm (W) x 210mm (H) x 100mm (D), not including protrusions							
	EMC Directive 2004/108/EC							
	Harmonized Standard / EN61326-1:2006 + EN 61326-2-3:2006							
	Separation into group / Group I							
	Division into classes / Class A							
European	Location intended for use / In industrial locations							
Compliance								
(CE marking)	Low Voltage Directive 2006/95/EC							
	Harmonized Standard / EN61010-1 2nd Edition							
	Over voltage category II							
	Pollution degree II							
	Altitude up to 2000m							

4-3. Transducers


Transducer	SE104720T
Temperature	
range	-4 to 140°F (-20 to 60°C)
Protection	IP65 (When filled with resin by the installer)
class	IP67 as an option (Resin-filled product, shipped with cable connected)
Compatible	
cable	RG-223/U
Maximum cable	
length	30 m

4-4. Optional parts

IP67 detector	Shipped from the fac	ctory with a 30 m cable connected				
Power cable	St's/option	Prepared by user				
(*1)	Model name	OLFLEX Classic 100				
		multi-conductor, flexible power and control cable				
	Part number	10060				
	Manufacturer	LAPP KABEL				
	Details	3 conductors				
		AWG16, 1.5 mm ²				
		Nominal outer diameter 8.1 mm				
Mounting plate	For wall mounting or standard pipe (DN50mm) mounting (Fig. 1-2-3-3)					
	Consist of:					
	Mounting plate, U bo	olt, Wing nut, Spring washer, Flat washer, screw M4.				
Expansion						
board						
AIN-10 (*2)	Analog input: Insula	ted passive input type				
Expansion						
board	Digital communication					
485-20 (*2)	Insulated RS-485, M	IODBUS-RTU compatible				
(*1)Power cable is	specified to comply y	with EC directive				


(*1)Power cable is specified to comply with EC directive. (*2)Expansion boards can be mounted simultaneously.

5. Analog output profiles



6. Transducer installation


- To minimize measurement errors arising from flow profile, a straight pipe run is necessary for transducer installation.
- Liquid should fill the pipes completely and transducers should be installed in locations which have no air bubbles.
- For measurements in underground piping, the usual means is to locate the flowmeter in a pit to facilitate transducer installation, maintenance, and testing.





[Refer to JEMIS 032-1987]


D : Pipe Diameter

7.Dimensions











Mounting Fixture for Transducer (Z method)


8. Wiring Connection 8-1. Output connection



9. System Wiring Connection



10. Building a flowmeter pit



- In principle, when measurement is of underground pipe, it is suggested to prepare dedicated flowmeter pit.
- It is not necessary to prepare a flowmeter pit in the case of indoor or outdoor piping, but proper footing should be planned for transducer mounting and equipment adjustments where the pipe is located high off the floor or when pipe diameter is large.


Building a flowmeter pit

- 1. Select pit site (taking into consideration the following points)
 - 1) Straight section of pipe is required for installation of transducers as explained under Part 5.
 - 2) Consult manufacturer if an adjustable valve or pump is used.
 - 3) To prevent noise interference or signal attenuation, coaxial cable used transducers and main unit should be less than 30m.
- 2. Size and construction of flowmeter pit
 - 1) Using above schematic as reference, determine size of flowmeter pit based on actual piping position and conditions. Height of pit should allow person to stand while working.
 - 2) Implement countermeasures for floods such as drainage gutters, etc. (Install water pump where water is liable to accumulate or flood.)
 - Consult Manufacturer for other specific conditions. (Above dimensions are ideal and not the minimum required.)

Transducer installation

- 1. Strip paint/coating from piping surfaces at transducer mounting locations and fix transducers on piping using the accessory mounting fixtures. When mounting transducers according to the "V" method, the distance separating the transducers should be about the diameter of the pipe. If the "Z" method is used, the distance should be one half of the diameter.
- 2. After installing and adjusting the transducers, remove transducer mountings, and coat pipe surface with anti-rust paint.

11. Appendix Flow Volume and Average Flow Velocity



Specification Code

Model number table

1	Node	el nui	mbe	r	Specificatior code			on	Contents
1	2	3	4	5	6	7	8	9	
L	F	8	1	0					ULTRASONIC FLOWMETER
					А				Power supply 100-230Vac,50/60Hz
					D				24Vdc±20%
						A			Transducers Type Standard (requires connecting to cables)
						В			Factory epoxy potting (Meets IP67, includes connecting cables to transducers only)
							0 1 2 3		I/O card No need Rs-485 Modbus Communication Card Analog Input Card(1ch) Both of RS-485 Modbus and Analog Input
								В	Mounting for Main unit Mounting plate (wall, surface or stand pipe)

Note:

All I/O options must be selected at time of ordering.

All units come with stainless steel mounting plate.

Coaxial cables

	Code					Contonto	
1	2	3	4	5	6	Contents	
С	С	L	0			Length ※1	
-				0	0	Without cable	
				0	5	5m	
				1	0	10m	
				1	5	15m	
				2	0	20m	
				2	5	25m	
				3	0	30m	

X1 All Meters are shipped from the factory with two (2) 10 m cables.



TOSHIBA INTERNATIONAL CORPORATION

INDUSTRIAL DIVISION 13131 WEST LITTLE YORK ROAD PHONE: (713) 466-0277 FACSIMILE: (713)896-5225 <u>EMAIL: instrument@tic.toshiba.com</u> www.toshiba.com/ind

HOUSTON, TX 77041 (800) 231-1412