

• 15W0102B500 •

SINUS PENTA PENTA MARINE IRIS BLUE SOLARDRIVE PLUS

USER MANUAL - Motor Drives Accessories -

Issued on 05/06/2019
R.01

English

- This manual is integrant and essential to the product. Carefully read the instructions contained herein as they provide important hints for use and maintenance safety.
- This device is to be used only for the purposes it has been designed to. Other uses should be considered improper and dangerous. The manufacturer is not responsible for possible damages caused by improper, erroneous and irrational uses.
- Enertronica Santerno S.p.A. is responsible for the product in its original setting.
- Any changes to the structure or operating cycle of the product must be performed or authorized by Enertronica Santerno S.p.A..
- Enertronica Santerno S.p.A. assumes no responsibility for the consequences resulting by the use of non-original spare-parts.
- Enertronica Santerno S.p.A. reserves the right to make any technical changes to this manual and to the product without prior notice. If printing errors or similar are detected, the corrections will be included in the new releases of the manual.
- The information contained herein is the property of Enertronica Santerno S.p.A. and cannot be reproduced. Enertronica Santerno S.p.A. enforces its rights on the drawings and catalogues according to the law.



Enertronica Santerno S.p.A.
Via della Concia, 7 – 40023 Castel Guelfo (BO) Italy
Tel. +39 0542 489711 – Fax +39 0542 489722
santerno.com info@santerno.com

REVISION INDEX

The following subjects covered in this User Manual (ID number **15W0102B500**, revision R.01) have been added, changed or suppressed with respect to the previous version of this User Manual (ID number **15W0102B500**, revision R.00).

The ENERTRONICA GROUP logo has been added.

The nameplates for BU200 and BU600 have been edited.

A note reading “Decisive voltage class C according to EN 61800-5-1” has been added for BU600.

The operating conditions of the available Braking Resistors have been made clearer.

IP23 Box Resistors, 4 kW to 64 kW: Part Numbers have been split between 1 kV and 3 kV.

The NEMA 1 GLANDKIT section has been added.

Input inductors: a note concerning the dedicated transformer featuring Vdc=5% or higher has been added.

The Output Toroidal Filters section has been added.

Option Boards For Fieldbus (Slot B): compatibility to firmware version has been added.

Option Boards For Fieldbus (Slot B): CClick and Powerlink removed (not available).

The meaning of the LEDs for each field bus has been made clearer in Status LEDs on the B40 Series Boards.

The BRIDGE MINI (SLOT B) section has been added.

The ES851 Datalogger Board (SLOT B) has been removed.

In ES847 I/O Expansion Board (Slot C), inputs XAIN1, XAIN2, XAIN3, XAIN6 have been removed (not available).

SANTERNO USER MANUALS MENTIONED IN THIS GUIDE

The following Santerno User Manuals are mentioned throughout this User Manual:

User Manual	User Manual Part Number			
	Sinus Penta	Penta Marine	Iris Blue	Solardrive Plus
Programming Guide	15R0102B200 SINUS PENTA Programming Guide	15R0102B200 SINUS PENTA Programming Guide	15R1102B200 IRIS BLUE Programming Guide	15P00SDB100 SOLARDRIVE PLUS Installation and Programming Guide
Installation Guide	15P0102B1 SINUS PENTA Installation Guide	15P0102B1 SINUS PENTA Installation Guide	15P1102B100 IRIS BLUE Installation Guide	15P00SDB100 SOLARDRIVE PLUS Installation and Programming Guide
Guide to the Regenerative Application	15Q0102B00 SINUS PENTA – Guide to the Regenerative Application	15Q0102B00 SINUS PENTA – Guide to the Regenerative Application	N/A	N/A
Guide to the Synchronous Motor Application	15Q0102B200 SINUS PENTA – Guide to the Synchronous Motor Application	15Q0102B200 SINUS PENTA - Guide to the Synchronous Motor Application	N/A	N/A
PROFIdrive COMMUNICATIONS BOARD – Installation and Programming Guide	15G0010B1 PROFIdrive COMMUNICATIONS BOARD – Installation and Programming Guide	15G0010B1 PROFIdrive COMMUNICATIONS BOARD - Installation and Programming Guide	15G0010B1 PROFIdrive COMMUNICATIONS BOARD - Installation and Programming Guide	15G0010B1 PROFIdrive COMMUNICATIONS BOARD - Installation and Programming Guide
BRIDGE MINI – User Manual	15P4600B100 BRIDGE MINI – User Manual	15P4600B100 BRIDGE MINI – User Manual	15P4600B100 BRIDGE MINI – User Manual	15P4600B100 BRIDGE MINI – User Manual

	User Manual Part Number			
User Manual	Sinus Penta	Penta Marine	Iris Blue	Solardrive Plus
Sine Filters – User Manual	15N0040B100 Sine Filters – User Manual	15N0040B100 Sine Filters – User Manual	15N0040B100 Sine Filters – User Manual	15N0040B100 Sine Filters – User Manual
Assembly Instructions for Through-panel Kit S22	15W0102B100 SINUS PENTA - Assembly Instructions for Through-panel Kit S22	15W0102B100 SINUS PENTA - Assembly Instructions for Through-panel Kit S22	N/A	15W0102B100 SINUS PENTA - Assembly Instructions for Through-panel Kit S22
Assembly Instructions for Through-panel Kit S32	15W0102B200 SINUS PENTA - Assembly Instructions for Through-panel Kit S32	15W0102B200 SINUS PENTA - Assembly Instructions for Through-panel Kit S32	N/A	15W0102B200 SINUS PENTA - Assembly Instructions for Through-panel Kit S32
Safe Torque Off Function – Application Manual	15W0102B300 Safe Torque Off Function – Application Manual	15W0102B300 Safe Torque Off Function – Application Manual	15W0102B300 Safe Torque Off Function – Application Manual	15W0102B300 Safe Torque Off Function – Application Manual
AC/DC Units	15P0102B300 AC/DC UNIT 465 – AC/DC UNIT 1050	15P0102B300 AC/DC UNIT 465 – AC/DC UNIT 1050	N/A	N/A
RemoteDrive	16B0901B1 Remote Drive REMOTE CONTROL – User Manual	16B0901B1 Remote Drive DRIVE REMOTE CONTROL – User Manual	N/A	N/A
BU600 – Programming Guide	15R0102B500 BU600 – Programming Guide	15R0102B500 BU600 – Programming Guide	N/A	N/A

TABLE OF CONTENTS

REVISION INDEX.....	2
SANTERNO USER MANUALS MENTIONED IN THIS GUIDE	2
1. OVERVIEW	16
2. POWER SUPPLY UNIT FOR DRIVES S41..S52 (SU465).....	16
2.1. DELIVERY CHECK.....	17
2.2. INSTALLING AND OPERATING THE SU465	17
2.3. SU465 NAMEPLATE.....	17
2.4. SU465 OPERATING MODE.....	18
2.4.1. SU465 OPERATION AS A 12-PULSE SUPPLY UNIT.....	18
2.5. SYSTEM REQUIREMENTS.....	19
2.6. TECHNICAL SPECIFICATIONS	19
2.7. INSTALLING THE SU465	20
2.7.1. ENVIRONMENTAL REQUIREMENTS FOR THE SU465 INSTALLATION, STORAGE AND TRANSPORT	20
2.7.2. MOUNTING THE SU465	21
2.7.3. IP21 KIT	22
2.7.4. THROUGH-PANEL KIT	23
2.7.5. NEMA1 KIT	24
2.7.6. POWER TERMINALS AND SIGNAL TERMINALS LAYOUT.....	25
2.7.7. SIGNAL CONNECTIONS	26
2.7.8. WIRING THE SU465	29
2.8. CROSS-SECTIONS OF THE POWER CABLES AND SIZES OF THE PROTECTIVE DEVICES WHEN THE SU465 IS INSTALLED	30
2.9. EARTH BONDING OF THE SU465.....	31
2.10. SCHEDULED MAINTENANCE OF THE SU465.....	31
2.11. INDUCTORS TO BE APPLIED TO THE DRIVE AND THE SU465 – 12-PULSE CONNECTION.....	31
2.12. INDUCTORS TO BE APPLIED TO THE DRIVE AND THE SU465 – 18-PULSE CONNECTION.....	32
3. RESISTIVE BRAKING.....	33
3.1 BRAKING RESISTORS TO BE SUPPLIED TO THE DRIVES EQUIPPED WITH INTERNAL BRAKING UNIT	34
3.1.1. APPLICATIONS WITH DUTY CYCLE 10% - CLASS 2T.....	35
3.1.2. APPLICATIONS WITH DUTY CYCLE 20% - CLASS 2T	36
3.1.3. APPLICATIONS WITH DUTY CYCLE 50% - CLASS 2T	37
3.1.4. APPLICATIONS WITH DUTY CYCLE 10% - CLASS 4T	38
3.1.5. APPLICATIONS WITH DUTY CYCLE 20% - CLASS 4T	39
3.1.6. APPLICATIONS WITH DUTY CYCLE 50% - CLASS 4T	40

- 3.1.7. APPLICATIONS WITH DUTY CYCLE 10% - CLASS 5T 41
- 3.1.8. APPLICATIONS WITH DUTY CYCLE 20% - CLASS 5T 42
- 3.1.9. APPLICATIONS WITH DUTY CYCLE 50% - CLASS 5T 43
- 3.1.10. APPLICATIONS WITH DUTY CYCLE 10% - CLASS 6T 44
- 3.1.11. APPLICATIONS WITH DUTY CYCLE 20% - CLASS 6T 45
- 3.1.12. APPLICATIONS WITH DUTY CYCLE 50% - CLASS 6T 46
- 3.2. BRAKING UNIT (BU200 2T-4T) FOR S41-S51 AND S60-S60P 47
 - 3.2.1. DELIVERY CHECK 47
 - 3.2.2. OPERATION 49
 - 3.2.3. CONFIGURATION JUMPERS 49
 - 3.2.4. ADJUSTING TRIMMERS 50
 - 3.2.5. INDICATOR LEDS 51
 - 3.2.6. RATINGS 51
 - 3.2.7. INSTALLING THE BU200 52
 - 3.2.8. EARTH BONDING OF THE BU200 56
 - 3.2.9. SCHEDULED MAINTENANCE OF THE BU200 56
 - 3.2.10. BRAKING RESISTORS FOR BU200 2T 57
 - 3.2.11. BRAKING RESISTORS FOR BU200 4T 59
- 3.3. BRAKING UNITS FOR S41..S52 AND THEIR PARALLEL CONFIGURATION AND DRIVES S60-S60P (BU600 4T-5T-6T) 61
 - 3.3.1. DELIVERY CHECK 61
 - 3.3.2. OPERATING MODE OF THE BU600 CONNECTED TO DRIVES S41..S52 AND THEIR CONFIGURATION IN PARALLEL 62
 - 3.3.3. OPERATING MODE OF THE BU600 WHEN CONNECTED TO S60 AND S60P DRIVES OR A DC-BUS MADE UP OF SINUS PENTA /PENTA MARINE DRIVES FROM DIFFERENT SIZES 63
 - 3.3.4. BU600 USED AS A GENERAL-PURPOSE BRAKING UNIT TO BE CONNECTED TO A DC-BUS 63
 - 3.3.5. DIAGNOSTICS 64
 - 3.3.6. SPECIFICATIONS 65
 - 3.3.7. INSTALLING THE BU600 65
 - 3.3.8. EARTH BONDING OF THE BU600 74
 - 3.3.9. PROTECTING THE BRAKING RESISTORS 74
 - 3.3.10. SCHEDULED MAINTENANCE OF THE BU600 74
 - 3.3.11. BRAKING RESISTORS TO BE APPLIED TO BU600 4T 75
 - 3.3.12. BRAKING RESISTORS TO BE APPLIED TO BU600 5T-6T 78
 - 3.3.13. SERIAL COMMUNICATIONS 83
 - 3.3.14. AUXILIARY POWER SUPPLY 86
- 3.4. BRAKING UNIT BU1440 FOR MODULAR INVERTERS (BU1440 4T AND BU1440 5T-6T) 87
 - 3.4.1. DELIVERY CHECK 87
 - 3.4.2. OPERATION 88
 - 3.4.3. RATINGS 88
 - 3.4.4. INSTALLING THE BU1440 89

3.4.5.	EARTH BONDING OF THE BU1440.....	97
3.4.6.	SCHEDULED MAINTENANCE OF THE BU1440	97
3.4.7.	BRAKING RESISTORS FOR BU1440 4T	97
3.4.8.	BRAKING RESISTORS FOR BU1440 5T-6T.....	100
3.5.	AVAILABLE BRAKING RESISTORS	104
3.5.1.	350W MODELS (IP55).....	104
3.5.2.	550W MODELS (IP33).....	105
3.5.3.	IP54 MODELS FROM 1100W TO 2200W	106
3.5.4.	IP20 MODELS FROM 4KW-8KW-12KW	108
3.5.5.	IP23 BOXES FROM 4KW TO 64KW	110
4.	NEMA 1 GLANDKIT	119
4.1.1.	NAMEPLATE NEMA 1 GLANDKIT.....	119
4.2.	IDENTIFICATION DATA	120
4.2.1.	2T-4T VOLTAGE CLASSES.....	120
4.2.2.	5T-6T VOLTAGE CLASSES.....	120
4.2.3.	OVERALL DIMENSIONS WHEN INSTALLING AN INVERTER WITH THE NEMA 1 GLANDKIT	121
5.	KEYPAD REMOTING KIT	122
5.1.	REMOTING THE KEYPAD ON THE CABINET.....	122
6.	INDUCTORS	123
6.1.	INPUT INDUCTORS	123
6.2.	OUTPUT INDUCTORS (DU/DT FILTERS).....	126
6.3.	APPLYING THE INDUCTOR TO THE INVERTER.....	127
6.3.1.	CLASS 2T – AC AND DC INDUCTORS.....	127
6.3.2.	CLASS 4T – AC AND DC INDUCTORS.....	128
6.3.3.	CLASS 5T-6T – AC AND DC INDUCTORS	129
6.4.	INDUCTANCE RATINGS	130
6.4.1.	CLASS 2T-4T – AC 3-PHASE INDUCTORS.....	130
6.4.2.	CLASS 5T-6T – AC 3-PHASE INDUCTORS.....	130
6.4.3.	CLASS 2T-4T – DC INDUCTORS.....	132
6.4.4.	CLASS 5T-6T – DC INDUCTORS.....	132
6.4.5.	CLASS 2T, 4T, 5T, 6T – 3-PHASE DU/DT INDUCTORS	134
6.5.	CLASS 2T – 3-PHASE AC INDUCTORS IN IP54 CABINET	135
6.6.	CLASS 4T – 3-PHASE AC INDUCTORS IN IP54 CABINET	136
6.7.	CLASS 5T-6T – 3-PHASE AC INDUCTORS IN IP54 CABINET	138
6.8.	OUTPUT SINGLE-PHASE INDUCTORS FOR MODULAR INVERTERS S75, S80, S90 140	
6.8.1.	AC SINGLE-PHASE INDUCTORS – CLASS 4T-5T-6T.....	140
6.9.	SINE FILTERS.....	141
6.10.	OUTPUT TOROIDAL FILTERS.....	142
7.	ES836/2 ENCODER BOARD (SLOT A)	143
7.1.	IDENTIFICATION DATA	143

- 7.2. ENVIRONMENTAL REQUIREMENTS 144
- 7.3. ELECTRICAL SPECIFICATIONS..... 144
- 7.4. INSTALLING ES836/2 ENCODER BOARD ON THE INVERTER (SLOT A)..... 145
- 7.5. TERMINALS IN ENCODER BOARD 146
- 7.6. CONFIGURATION DIP-SWITCHES 146
- 7.7. JUMPER SELECTING THE TYPE OF ENCODER SUPPLY 147
- 7.8. ADJUSTING TRIMMER 148
- 7.9. ENCODER WIRING AND CONFIGURATION 148
- 7.10. WIRING THE ENCODER CABLE 153
- 8. ES913 LINE DRIVER ENCODER BOARD (SLOT A).....154
 - 8.1. IDENTIFICATION DATA 154
 - 8.2. ENVIRONMENTAL REQUIREMENTS 154
 - 8.3. ELECTRICAL SPECIFICATIONS..... 155
 - 8.4. INSTALLING THE LINE DRIVER BOARD ON THE INVERTER (SLOT A) 156
 - 8.5. TERMINALS IN THE LINE DRIVER ENCODER BOARD 157
 - 8.6. CONFIGURATION DIP-SWITCHES 157
 - 8.7. ENCODER SUPPLY SELECTION JUMPER..... 158
 - 8.8. ADJUSTING TRIMMER 159
- 9. ES860 SIN/COS ENCODER BOARD (SLOT A)160
 - 9.1. IDENTIFICATION DATA 162
 - 9.2. INSTALLING ES860 BOARD ON THE INVERTER (SLOT A) 162
 - 9.2.1. SIN/COS ENCODER CONNECTOR..... 164
 - 9.3. ES860 CONFIGURATION AND OPERATING MODES 165
 - 9.3.1. CONFIGURING AND ADJUSTING THE ENCODER SUPPLY VOLTAGE..... 166
 - 9.4. CONNECTING THE ENCODER CABLE 167
 - 9.5. ENVIRONMENTAL REQUIREMENTS 168
 - 9.6. ELECTRICAL RATINGS 168
- 10. ES822 ISOLATED SERIAL BOARD (SLOT B)170
 - 10.1. IDENTIFICATION DATA 170
 - 10.2. ENVIRONMENTAL REQUIREMENTS 170
 - 10.3. ELECTRICAL FEATURES 171
 - 10.4. INSTALLING ES822 BOARD ON THE INVERTER (SLOT B) 172
 - 10.5. JUMPER FOR RS232/RS485 SELECTION 173
 - 10.6. DIP-SWITCH FOR RS485 TERMINATOR 173
- 11. OPTION BOARDS FOR FIELDBUS (SLOT B)174
 - 11.1. IDENTIFICATION DATA 175
 - 11.2. INSTALLING THE FIELDBUS BOARD ON THE INVERTER (SLOT B) 176
 - 11.3. STATUS LEDS ON THE B40 SERIES BOARDS 178
 - 11.3.1. NSTA/MSTA LEDS - PROFIBUS DP 178
 - 11.3.2. NSTA/MSTA LEDS - DEVICENET 178

11.3.3. NSTA/MSTA LEDS - PROFINET	179
11.3.4. NSTA/MSTA LEDS LEDS - MODBUS/TCP	179
11.3.5. NSTA/MSTA LEDS - ETHERNET IP	179
11.3.6. NSTA/MSTA LEDS - ETHERCAT	179
11.3.7. PROFINET LINK LEDS	180
11.3.8. MODBUS/TCP LINK LEDS.....	180
11.3.9. ETHERNET IP LINK LEDS.....	180
11.3.10. ETHERCAT LINK LEDS	180
11.4. STATUS LEDS ON THE ANYBUS-S BOARDS	182
11.4.1. LEDS FOR FIELDBUS INTERFACE CPU DIAGNOSTICS	182
11.4.2. LEDS FOR PROFIBUS-DP® BOARD DIAGNOSTICS	183
11.4.3. LEDS FOR DEVICENET® BOARD DIAGNOSTICS	183
11.4.4. LEDS FOR CANOPEN® BOARD DIAGNOSTICS.....	184
11.4.5. LEDS FOR ETHERNET BOARD DIAGNOSTICS.....	184
11.5. B40 SERIES BOARD FOR PROFIBUS-DP®.....	185
11.5.1. PROFIBUS® FIELDBUS CONNECTOR	186
11.5.2. BUS CONFIGURATION	186
11.5.3. CONNECTION TO THE FIELDBUS	187
11.6. B40 SERIES BOARDS FEATURING ETHERNET INTERFACE (PROFINET IRT, MODBUS/TCP, ETHERCAT, ETHERNET/IP).....	188
11.6.1. ETHERNET CONNECTOR	189
11.6.2. CONNECTION TO THE NETWORK	189
11.6.3. CONFIGURING B40 SERIES BOARDS WITH ETHERNET INTERFACE	190
11.7. B40 SERIES BOARD FOR DEVICENET®.....	193
11.7.1. FIELDBUS DEVICENET TERMINAL BOARD.....	193
11.7.2. CONNECTION TO THE FIELDBUS	194
11.8. ANYBUS-S PROFIBUS-DP® BOARD	195
11.8.1. PROFIBUS® FIELDBUS CONNECTOR	196
11.8.2. CONFIGURATION OF THE PROFIBUS-DP COMMUNICATIONS BOARD	196
11.8.3. CONNECTION TO THE FIELDBUS	198
11.9. ANYBUS-S PROFIDRIVE® BOARD	199
11.10. ANYBUS-S DEVICENET® BOARD	199
11.10.1. DEVICENET® FIELDBUS TERMINALS.....	200
11.10.2. BOARD CONFIGURATION	200
11.10.3. CONNECTION TO THE FIELDBUS	201
11.11. ANYBUS-S CANOPEN® FIELDBUS BOARD.....	202
11.11.1. CANOPEN® FIELDBUS CONNECTOR.....	203
11.11.2. BOARD CONFIGURATION	203
11.11.3. CONNECTION TO THE FIELDBUS	204
11.12. ANYBUS-S ETHERNET BOARD FOR MODBUS/TCP	205
11.12.1. ETHERNET CONNECTOR.....	206
11.12.2. CONNECTION TO THE NETWORK	206

11.12.3.	CONFIGURATION OF THE ETHERNET BOARD FOR MODBUS/TCP.....	208
11.13.	ENVIRONMENTAL REQUIREMENTS COMMON TO ALL BOARDS	215
12.	ES919 COMMUNICATIONS BOARD (SLOT B)	216
12.1.	IDENTIFICATION DATA	216
12.2.	ENVIRONMENTAL REQUIREMENTS COMMON TO ALL BOARDS	216
12.3.	ELECTRICAL FEATURES COMMON TO ALL BOARDS.....	217
12.4.	INSTALLING THE ES919 BOARD ON THE DRIVE (SLOT B).....	217
12.4.1.	ES919 BOARD FOR METASYS® N2	218
12.4.2.	CONFIGURATION.....	219
12.4.3.	RS485 CONNECTOR.....	219
12.4.4.	LEDS ON THE ASP485 PROTOCESSOR MODULE	219
12.4.5.	BAUD RATE DIP-SWITCHES	220
12.4.6.	ADDRESS DIP-SWITCHES	220
12.5.	ES919 BOARD FOR BACNET/ETHERNET	220
12.5.1.	ETHERNET CONNECTOR	221
12.5.2.	LEDS ON THE FFP485 PROTOCESSOR MODULE.....	221
12.5.3.	TROUBLESHOOTING TIPS.....	222
12.5.4.	BOARD CONFIGURATION.....	223
12.6.	ES919 BOARD FOR BACNET/RS485	224
12.6.1.	RS485 CONNECTOR.....	224
12.6.2.	BOARD CONFIGURATION	225
13.	BRIDGE MINI (SLOT B).....	226
13.1.	IDENTIFICATION DATA	227
13.2.	INSTALLING THE BOARD ON THE INVERTER (SLOT B).....	227
13.3.	CONNECTIVITY	227
14.	ES847 I/O EXPANSION BOARD (SLOT C).....	228
14.1.	IDENTIFICATION DATA	229
14.2.	INSTALLING ES847 BOARD ON THE INVERTER (SLOT C).....	229
14.3.	ES847 BOARD TERMINALS	231
14.4.	CONFIGURATION DIP-SWITCHES	233
14.5.	POSSIBLE SETTINGS FOR DIP-SWITCHES SW1 AND SW2.....	234
14.6.	WIRING DIAGRAMS.....	236
14.6.1.	CONNECTION OF “FAST” DIFFERENTIAL ANALOG INPUTS	236
14.6.2.	CONNECTION OF “FAST” CURRENT INPUTS	237
14.6.3.	CONNECTING “SLOW” ANALOG INPUTS TO VOLTAGE SOURCES	237
14.6.4.	CONNECTING “SLOW” ANALOG INPUTS TO CURRENT SOURCES.....	238
14.6.5.	CONNECTING “SLOW” ANALOG INPUTS TO THERMISTOR PT100.....	238
14.6.6.	CONNECTING ISOLATED DIGITAL INPUTS.....	239
14.6.7.	CONNECTION TO AN ENCODER OR A FREQUENCY INPUT	240
14.6.8.	CONNECTION TO ISOLATED DIGITAL OUTPUTS.....	241
14.7.	ENVIRONMENTAL REQUIREMENTS.....	242

14.8. ELECTRICAL RATINGS	243
14.8.1. ANALOG INPUTS	243
14.8.2. DIGITAL INPUTS	245
14.8.3. DIGITAL OUTPUTS	246
14.8.4. SUPPLY OUTPUTS	246
15. ES870 RELAY I/O EXPANSION BOARD (SLOT C)	247
15.1. IDENTIFICATION DATA	247
15.2. INSTALLING ES870 BOARD ON THE INVERTER (SLOT C)	248
15.3. ES870 BOARD TERMINALS	249
15.4. CONNECTION TO AN ENCODER OR A FREQUENCY INPUT	250
16. I/O EXPANSION BOARD 120/240VAC ES988 (SLOT C)	251
16.1. IDENTIFICATION DATA	252
16.2. INSTALLING THE ES988 OPTION BOARD ON THE DRIVES (SLOT C)	252
16.3. DIGITAL INPUT TERMINALS AND RELAY OUTPUT	255
16.4. ES988 OPERATING MODE	256
16.5. MAIN FEATURES	258
16.6. ENVIRONMENTAL CONDITIONS	258
16.7. ELECTRICAL SPECIFICATIONS	259
17. ES861 RESOLVER AND INCREMENTAL ENCODER BOARD (SLOT C)	261
17.1. IDENTIFICATION DATA	262
17.2. INSTALLING ES861 BOARD ON THE INVERTER (SLOT C)	263
17.2.1. RESOLVER CONNECTOR	265
17.2.2. INCREMENTAL ENCODER AND DIGITAL LINES CONNECTORS	266
17.3. ES861 CONFIGURATION AND OPERATING MODES	267
17.4. CONFIGURING AND ADJUSTING THE ENCODER SUPPLY VOLTAGE	267
17.5. CONNECTING THE RESOLVER CABLE	269
17.6. ENVIRONMENTAL REQUIREMENTS	270
17.7. ELECTRICAL RATINGS	270
18. ES950 BISS/ENDAT ENCODER BOARD (SLOT C)	272
18.1. IDENTIFICATION DATA	274
18.2. INSTALLING ES950 BOARD ON THE INVERTER (SLOT C)	275
18.2.1. BISS/ENDAT ENCODER CONNECTOR	277
18.2.2. INCREMENTAL ENCODER AND DIGITAL LINE CONNECTORS	278
18.3. ES950 CONFIGURATION AND OPERATING MODES	279
18.3.1. BISS OPERATING MODE	280
18.3.2. ENDAT OPERATING MODE	280
18.3.3. CONFIGURING AND ADJUSTING THE ENCODER SUPPLY VOLTAGE	280
18.4. CONNECTING THE ENCODER CABLE	282
18.4.1. ENVIRONMENTAL REQUIREMENTS	284
18.4.2. ELECTRICAL RATINGS	284

19.	ES966 ENCODER BOARD HIPERFACE (SLOT C)	286
19.1.	PART NUMBER	288
19.2.	INSTALLING THE ES966 BOARD ON THE INVERTER (SLOT C)	288
19.3.	HIPERFACE® ENCODER CONNECTOR.....	291
19.4.	INCREMENTAL ENCODER CONNECTORS AND DIGITAL LINES	292
19.5.	OPERATING MODE AND CONFIGURATION OF HIPERFACE ENCODER BOARD 293	
19.6.	HIPERFACE® OPERATING MODE.....	294
19.7.	CONFIGURING AND ADJUSTING THE ENCODER SUPPLY VOLTAGE	295
19.8.	TEMPERATURE SENSOR CONFIGURATION.....	297
19.9.	CONNECTING THE ENCODER CABLE	297
19.10.	ENVIRONMENTAL REQUIREMENTS	299
19.11.	ELECTRICAL SPECIFICATIONS.....	299
20.	ES914 POWER SUPPLY UNIT BOARD.....	301
20.1.	IDENTIFICATION DATA	303
20.2.	WIRING ES914 BOARD.....	303
21.	“LOC-0-REM” KEY SELECTOR SWITCH AND EMERGENCY PUSH-BUTTON FOR IP54 MODELS	308
21.1.	WIRING IP54 INVERTERS WITH OPTIONAL “LOC-0-REM” KEY SELECTOR SWITCH AND EMERGENCY PUSH-BUTTON	310
22.	INDEX.....	311

Index of Figures

Figure 1: Nameplate for SU465	17
Figure 2: The SU465 in 12-pulse configuration	18
Figure 3: The SU465 as a supply unit of a conversion unit	18
Figure 4: Dimensions and fixing points for the SU465	21
Figure 5: Overall dimensions when using IP21 kit	22
Figure 6: Dimensions and fixing points when using the through-panel kit for the SU465	23
Figure 7: NEMA1 kit and kit installation on the SU465	24
Figure 8: Overall dimensions when installing the NEMA1 kit	24
Figure 9: Power terminals	25
Figure 10: Position of the jumpers in the ES840/1 board	28
Figure 11: Signal terminal board	28
Figure 12: Example of a 9-pin shielded cable for signal connection	29
Figure 13: S41–S52 connections with 12- and 18-pulse SU465	29
Figure 14: Nameplate for BU200 2T-4T	48
Figure 15: Positions of BU200 configuration jumpers	49
Figure 16: Positions of BU200 adjusting trimmers	50
Figure 17: Position of the Indicator LEDs	51
Figure 18: Dimensions and fixing points of BU200	53
Figure 19: Terminals in BU200	54
Figure 20: Connecting one BU200 to the inverter	55
Figure 21: Master – Slave multiple connection	56
Figure 22: Nameplate for BU600 4T-5T-6T	61
Figure 23: BRAKE connector supplied with the drive	62
Figure 24: Cable connecting the drive to braking unit BU600	62
Figure 25: Diagnostic LEDs	64
Figure 26: Dimensions and fixing points of braking unit BU600	66
Figure 27: Power terminals	68
Figure 28: Signal terminals in the BU600	70
Figure 29: Wiring diagram of a single drive with braking unit BU600	71
Figure 30: Signal connections of two BU600 operating as slaves	72
Figure 31: Power connections and location of two BU600 operating as slaves	73
Figure 32: Example of direct and multidrop connection	83
Figure 33: Recommended wiring diagram for “2-wire” MODBUS connection	85
Figure 34: Nameplate for BU1440 4T	87
Figure 35: Dimensions and fixing points of BU1440	90
Figure 36: External power connections for modular inverters S65-S70 provided with BU1440	92
Figure 37: External power connections for modular inverters S75-S80 provided with BU1440	93
Figure 38: ES841 Unit gate board for the braking unit	94
Figure 39: Connection points on ES842 for the braking unit optical fibres	95
Figure 40: Internal wiring of inverters S65-S70 provided with a braking unit	96
Figure 41: Overall dimensions, 350W resistor	104
Figure 42: Overall dimensions for 550W braking resistor	105
Figure 43: Overall dimensions for braking resistors from 1100W to 2200W	106
Figure 44: Overall dimensions for braking resistors 4kW, 8kW, 12kW	108
Figure 45: Overall dimensions of IP23 Box resistors	110
Figure 46: Position of electrical connections in box resistors	110
Figure 47: Typical nameplate for SINUS PENTA NEMA KIT accessory	119
Figure 48: Example of a NEMA 1 Kit installed on a SINUS PENTA	120
Figure 49: Wiring diagram for optional inductors	123
Figure 50: Amplitude of harmonic currents (approximate values)	125
Figure 51: Output inductor wiring	126
Figure 52: Mechanical features of a 3-phase inductor	131
Figure 53: Mechanical features of a DC inductor	133
Figure 54: Mechanical features of the 3-phase du/dt inductors	134
Figure 55: Mechanical features of three-phase inductors for Class 2T-4T in IP54 cabinet	137

Figure 56: Mechanical features of a 3-phase inductor for Class 5T-6T in IP54 cabinet 139

Figure 57: Mechanical features of a single-phase output inductor..... 140

Figure 58: Sine filter..... 141

Figure 59: Output toroidal filter 142

Figure 59: Encoder board (ES836/2)..... 143

Figure 60: Position of slot A for the installation of the encoder board 145

Figure 61: Encoder board fastened to its slot..... 145

Figure 62: Positions of DIP-switches and their factory-setting 146

Figure 63: LINE DRIVER or PUSH-PULL encoder with complementary outputs 149

Figure 64: PUSH-PULL encoder with single-ended outputs 150

Figure 65: PNP or NPN encoder with single-ended outputs and external load resistors..... 151

Figure 66: PNP or NPN encoder with single-ended outputs and internal load resistors..... 152

Figure 67: Wiring the encoder cable..... 153

Figure 68: ES913 Encoder board 154

Figure 69: Position of slot A for the installation of the encoder board 156

Figure 70: Encoder board fastened to its slot..... 156

Figure 71: Location of the configuration DIP-switches 157

Figure 72: Location of the jumpers selecting the encoder supply voltage 159

Figure 73: ES860 Sin/Cos Encoder board 161

Figure 74: Location of Slot A inside the drive terminal board covers 162

Figure 75: Fitting the ES860 board inside the drive 163

Figure 76: Pin layout on the high density connector 164

Figure 77: DIP-switch SW1 setting in three-channel mode..... 165

Figure 78: DIP-switch SW1 setting for five-channel mode..... 165

Figure 79: Position of the jumper and voltage adjusting trimmer 166

Figure 80: Recommended dual shielded connection for encoder cable 167

Figure 81: ES822 board..... 170

Figure 82: Position of the slot for the installation of the serial isolated board 172

Figure 83: Jumper setting RS232/RS485..... 173

Figure 84: Configuration of terminator DIP-switch for line RS485..... 173

Figure 85: Location of the slot B inside the terminal board cover of Santerno drives 176

Figure 86: Checking contacts in the slot B 177

Figure 87: Fastening the communications board to slot B 177

Figure 88: Position of the status LEDs on the B40 series board..... 181

Figure 89: Position of indicator LEDs on the board 182

Figure 90: PROFIBUS-DP® fieldbus communications board 185

Figure 91: Example of a Profibus network (the correct setting of the line terminators is highlighted) 186

Figure 92: Profibus® FC (FastConnect) connector with line termination settings 187

Figure 93: B40 series Fieldbus comms board with Ethernet interface 189

Figure 94: DeviceNET Fieldbus Comms Board..... 193

Figure 95: PROFIBUS-DP® fieldbus communications board 195

Figure 96: Example of a Profibus network (the correct setting of the line terminators is highlighted) 197

Figure 97: Example of the rotary-switch position to set Profibus address “19” 197

Figure 98: DeviceNet® Fieldbus communications board 199

Figure 99: Outline of the topology of a DeviceNet trunk line 201

Figure 100: CANopen® fieldbus communications board 202

Figure 101: Example of the position of the rotary-switches for 125kbits/s and Device Address 29..... 203

Figure 102: Ethernet Fieldbus Communications Board..... 205

Figure 103: Cable of Cat. 5 for Ethernet and standard colour arrangement in the connector 206

Figure 104: Windows 7 - Accessing directly to the network configuration folder 209

Figure 105: Setting a computer for a point-to-point connection to the inverter 210

Figure 106: Setting the DIP-switches to set the IP address 192.168.0.2..... 211

Figure 107: Internal webserver 212

Figure 108: Example of the ping command to the IP address of the inverter interface board 213

Figure 109: Anybus IP config utility 213

Figure 110: Setting ModScan for a Modbus/TCP connection 214

Figure 111: Display of the output variables of the inverter through the Modbus/TCP protocol..... 214

Figure 112: Position of the slot for ES919 board..... 218

Figure 113: ES919 Board for Metasys® N2 218

Figure 114: RS485 connector for Metasys® N2..... 219

Figure 115: ES919 Board for BACnet/Ethernet..... 220

Figure 116: BACnet LEDs	221
Figure 117: BACnet IP Configuration	223
Figure 118: ES919 Board for BACnet/RS485	224
Figure 119: RS485 connector for BACnet/RS485	224
Figure 120: BACnet MSTP Configuration.....	225
Figure 121: Bridge Mini Embedded	227
Figure 122: Bridge Mini Stand alone	227
Figure 123: Signal conditioning and additional I/Os board (ES847)	229
Figure 124: Removing the inverter cover; location of slot C.....	230
Figure 125: Fitting the strips inside ES847 board and fixing the board on slot C	230
Figure 126: Connection of a bipolar voltage source to a differential input	236
Figure 127: Connection of 0÷20mA (4÷20mA) sensors to “fast” current inputs	237
Figure 128: Connecting a voltage source to a “slow” analog input	237
Figure 129: Connecting thermoresistors PT100 to analog channels XAIN8–11 / T1–4	238
Figure 130: PNP input wiring	239
Figure 131: Connecting the incremental encoder to fast inputs XMDI7 and XMDI8.....	240
Figure 132: Signal sent from a 24V, Push-pull frequency output.....	240
Figure 133: XMDOx output connection as PNP for relay command with internal power supply	241
Figure 134: XMDOx output connection as PNP for relay command with external power supply	241
Figure 135: XMDOx output connection as NPN for relay command with internal power supply	242
Figure 136: XMDOx output connection as NPN for relay command with external power supply	242
Figure 137: Relay I/O expansion board ES870.....	247
Figure 138: Removing the inverter cover; location of slot C.....	248
Figure 139: ES988 option board, DIGITAL I/O 120/240 Vrms	251
Figure 140: Location of slot C inside the terminal board cover	252
Figure 141: Terminal strips inserted into SLOT C	253
Figure 142: Fastening ES988 option board inside the inverter	254
Figure 143: Input-output signal terminal blocks.....	255
Figure 144: Block diagram for ES988 interfacing.....	256
Figure 145: Utilization example of digital inputs on ES988 option board	257
Figure 146: ES861 Incremental Encoder and Resolver expansion board	262
Figure 147: Location of slot C inside the terminal board cover of the drives	263
Figure 148: Terminal strips inserted into SLOT C	264
Figure 149: Fitting the ES861 board inside the drive	264
Figure 150: Pin layout on the D-sub 9-pin female connector	265
Figure 151: Input-output signal terminal boards.....	266
Figure 152: Jumpers and trimmer for power supply configuration	267
Figure 153: Recommended dual shielded connection for resolver cable	269
Figure 154: ES950 encoder BiSS/EnDat board	273
Figure 155: Location of slot C inside the terminal board cover in the drives.....	275
Figure 156: Terminal strips inserted into SLOT C	276
Figure 157: Fitting the ES950 board inside the inverter	276
Figure 158: Pin layout on CN7 D-sub 15-pin female connector.....	277
Figure 159: Input-output signal terminal board.....	278
Figure 160: Block diagram for ES950 board interface	279
Figure 161: Jumpers and trimmer for power supply configuration	281
Figure 162: Recommended dual shielded connection for encoder cable	283
Figure 163: ES966 Hiperface Encoder Board	287
Figure 164: Location of slot C inside the terminal board cover of the drive	289
Figure 165: Inserting terminal strips to slot C	289
Figure 166: Fixing the ES966 board inside the drive	290
Figure 167: Pin layout on HD female D-sub 26 connector	291
Figure 168: Input-output signal terminals	292
Figure 169: Block diagram of ES966 interface board.....	293
Figure 170: Location of the jumpers, trimmers and DIP-switches of ES966.....	296
Figure 171: Connection method recommended for the double-shield encoder cable on ES966.....	298
Figure 172: ES914 Power supply unit board.....	301
Figure 173: Dimensions of ES914 board.....	301
Figure 174: Basic wiring diagram for ES914 board	302
Figure 175: Block-diagram with 3-zone insulation.....	303
Figure 176: Position of the LEDs and DIP-switches in ES914 board.....	307

Figure 177: Wiring diagram for IP54 inverters..... 310

Index of Tables

Table 1: Product – Power Supply Unit SU465 compatibility..... 16

Table 2: Product – Resistive braking compatibility 33

Table 3: Alarm ID and Type of fault on BU600 with the TYPE OF FAULT LED 64

Table 4: BU600 Power terminals..... 67

Table 5: Product – NEMA 1 GLANDKIT compatibility..... 119

Table 6: Product – Keypad remotng kit compatibility 122

Table 7: Product – Inductors compatibility..... 123

Table 8: Product – ES836/2 Encoder board compatibility..... 143

Table 9: Product – ES913 Encoder board compatibility..... 154

Table 10: Product – ES860 Encoder board compatibility..... 160

Table 11: Product – ES822 Optoisolated serial board compatibility 170

Table 12: Product – Fieldbus board compatibility 174

Table 13: Product – ES919 Communications board compatibility 216

Table 14: Product – Bridge Mini compatibility 226

Table 15: Product - ES847 I/O Expansion board compatibility 228

Table 16: Product – ES870 I/O Expansion board compatibility 247

Table 17: Product – ES988 I/O Expansion board compatibility 251

Table 18: Product – ES861 Resolver and incremental encoder board compatibility 261

Table 19: Product – ES950 BISS/EnDat Encoder board compatibility 272

Table 20: Product – ES966 Hiperface Encoder board compatibility 286

Table 21: Configuration of incremental encoder power supply 295

Table 22: Configuration of Hiperface encoder power supply 295

Table 23: DIP-switch configuration for the temperature sensor on ES966 297

Table 24: Configuration of jumper J7 298

Table 25: Product – ES914 Power Supply Unit board compatibility 301

Table 26: Product – Key selector switch and Emergency push-button for IP54 models compatibility 308

1. OVERVIEW

This manual covers the specifications and installation instructions for the option boards and external accessories available for the following products manufactured by Santerno:

- Sinus Penta
- Penta Marine
- Iris Blue
- Solardrive Plus

The accessory-product compatibility is stated in the Compatibility Table at the beginning of each section in this manual.

2. POWER SUPPLY UNIT FOR DRIVES S41..S52 (SU465)

Product-Accessory Compatibility		
Product	Power Supply Unit SU465	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	-	
Solardrive Plus	-	

Table 1: Product – Power Supply Unit SU465 compatibility

The power supply for the S41..S52 drives (see the 12-pulse Connection for Modular Inverters in the Installation Guide) requires the SU465.

The SU465 must be installed next to the inverter and is to be connected as described below.

Instructions on how to transport, handle and unpack the product, please refer to the general instructions given in the Transport and Handling and Unpacking in the Installation Guide.

The SU465 may be utilized as a 12-pulse rectifier for the following drive sizes:

1. S41
2. S42
3. S51
4. S52

Alternatively, it may be used as a standard rectifier.

The voltage input must range from 200Vac to 690Vac; the maximum allowable current for the SU465 is 465A.

An 18-pulse connection may be obtained by using N.2 supply units SU465.

The supply unit may also be used as a stand-alone supply unit. Please refer to the specific manual AC/DC Units.

The SU465 is an Open Type device featuring IP00 degree of protection suitable for installation inside a cabinet featuring at least IP3X degree of protection.

2.1. Delivery Check

Make sure that the equipment is not damaged and that it complies with the equipment you ordered by referring to the nameplate located on the inverter front part. The inverter nameplate is described below. If the equipment is damaged, contact the supplier or the insurance company concerned. If the equipment does not comply with the one you ordered, please contact the supplier as soon as possible.

If the equipment is stored before being started, make sure that the ambient conditions do not exceed the acceptable ratings (temperature: -25°C to $+70^{\circ}\text{C}$; relative humidity $<95\%$, no condensation). The equipment guarantee covers any manufacturing defect. The manufacturer has no responsibility for possible damages occurred when shipping or unpacking the inverter. The manufacturer is not responsible for possible damages or faults caused by improper and irrational uses; wrong installation; improper conditions of temperature, humidity, or the use of corrosive substances. The manufacturer is not responsible for possible faults due to the inverter operation at values exceeding the inverter ratings and is not responsible for consequential and accidental damages. The equipment is covered by 2-year guarantee starting from the date of delivery.

2.2. Installing and Operating the SU465

Please refer to the general instructions given in section Installing and Operating the Equipment in the Installation Guide.

2.3. SU465 Nameplate




Figure 1: Nameplate for SU465

- | | |
|--------------------------|-----------------------------|
| 1. Model: | SU465 |
| 2. Input voltage: | 200-690 Vac |
| 3. Input frequency: | 50-60 Hz |
| 4. Input current: | 380 A nominal current |
| 5. Output voltage: | 282-975 Vdc |
| 6. Output current: | 465 A nominal 580 A maximum |
| 7. Nominal power: | 453 kVA |
| 8. Degree of protection: | IP00 \ IP21 |

2.4. SU465 Operating Mode

The SU465 may operate as follows:

- In parallel to a 12-pulse converter (this solution reduces the harmonic contents to the power supply mains):




Figure 2: The SU465 in 12-pulse configuration

- As a supply unit for a conversion unit:




Figure 3: The SU465 as a supply unit of a conversion unit

2.4.1. SU465 Operation as a 12-pulse Supply Unit

The 12-pulse supply unit is controlled directly by the drive. When operating as an additional rectifier bridge for the 12-pulse connection, the following diagnostics functions are performed by the driver board of the drive:

- Phase detection and measurement
- Heatsink overtemperature measurement and alarm
- Precharge control

2.5. System Requirements

As the input current is automatically controlled, the system must meet the following requirements:

- Provide the drive and the supply unit with line inductors as detailed in section Inductors to be Applied to the Drive and the SU465.
- The three-phase transformer must be:
 - Symmetrical
 - With Dy11d0 or Dy5d0 vector unit
 - The secondary output voltages must range:
 - Within 5% of relative variation at full load
 - Within 0.5% under no-load conditions
 - The short-circuit current must be $V_{sc} > 4\%$
- Wiring to the transformer, the supply unit and the drive shall be as close as possible in terms of cable length and cable cross-section.

2.6. Technical Specifications

Electrical specifications:

Overvoltage category III (according to EN 61800-5-1)

MODEL	Rated input current (A)	Supply voltage	Rated output current (A)	Maximum output current (A)	Output voltage	Dissipated power (at rated current) (W)
SU465	380	200-690Vac	465	580	0-975Vdc	1160

Mechanical specifications:

MODEL	Degree of protection	Sound pressure (dB)
SU465	IP00(*)	57

(*) NEMA1 when using the special optional kit

2.7. Installing the SU465

2.7.1. Environmental Requirements for the SU465 Installation, Storage and Transport

Maximum surrounding air temperature	-10 to +40°C with no derating from +40°C to +55°C with 2% derating of the rated current for each degree beyond +40°C
Ambient temperatures for storage and transport	-25°C to +70°C.
Installation environment	Pollution degree 2 or better (according to EN 61800-5-1). Do not install in direct sunlight and in places exposed to conductive dust, corrosive gases, vibrations, water sprinkling or dripping (depending on IP ratings); do not install in salty environments.
Altitude	Max. altitude for installation 2000 m a.s.l. For installation above 2000 m and up to 4000 m, please contact Enertronica Santerno S.p.A.. Above 1000 m, derate the rated current by 1% every 100 m.
Operating ambient humidity	From 5% to 95%, from 1g/m ³ to 29g/m ³ , non-condensing and non-freezing (class 3K3 according to EN 61800-5-1).
Storage ambient humidity	From 5% to 95%, from 1g/m ³ to 29g/m ³ , non-condensing and non-freezing (class 1K3 according to EN 61800-5-1).
Ambient humidity during transport	Max. 95%, up to 60g/m ³ ; condensation may appear when the equipment is not running (class 2K3 according to EN 61800-5-1).
Storage and operating atmospheric pressure	From 86 to 106 kPa (classes 3K3 and 1K4 according to EN 61800-5-1).
Atmospheric pressure during transport	From 70 to 106 kPa (class 2K3 according to EN 61800-5-1).



CAUTION

Ambient conditions strongly affect the inverter life. Do not install the equipment in places that do not have the above-mentioned ambient conditions.

2.7.2. Mounting the SU465

The SU465 must be installed on the left of the drive in upright position inside a cabinet. The mechanical dimensions and fixing points are given in the figures below.

If the braking unit or an additional supply unit is installed, those units may be installed side by side.

The minimum allowable side clearance is 150mm and 100mm top and bottom.

Dimensions (mm)			Fixing point distance (mm)				Type of screws	Weight (kg)
W	H	D	X	Y	D1	D2	M8-M10	36.6
257	550	398.5	170	515	12	6		





Figure 4: Dimensions and fixing points for the SU465

2.7.3. IP21 Kit

The SU465 may be provided with a special safety kit against top-down water dripping to get IP21 degree of protection. Consequently, the side dimensions become 30mm.



S000615


Figure 5: Overall dimensions when using IP21 kit

2.7.4. Through-panel Kit

The supply unit may be provided with the special through-panel kit for the segregation of the air flows.

Dimensions (mm)			Fixing point distance (mm)				Type of screws	Weight (kg)
W	H	D	X	Y	X1	Y1		
325	683	398.5	250	650	293	400	M8-M10	2

Part Number
ZZ0119280




S000616

Figure 6: Dimensions and fixing points when using the through-panel kit for the SU465

2.7.5. NEMA1 Kit

The SU465 may be provided with the special NEMA1 kit against accidental contacts. This optional kit is to be installed directly on the supply unit case and provides protection against accidental contacts with the power terminals in the supply unit.



S000617


Figure 7: NEMA1 kit and kit installation on the SU465

Part Number
ZZ0119270

The NEMA1 kit is provided with N.3 removable plates that may be drilled to suit the installer's needs in terms of cable paths to the mains and the unit to be power supplied.

The installer is responsible for the utilization of safe materials able to preserve the equipment's degree of protection. It is recommended that the cables do not enter into contact with sharp metal parts that may jeopardize isolation.

Kit dimensions (mm)			SU465 length + NEMA1 kit	Type of screws for mounting	Weight (kg)
W	H	D	H	M8	3.4
187	298	248	765		



S000618

Figure 8: Overall dimensions when installing the NEMA1 kit


2.7.6. Power Terminals and Signal Terminals Layout

Power Wiring

The SU465 is to be connected to the drive as follows:

Decisive voltage class C according to EN 61800-5-1

Terminal	Type	Tightening Torque (Nm)	Connection cable cross-section mm ² (AWG/kcmils)	NOTES
R	Bar	30	240mm ² (500kcmils)	To be connected to phase R of the transformer
S	Bar	30	240mm ² (500kcmils)	To be connected to phase S of the transformer
T	Bar	30	240mm ² (500kcmils)	To be connected to phase T of the transformer
+	Bar	30	240mm ² (500kcmils)	To be connected to terminal 47/+ of the drive
-	Bar	30	240mm ² (500kcmils)	To be connected to terminal 49/- of the drive



S000619

Figure 9: Power terminals



CAUTION

When the SU465 is used as a 12-pulse rectifier, bars **47/D** and **47/+** in drives S41-42-51-52 are to be short-circuited.




CAUTION

When the SU465 is used as a supply unit, bars **47/D** and **47/+** in the drive are to be disconnected by removing the default bridge.



DANGER

DUAL POWER SUPPLY: The SU465 may be both AC supplied (input) and DC supplied (output) thanks to the parallel connection to the drive. Disconnect both sources (input AC power supply and parallel connection to the drive) before operating on the equipment.



S000625



DANGER

Once both AC power supply and DC power supply have been isolated, wait at least 20 minutes before operating on the DC-links to give the capacitors time to discharge.

2.7.7. Signal Connections

Each supply unit is provided with two DB9 connectors for the connection of the control signals. By way of connector CN1, located on the left side if seen frontally (see Figure 11), the device receives the control signals from the drive to be power supplied. Connector CN2 features a similar signal set for the cascade connection of an additional supply unit.

Connector CN1 – Connect terminal board M1 to the drive via a shielded DB9 cable, AWG26, provided with male DB9 terminal on the drive side and female DB9 terminal on the SU465.

Decisive voltage class A according to EN 61800-5-1

N.	Name	Description	I/Os	NOTES
1	12PHU	12-ph UNIT FITTED	0-24V	+24V available 0V n/available
2	PREC_M	Thyristor firing precharge (master)	0-24V	+24V firing failed; 0V: firing successful
3	Vrs	Vrs phase readout	±5V analog	Vrs/200 for 2T-4T Vrs/250 for 5T-6T
4	Vst	Vst phase readout	±5V analog	Vrs/200 for 2T-4T Vrs/250 for 5T-6T
5	VBOK	ON/OFF command for thyristor firing	0-24V	+24V for thyristor firing
6	+24V	24Vdc power supply	20W (in common with the drive 24V power supply)	
7	0V	0V	Control board zero volt	
8	PT_M	Thermoswitch (master)	0-24V	+24V thermoswitch open; 0V: thermoswitch OK
9	NTC_M	NTC readout (master)		NTC 10k polarized at 5V with 6k81

Connector CN2 – If required, connect terminal board M2 to the additional shielded DB9 connector, at least AWG26, with a male DB9 connector on the first SU465 and a DB9 female on the second SU465.

Decisive voltage class A according to EN 61800-5-1

N.	Name	Description	I/Os	NOTES
1	18PHU	18-ph UNIT FITTED	0-24V	+24V available 0V n/available
2	PREC_S	Thyristor firing precharge (slave)	0-24V	+24V firing failed; 0V: firing successful
3	-			Not connected
4	-			Not connected
5	VBOK	ON/OFF command for thyristor firing	0-24V	+24V for thyristor firing
6	+24V	24Vdc power supply	ON/OFF command for thyristor firing	
7	0V	0V	24Vdc power supply	
8	PT_S	Thermoswitch (slave)	0-24V	+24V thermoswitch open; 0V: thermoswitch OK
9	NTC_S	NTC readout (slave)		NTC 10k polarized at 5V with 6k81

In the event of a 18-pulse or more connection, an external 24V supply unit connected to pins 6 and 7 is required. 20W power is required for each additional unit.

The connection in parallel of more than one supply unit requires configuring the ES840/1 control board by changing the default settings of special-purpose jumpers. Those settings are given in the table below, based on the position of the supply unit in the device chain (first position, intermediate position, end position).

	SU465 in first position	SU465 in intermediate position	SU465 in end position
J1	ON	ON	ON
J2	ON	ON	ON
J3	OFF	OFF	ON
J4	OFF	OFF	ON
J5	ON	OFF	OFF
J6	ON	OFF	OFF




Figure 10: Position of the jumpers in the ES840/1 board

The configuration of jumpers J7-J8 depends on the operating voltage of the SU465.

	2T-4T	5T-6T
J7	1-2	2-3
J8	1-2	2-3





Figure 11: Signal terminal board



S000622

Figure 12: Example of a 9-pin shielded cable for signal connection

2.7.8. Wiring the SU465



SU000623

Figure 13: S41–S52 connections with 12- and 18-pulse SU465

2.8. Cross-sections of the Power Cables and Sizes of the Protective Devices when the SU465 is Installed

The minimum requirements of the inverter cables and the protective devices needed to protect the system against short-circuits are given in the tables below. It is however recommended that the applicable regulations in force be observed; also check if voltage drops occur for cable links longer than 100m.

For the largest inverter sizes, special links with multiple conductors are provided for each phase. For example, 2x150 in the column relating to the cable cross-section means that two 150mm² parallel conductors are required for each phase.

Multiple conductors shall have the same length and must run parallel to each other, thus ensuring even current delivery at any frequency value. Paths having the same length but a different shape deliver uneven current at high frequency.

Also, do not exceed the tightening torque for the terminals to the bar connections. For connections to bars, the tightening torque relates to the bolt tightening the cable lug to the copper bar. The cross-section values given in the tables below apply to copper cables.

The links between the motor and the drive must have the same lengths and must follow the same paths. Use 3-phase cables where possible.

Dimensioning depends on the configuration of the SU465 (12-pulse connection or power supply unit – rectifier).

Voltage Class	Size	Drive Model	Rated Inverter Current	Tightening Torque	Cable Cross-section to Mains and Motor Side	Fast Fuses (700V) + Disc. Switch	Magnetic Circuit Breaker	AC1 Contactor
			A	Nm	mm ² (AWG/kcmils)	A	A	A
2T-4T	S41	0180	150	10	95 (4/0AWG)	200	160	160
		0202	175	10	95 (4/0AWG)	250	200	250
		0217	190	10	120 (250kcmils)	250	250	250
		0260	225	10	120 (250kcmils)	315	400	275
2T-4T	S51	0313	240	10	120 (250kcmils)	400	400	275
		0367	275	25-30	150 (300kcmils)	400	400	400
		0402	340	25-30	240 (500kcmils)	500	400	450
5T-6T	S42	0181	155	30	95 (4/0AWG)	200	200	250
		0201	165	30	95 (4/0AWG)	200	200	250
		0218	180	30	120 (250kcmils)	250	250	250
		0259	200	30	120 (250kcmils)	250	250	250
5T-6T	S52	0290	225	30	150 (300kcmils)	315	400	275
		0314	250	30	185 (400kcmils)	400	400	400
		0368	280	30	240 (500kcmils)	400	400	400
		0401	320	30	240 (500kcmils)	450	400	450



NOTE

[*] These rated current values apply to the 12-pulse configuration only; configurations other than the 12-pulse configuration have different rated current values.

2.9. Earth Bonding of the SU465

For the earth bonding of the SU465 and the transformer for the 12-pulse application, please refer to the general instructions given in section Inverter and Motor Ground Connection in the Installation Guide.

2.10. Scheduled Maintenance of the SU465

For the SU465 scheduled maintenance, please refer to the general instructions given in section Inverter Scheduled Maintenance in the Installation Guide.

2.11. Inductors to be Applied to the Drive and the SU465 – 12-pulse Connection

Voltage Class	Drive Size	Drive Model	INPUT THREE-PHASE AC INDUCTOR
2T-4T	S41	0180	IM0126244 0.09mH–252Arms
		0202	
		0217	
		0260	
2T-4T	S51	0313	IM0126282 0.063mH–360Arms
		0367	
		0402	
5T-6T	S42	0181	IM0127274 0.12mH–325Arms
		0201	
		0218	
		0259	
5T-6T	S52	0290	IM0127330 0.096mH–415Arms
		0314	
		0368	
		0401	

2.12. Inductors to be Applied to the Drive and the SU465 – 18-pulse connection

Voltage Class	Drive Size	Drive Model	INPUT THREE-PHASE AC INDUCTOR
2T-4T	S41	0180	IM0126204
		0202	0.16mH–145Arms
		0217	IM0126244
		0260	
2T-4T	S51	0313	0.09mH–252Arms
		0367	
		0402	
5T-6T	S42	0181	IM0127202
		0201	0.29mH–140Arms
		0218	IM0127227
0259	0.19mH–210Arms		
5T-6T	S52	0290	IM0127274
		0314	
		0368	0.12mH–325Arms
		0401	

3. RESISTIVE BRAKING

Product-Accessory Compatibility		
Product	Power Supply Unit SU465	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	-	
Solardrive Plus	-	

Table 2: Product – Resistive braking compatibility

When a large braking torque is required or the load connected to the motor is pulled (as for instance in lifting applications), the power regenerated by the motor is to be dissipated. This can be obtained in two ways:

- by dissipating energy to braking resistors (in that case a braking module is required); or
- by powering the inverter via the DC-bus using a system able to deliver energy to the mains. Both solutions are available.

Both solutions are available: The first solution is described below; for the second solution, please refer to the technical documentation pertaining to the Regenerative Inverter (see the Guide to the Regenerative Application).

From size S05 to size S32, the products are supplied with a built-in braking module. The braking resistor is to be connected outside the inverter to terminal B and terminal + (see Power Terminals for S05-S52 in the Installation Guide); properly set the parameters relating to the inverter braking (see the product’s Programming Guide). External braking units are used for greater sizes; please refer to the relevant sections in this manual also for the description of the suitable braking resistors.

When choosing the braking resistor, consider the following:

- drive supply voltage (voltage class),
- the braking resistor Ohm value
- the rated power of the resistor.

The voltage class and the Ohm value determine the instant power dissipated in the braking resistor and are relating to the motor power (see note below); the rated power determines the mean power to be dissipated in the braking resistor and is relating to the duty cycle of the equipment, i.e. to the resistor activation time in respect to the duty cycle full time (the duty cycle of the resistor is equal to the motor braking time divided by the equipment duty cycle).

It is not possible to connect resistors with a Ohm value lower than the min. value acknowledged by the inverter.



NOTE

The braking power required to reduce the speed of a rotating body is proportional to the total moment of inertia of the rotating mass, to the speed variation, to the absolute speed and is inversely proportional to the deceleration time required.

The following pages contain application tables stating the resistors to be used depending on the inverter model, the application requirements and the supply voltage.



NOTE

The braking resistor power is given as an approximate empirical value; the correct dimensioning of the braking resistor is based on the equipment duty cycle and the power regenerated during the braking stage.

3.1 Braking Resistors to be Supplied to the Drives Equipped with Internal Braking Unit



NOTE

The wire cross-sections given in the table relate to one wire per braking resistor.



NOTE

The Part Numbers of the braking resistors in the tables are given in the Available Braking Resistors section.



**HOT
SURFACE**

The braking resistor case may reach 200°C based on the operating cycle.



CAUTION

The cables of the braking resistors shall have insulation features and heat-resistance features suitable for the application. The minimum rated voltage of the cables must be 450/700 V for inverters 2T, 0.6/1kV for inverters 4T/5T/6T.



CAUTION

The power dissipated by the braking resistors may be the same as the rated power of the connected motor multiplied by the braking duty-cycle; use a proper air-cooling system. Do not install braking resistors near heat-sensitive equipment or objects.



CAUTION

Do not connect to the inverter any braking resistor with an Ohm value lower than the value given in the tables.



CAUTION

Never exceed the maximum operating time of the resistor as given in the Available Braking Resistors section.

3.1.1. Applications with DUTY CYCLE 10% - Class 2T

Size	Model	BRAKING RESISTORS					
		Min. Applicable Resistor (Ω)	Type	Degree of Protection	Type of Connection	Value (Ω)	Wire cross-section mm2 (AWG)
S05	0007	25.0	56Ω-350W	IP55	A	56	2.5(14)
	0008	25.0	2*56Ω-350W	IP55	B	28	2.5(14)
	0010	25.0	2*56Ω-350W	IP55	B	28	2.5(14)
	0013	18.0	2*56Ω-350W	IP55	B	28	2.5(14)
	0015	18.0	2*56Ω-350W	IP55	B	28	2.5(14)
	0016	18.0	3*56Ω-350W	IP55	B	18.7	2.5(14)
	0020	18.0	3*56Ω-350W	IP55	B	18.7	2.5(14)
S12	0023	15.0	15Ω-1100W	IP55	A	15	4(12)
	0033	10.0	10Ω-1500W	IP54	A	10	4(12)
	0037	10.0	10Ω-1500W	IP54	A	10	4(12)
S15	0040	7.5	2*15Ω-1100W	IP55	A	7.5	4(12)
	0049	5.0	5Ω-4000W	IP20	A	5.0	10(8)
S20	0060	5.0	5Ω-4000W	IP20	A	5.0	10(8)
	0067	5.0	5Ω-4000W	IP20	A	5.0	10(8)
	0074	4.2	5Ω-4000W	IP20	A	5.0	10(8)
	0086	4.2	5Ω-4000W	IP20	A	5.0	10(8)
S30	0113	3.0	3.3Ω-8000W	IP20	A	3.3	10(8)
	0129	3.0	3.3Ω-8000W	IP20	A	3.3	10(8)
	0150	2.5	3.3Ω-8000W	IP20	A	3.3	10(8)
	0162	2.5	3.3Ω-8000W	IP20	A	3.3	10(8)

3.1.2. Applications with DUTY CYCLE 20% - Class 2T

Size	Model	BRAKING RESISTORS					
		Min. Applicable Resistor (Ω)	Type	Degree of Protection	Type of Connection	Value (Ω)	Wire cross-section mm ² (AWG)
S05	0007	25.0	2*100Ω-350W	IP55	B	50	2.5(14)
	0008	25.0	2*56Ω-350W	IP55	B	28	2.5(14)
	0010	25.0	2*56Ω-350W	IP55	B	28	2.5(14)
	0013	18.0	4*100Ω-350W	IP55	B	25	2.5(14)
	0015	18.0	4*100Ω-350W	IP55	B	25	2.5(14)
	0016	18.0	25Ω-1800W	IP54	A	25	2.5(14)
	0020	18.0	25Ω-1800W	IP54	A	25	2.5(14)
S12	0023	15.0	15Ω-2200W	IP54	A	15	4(12)
	0033	10.0	2*25Ω-1800W	IP54	B	12.5	2.5(14)
	0037	10.0	2*25Ω-1800W	IP54	B	12.5	2.5(14)
S15	0040	7.5	2*15Ω-2200W	IP54	B	7.5	2.5(14)
	0049	5	5Ω-4000W	IP20	A	5	6(10)
S20	0060	5.0	5Ω-8000W	IP20	A	5	10(8)
	0067	5.0	5Ω-8000W	IP20	A	5	10(8)
	0074	4.2	5Ω-8000W	IP20	A	5	10(8)
	0086	4.2	5Ω-8000W	IP20	A	5	10(8)
S30	0113	3.0	3.3Ω-12000W	IP20	A	3.3	16(6)
	0129	3.0	3.3Ω-12000W	IP20	A	3.3	16(6)
	0150	2.5	3.3Ω-12000W	IP20	A	3.3	16(6)
	0162	2.5	3.3Ω-12000W	IP20	A	3.3	16(6)

3.1.3. Applications with DUTY CYCLE 50% - Class 2T

Size	Model	BRAKING RESISTORS					
		Min. Applicable Resistor (Ω)	Type	Degree of Protection	Type of Connection	Value (Ω)	Wire cross-section mm ² (AWG)
S05	0007	25.0	50Ω-1100W	IP55	A	50	2.5(14)
	0008	25.0	25Ω-1800W	IP54	A	25	2.5(14)
	0010	25.0	25Ω-1800W	IP54	A	25	2.5(14)
	0013	18.0	25Ω-4000W	IP20	A	25	2.5(14)
	0015	18.0	25Ω-4000W	IP20	A	25	2.5(14)
	0016	18.0	25Ω-4000W	IP20	A	25	2.5(14)
	0020	18.0	20Ω-4000W	IP20	A	20	4(12)
S12	0023	15.0	20Ω-4000W	IP20	A	20	6(10)
	0033	10.0	10Ω-8000W	IP20	A	10	10(8)
	0037	10.0	10Ω-8000W	IP20	A	10	10(8)
S15	0040	6.6	6.6Ω-12000W	IP20	A	6.6	16(6)
	0049	6.6	6.6Ω-12000W	IP20	A	6.6	16(6)
S20	0060	5.0	6.6Ω-12000W	IP20	A	6.6	16(6)
	0067	5.0	2*10Ω-8000W	IP20	B	5	10(8)
	0074	4.2	2*10Ω-8000W	IP20	B	5	10(8)
	0086	4.2	2*10Ω-8000W	IP20	B	5	10(8)
S30	0113	3.0	2*6.6Ω-12000W	IP20	B	3.3	16(6)
	0129	3.0	2*6.6Ω-12000W	IP20	B	3.3	16(6)
	0150	2.5	3*10Ω-12000W	IP20	B	3.3	10(8)
	0162	2.5	3*10Ω-12000W	IP20	B	3.3	10(8)

Type of connection:

A - One resistor

B - Two or multiple parallel-connected resistors



CAUTION

The cable cross-sections given in the table relate to the cable connecting each individual braking resistor. For example, if a braking resistor is connected to N.2 parallel-connected resistors, the cable cross-section in the table is the one for each resistor connected to the braking unit.

3.1.4. Applications with DUTY CYCLE 10% - Class 4T

Size	Model	BRAKING RESISTORS					
		Min. Applicable Resistor (Ω)	Type	Degree of Protection	Type of Connection	Value (Ω)	Wire cross-section mm^2 (AWG)
S05	0005	50	75 Ω -550W	IP33	A	75	2.5(14)
	0007	50	75 Ω -550W	IP33	A	75	2.5(14)
	0009	50	50 Ω -1100W	IP55	A	50	2.5(14)
	0011	50	50 Ω -1100W	IP55	A	50	2.5(14)
	0014	50	50 Ω -1100W	IP55	A	50	2.5(14)
S12	0016	40	50 Ω -1500W	IP54	A	50	2.5(14)
	0017	40	50 Ω -1500W	IP54	A	50	2.5(14)
	0020	40	50 Ω -1500W	IP54	A	50	2.5(14)
	0025	20	25 Ω -1800W	IP54	A	25	4(12)
	0030	20	25 Ω -1800W	IP54	A	25	4(12)
	0034	20	20 Ω -4000W	IP20	A	20	4(12)
	0036	20	20 Ω -4000W	IP20	A	20	4(12)
S15	0040	15	15 Ω -4000W	IP20	A	15	6(10)
	0049	10	15 Ω -4000W	IP20	A	15	6(10)
S20	0060	10	10 Ω -8000W	IP20	A	10	10(8)
	0067	10	10 Ω -8000W	IP20	A	10	10(8)
	0074	7.5	10 Ω -8000W	IP20	A	10	10(8)
	0086	7.5	10 Ω -8000W	IP20	A	10	10(8)
S30	0113	6	6.6 Ω -12000W	IP20	A	6.6	10(8)
	0129	6	6.6 Ω -12000W	IP20	A	6.6	10(8)
	0150	5	5 Ω -16000W	IP20	A	5	16(6)
	0162	5	5 Ω -16000W	IP20	A	5	16(6)

Type of connection:

A - One resistor

3.1.5. Applications with DUTY CYCLE 20% - Class 4T

Size	Model	BRAKING RESISTORS					
		Min. Applicable Resistor (Ω)	Type	Degree of Protection	Type of Connection	Value (Ω)	Wire cross-section mm^2 (AWG)
S05	0005	50	50 Ω -1100W	IP55	A	50	2.5(14)
	0007	50	50 Ω -1100W	IP55	A	50	2.5(14)
	0009	50	50 Ω -1100W	IP55	A	50	2.5(14)
	0011	50	50 Ω -1500W	IP54	A	50	2.5(14)
	0014	50	50 Ω -1500W	IP54	A	50	2.5(14)
S12	0016	40	50 Ω -2200W	IP54	A	50	2.5(14)
	0017	40	50 Ω -2200W	IP54	A	50	2.5(14)
	0020	40	50 Ω -4000W	IP20	A	50	2.5(14)
	0025	20	25 Ω -4000W	IP20	A	25	6(10)
	0030	20	25 Ω -4000W	IP20	A	25	6(10)
	0034	20	20 Ω -4000W	IP20	A	20	6(10)
	0036	20	20 Ω -4000W	IP20	A	20	6(10)
S15	0040	15	15 Ω -8000W	IP23	A	15	10(8)
	0049	10	10 Ω -12000W	IP20	A	10	10(8)
S20	0060	10	10 Ω -12000W	IP20	A	10	16(6)
	0067	10	10 Ω -12000W	IP20	A	10	16(6)
	0074	7.5	10 Ω -16000W	IP23	A	10	16(6)
	0086	7.5	10 Ω -16000W	IP23	A	10	16(6)
S30	0113	6	2*3.3 Ω -8000W	IP20	C	6.6	16(6)
	0129	6	2*3.3 Ω -8000W	IP20	C	6.6	16(6)
	0150	5	2*10 Ω -12000W	IP20	B	5	16(6)
	0162	5	2*10 Ω -12000W	IP20	B	5	16(6)

Type of connection:

- A** - One resistor
- B** - Two or multiple parallel-connected resistors
- C** - Two series-connected resistors

3.1.6. Applications with DUTY CYCLE 50% - Class 4T

Size	Model	BRAKING RESISTORS					
		Min. Applicable Resistor (Ω)	Type	Degree of Protection	Type of Connection	Value (Ω)	Wire cross-section mm^2 (AWG)
S05	0005	50	50 Ω -4000W	IP23	A	50	4(12)
	0007	50	50 Ω -4000W	IP23	A	50	4(12)
	0009	50	50 Ω -4000W	IP23	A	50	4(12)
	0011	50	50 Ω -4000W	IP23	A	50	4(12)
	0014	50	50 Ω -4000W	IP23	A	50	4(12)
S12	0016	40	50 Ω -8000W	IP23	A	50	4(12)
	0017	40	50 Ω -8000W	IP23	A	50	4(12)
	0020	40	50 Ω -8000W	IP23	A	50	4(12)
	0025	20	20 Ω -12000W	IP23	A	20	10(8)
	0030	20	20 Ω -12000W	IP23	A	20	10(8)
	0034	20	20 Ω -16000W	IP23	A	20	10(8)
	0036	20	20 Ω -16000W	IP23	A	20	10(8)
S15	0040	15	15 Ω -24000W	IP23	A	15	16(6)
	0049	10	15 Ω -24000W	IP23	A	15	16(6)
S20	0060	10	10 Ω -24000W	IP23	A	10	16(6)
	0067	10	10 Ω -24000W	IP23	A	10	16(6)
	0074	7.5	2*15 Ω -24000W	IP23	B	7.5	16(6)
	0086	7.5	2*15 Ω -24000W	IP23	B	7.5	16(6)
S30	0113	6	6 Ω -64000W	IP23	A	6	35(2)
	0129	6	6 Ω -64000W	IP23	A	6	35(2)
	0150	5	5 Ω -64000W	IP23	A	5	50(1/0)
	0162	5	5 Ω -64000W	IP23	A	5	50(1/0)

Type of connection:

A - One resistor

B - Two or multiple parallel-connected resistors

3.1.7. Applications with DUTY CYCLE 10% - Class 5T

Size	Model	BRAKING RESISTOR					
		Min. Applicable Resistor (Ω)	Type	Degree of Protection	Type of Connection	Value (Ω)	Wire cross-section mm^2 (AWG)
S14	0003	120	250 Ω -1100W	IP55	A	250	10(8)
	0004	120	180 Ω -1100W	IP55	A	180	10(8)
	0006	60	120 Ω -1800W	IP55	A	120	10(8)
	0012	60	100 Ω -2200W	IP55	A	100	10(8)
	0018	60	82 Ω -4000W	IP20	A	82	10(8)
	0019	40	60 Ω -4000W	IP20	A	60	10(8)
	0021	40	45 Ω -4000W	IP23	A	45	10(8)
	0022	25	45 Ω -4000W	IP23	A	45	10(8)
	0024	25	30 Ω -4000W	IP23	A	30	10(8)
S22	0032	20	22 Ω -8000W	IP23	A	22	10(8)
	0042	12	22 Ω -8000W	IP23	A	22	10(8)
	0051	12	18 Ω -8000W	IP23	A	18	10(8)
	0062	12	15 Ω -12000W	IP23	A	15	10(8)
S32	0069	12	12 Ω -12000W	IP23	A	12	10(8)
	0076	8	10 Ω -12000W	IP23	A	10	16(6)
	0088	8	8.2 Ω -16000W	IP23	A	8.2	16(6)
	0131	5	6.6 Ω -24000W	IP23	A	6.6	16(6)
	0164	5	5 Ω -24000W	IP23	A	5	16(6)

Type of connection:

A - One resistor

3.1.8. Applications with DUTY CYCLE 20% - Class 5T

Size	Model	BRAKING RESISTOR					
		Min. Applicable Resistor (Ω)	Type	Degree of Protection	Type of Connection	Value (Ω)	Wire cross-section mm^2 (AWG)
S14	0003	120	250 Ω -1500W	IP55	A	250	10(8)
	0004	120	180 Ω -1500W	IP55	A	180	10(8)
	0006	60	120 Ω -4000W	IP20	A	120	10(8)
	0012	60	100 Ω -4000W	IP20	A	100	10(8)
	0018	60	82 Ω -4000W	IP23	A	82	10(8)
	0019	40	60 Ω -4000W	IP23	A	60	10(8)
	0021	40	45 Ω -8000W	IP20	A	45	10(8)
	0022	25	45 Ω -8000W	IP23	A	45	10(8)
	0024	25	30 Ω -8000W	IP23	A	30	10(8)
S22	0032	20	22 Ω -12000W	IP23	A	22	10(8)
	0042	12	22 Ω -12000W	IP23	A	22	10(8)
	0051	12	18 Ω -12000W	IP23	A	18	10(8)
	0062	12	15 Ω -16000W	IP23	A	15	10(8)
S32	0069	12	12 Ω -16000W	IP23	A	12	10(8)
	0076	8	10 Ω -24000W	IP23	A	10	16(6)
	0088	8	8.2 Ω -24000W	IP23	A	8.2	16(6)
	0131	5	6.6 Ω -32000W	IP23	A	6.6	25(3)
	0164	5	5 Ω -48000W	IP23	A	5	25(3)

Type of connection:

A - One resistor

3.1.9. Applications with DUTY CYCLE 50% - Class 5T

Size	Model	BRAKING RESISTOR					
		Min. Applicable Resistor (Ω)	Type	Degree of Protection	Type of Connection	Value (Ω)	Wire cross-section mm^2 (AWG)
S14	0003	120	250 Ω -2200W	IP55	A	250	16(6)
	0004	120	180 Ω -4000W	IP20	A	180	16(6)
	0006	60	120 Ω -4000W	IP23	A	120	16(6)
	0012	60	100 Ω -4000W	IP23	A	100	16(6)
	0018	60	82 Ω -8000W	IP20	A	82	16(6)
	0019	40	60 Ω -8000W	IP23	A	60	16(6)
	0021	40	45 Ω -12000W	IP20	A	45	16(6)
	0022	25	45 Ω -12000W	IP23	A	45	16(6)
	0024	25	30 Ω -16000W	IP23	A	30	16(6)
S22	0032	20	22 Ω -16000W	IP23	A	22	16(6)
	0042	12	22 Ω -24000W	IP23	A	22	16(6)
	0051	12	18 Ω -24000W	IP23	A	18	16(6)
	0062	12	15 Ω -32000W	IP23	A	15	16(6)
S32	0069	12	12 Ω -48000W	IP23	A	12	16(6)
	0076	8	10 Ω -48000W	IP23	A	10	25(3)
	0088	8	8.2 Ω -64000W	IP23	A	8.2	25(3)
	0131	5	6.6 Ω -64000W	IP23	A	6.6	50(1/0)
	0164	5	2x10 Ω -48000W	IP23	B	5	50(1/0)

Type of connection:

A - One resistor**B** - Two series-connected resistors

3.1.10. Applications with DUTY CYCLE 10% - Class 6T

Size	Model	BRAKING RESISTOR					
		Min. Applicable Resistor (Ω)	Type	Degree of Protection	Type of Connection	Value (Ω)	Wire cross-section mm^2 (AWG)
S14	0003	150	250 Ω -1500W	IP55	A	250	10(8)
	0004	150	180 Ω -2200W	IP55	A	180	10(8)
	0006	80	150 Ω -2200W	IP55	A	150	10(8)
	0012	80	120 Ω -4000W	IP20	A	120	10(8)
	0018	80	82 Ω -4000W	IP20	A	82	10(8)
	0019	50	60 Ω -4000W	IP23	A	60	10(8)
	0021	50	60 Ω -4000W	IP23	A	60	10(8)
	0022	30	45 Ω -4000W	IP23	A	45	10(8)
	0024	30	30 Ω -8000W	IP23	A	30	10(8)
S22	0032	25	30 Ω -8000W	IP23	A	30	10(8)
	0042	15	22 Ω -8000W	IP23	A	22	10(8)
	0051	15	18 Ω -12000W	IP23	A	18	10(8)
	0062	15	15 Ω -12000W	IP23	A	15	10(8)
S32	0069	15	15 Ω -12000W	IP23	A	15	10(8)
	0076	10	10 Ω -16000W	IP23	A	10	16(6)
	0088	10	10 Ω -24000W	IP23	A	10	16(6)
	0131	6	6.6 Ω -24000W	IP23	A	6.6	16(6)
	0164	6	6 Ω -32000W	IP23	A	6	16(6)

Type of connection:

A - One resistor

3.1.11. Applications with DUTY CYCLE 20% - Class 6T

Size	Model	BRAKING RESISTOR					
		Min. Applicable Resistor (Ω)	Type	Degree of Protection	Type of Connection	Value (Ω)	Wire cross-section mm^2 (AWG)
S14	0003	150	250 Ω -2200W	IP55	A	250	10(8)
	0004	150	180 Ω -4000W	IP20	A	180	10(8)
	0006	80	150 Ω -4000W	IP20	A	150	10(8)
	0012	80	120 Ω -4000W	IP23	A	120	10(8)
	0018	80	82 Ω -4000W	IP23	A	82	10(8)
	0019	50	60 Ω -4000W	IP23	A	60	10(8)
	0021	50	60 Ω -8000W	IP23	A	60	10(8)
	0022	30	45 Ω -8000W	IP23	A	45	10(8)
	0024	30	30 Ω -8000W	IP23	A	30	10(8)
S22	0032	25	30 Ω -12000W	IP23	A	30	10(8)
	0042	15	22 Ω -12000W	IP23	A	22	10(8)
	0051	15	18 Ω -16000W	IP23	A	18	10(8)
	0062	15	15 Ω -16000W	IP23	A	15	10(8)
S32	0069	15	15 Ω -16000W	IP23	A	15	10(8)
	0076	10	10 Ω -24000W	IP23	A	10	16(6)
	0088	10	10 Ω -32000W	IP23	A	10	16(6)
	0131	6	6.6 Ω -48000W	IP23	A	6.6	25(3)
	0164	6	6 Ω -48000W	IP23	A	6	25(3)

Type of connection:

A - One resistor

3.1.12. Applications with DUTY CYCLE 50% - Class 6T

Size	Model	BRAKING RESISTOR					
		Min. Applicable Resistor (Ω)	Type	Degree of Protection	Type of Connection	Value (Ω)	Wire cross-section mm^2 (AWG)
S14	0003	150	250 Ω -4000W	IP20	A	250	16(6)
	0004	150	180 Ω -4000W	IP23	A	180	16(6)
	0006	80	150 Ω -4000W	IP23	A	150	16(6)
	0012	80	120 Ω -8000W	IP20	A	120	16(6)
	0018	80	82 Ω -8000W	IP23	A	82	16(6)
	0019	50	60 Ω -8000W	IP23	A	60	16(6)
	0021	50	60 Ω -12000W	IP23	A	60	16(6)
	0022	30	45 Ω -16000W	IP23	A	45	16(6)
	0024	30	30 Ω -16000W	IP23	A	30	16(6)
S22	0032	25	30 Ω -24000W	IP23	A	30	16(6)
	0042	15	22 Ω -24000W	IP23	A	22	16(6)
	0051	15	18 Ω -32000W	IP23	A	18	16(6)
	0062	15	15 Ω -48000W	IP23	A	15	16(6)
S32	0069	15	15 Ω -48000W	IP23	A	15	16(6)
	0076	10	10 Ω -64000W	IP23	A	10	25(3)
	0088	10	10 Ω -64000W	IP23	A	10	25(3)
	0131	6	2x3 Ω -48000W	IP23	C	6	50(1/0)
	0164	6	2x3 Ω -48000W	IP23	C	6	50(1/0)

Type of connection:

A - One resistor

C - Two series-connected resistors

3.2. Braking Unit (BU200 2T-4T) for S41-S51 and S60-S60P

An external braking unit is available for sizes S60 2T-4T from S41 to S60P.

The BU200 is an Open Type Equipment – degree of protection IP00 – that can be installed inside another enclosure featuring degree of protection IP3X as a minimum requirement.

Transporting, handling and unpacking the braking unit is covered in the general instructions given in the “Transport and Handling” and “Unpacking” sections in the Installation Guide.

3.2.1. Delivery Check

Make sure that the equipment is not damaged and it complies with the equipment you ordered by referring to its front nameplate (see figure below).

If the equipment is damaged, contact the supplier or the insurance company concerned.

If the equipment does not comply with the one you ordered, please contact the supplier as soon as possible.

If the equipment is stored before being started, make sure that temperatures range from $-25^{\circ}\text{C} \div +70^{\circ}\text{C}$ and that relative humidity is $<95\%$ (non-condensing).

The equipment guarantee covers any manufacturing defect. The manufacturer has no responsibility for possible damages due to the equipment transportation or unpacking. The manufacturer is not responsible for possible damages or faults caused by improper and irrational uses; wrong installation; improper conditions of temperature, humidity, or the use of corrosive substances. The manufacturer is not responsible for possible faults due to the equipment operation at values exceeding the equipment ratings and is not responsible for consequential and accidental damages.

The braking unit BU200 is covered by a two-year guarantee starting from the date of delivery.

3.2.1.1. Nameplate for BU200 2T-4T




Figure 14: Nameplate for BU200 2T-4T

Numbered items in the figure above:

1. Model: BU200 – braking unit 2T-4T
2. Voltage class: List of applicable voltage classes
3. Supply ratings: 200-800 Vdc (DC supply voltage produced by the inverter terminals)
4. Output current: 80A (average) – continuous average current in output cables
130A (max.) – max. current in output cables (may be held for the time given in column “Max. Duration of Continuous Operation” in the resistors tables below)
5. Min. load: Minimum value of the resistor to be connected to the output terminals (see application tables below)

3.2.2. Operation

The basic size of the braking unit can be used with a braking resistor avoiding exceeding a max. instant current of 130 A, corresponding to a maximum braking power of approx. 97.5 kW (class 4T) and to an average power of 60 kW (class 4T). For applications requiring higher braking power values, multiple braking units can be parallel-connected in order to obtain a greater braking power based on the number of braking units.

To ensure that the overall braking power is evenly distributed to all braking units, configure one braking unit in MASTER mode and the remaining braking units in SLAVE mode, and connect the output signal of the MASTER unit (terminal 8 in connector M1) to the forcing input for all SLAVE braking units (terminal 4 in connector M1).

3.2.3. Configuration Jumpers

Jumpers located on the control board for BU200 are used for the configuration of the braking unit. Their positions and functions are as follows:

Jumper	Function
J1	If on, it configures the SLAVE operating mode
J2	If on, it configures the MASTER operating mode



NOTE

Either one of the two jumpers must always be “on”. Avoid enabling both jumpers at a time.

Jumper	Function
J3	To be activated for class 4T inverters and mains voltage [380 Vac to 480 Vac]
J4	To be activated for class 2T inverters and mains voltage [200 Vac to 240 Vac]
J5	To be activated for class 4T inverters and mains voltage [481 Vac to 500 Vac]
J6	To be activated for special adjustment requirements



NOTE

One of the four jumpers must always be “ON”. Avoid enabling two or more jumpers at a time.




Figure 15: Positions of BU200 configuration jumpers



DANGER

Before changing jumper positions, remove voltage from the equipment and wait at least 20 minutes.



CAUTION

Never set jumpers to a voltage value lower than the inverter supply voltage. This will avoid continuous activation of the braking unit.

3.2.4. Adjusting Trimmers


Four trimmers are installed on the inverter control board. Depending on the jumper configuration, each trimmer allows the fine-tuning of the braking unit voltage threshold trip. Jumper-trimmer matching is as follows:

Mains voltage [Vac]	Jumper	Trimmer	Minimum braking voltage [Vdc]	Rated braking voltage [Vdc]	Maximum braking voltage [Vdc]
200÷240 (2T)	J4	RV3	339	364	426
380÷480 (4T)	J3	RV2	700	764	826
481÷500 (4T)	J5	RV4	730	783	861
230÷500	J6	RV5	464	650	810



CAUTION

The maximum values in the table above are theoretical values for special applications only. Their use must be authorized by Enertronica Santerno S.p.A.. For standard applications, never change the factory-set rated value.



P000655-0

Figure 16: Positions of BU200 adjusting trimmers

3.2.5. Indicator LEDs

The indicator LEDs below are located on the front part of the braking units:

- OK LED** Normally “on”; the equipment is running smoothly. This LED turns off due to overcurrent or power circuit failure.
- B LED** Normally off”; this LED turns on when the braking unit activates.
- TMAX LED** Normally “off”; this LED turns on when the thermoswitch located on the heat sink of the braking unit trips; if overtemperature protection trips, the equipment is locked until temperature drops below the alarm threshold.




Figure 17: Position of the Indicator LEDs

3.2.6. Ratings

SIZE	Max. Braking Current (A)	Average Braking Current (A)	Sound Pressure (dB)	INVERTER SUPPLY VOLTAGE and JUMPER POSITIONS		
				200-240Vac (class 2T)	380-480Vac (class 4T)	481-500Vac (class 4T)
				J4	J3	J5
				MIN. BRAKING RESISTOR (Ω)		
BU200	130	80	55	3	6	6

3.2.7. Installing the BU200

3.2.7.1. Environmental Requirements for the BU200 Installation, Storage and Transport

Maximum surrounding air temperature	-10 to +40°C with no derating from +40°C to +55°C with a 2% derating of the rated current for each degree beyond +40°C.
Ambient temperatures for storage and transport	-25°C to +70°C.
Installation environment	Pollution degree 2 or better (according to EN 61800-5-1). Do not install in direct sunlight and in places exposed to conductive dust, corrosive gases, vibrations, water sprinkling or dripping (depending on IP ratings); do not install in salty environments.
Altitude	Max. altitude for installation 2000 m a.s.l. For installation above 2000 m and up to 4000 m, please contact Enertronica Santerno S.p.A.. Above 1000 m, derate the rated current by 1% every 100 m.
Operating ambient humidity	From 5% to 95%, from 1g/m ³ to 29g/m ³ , non-condensing and non-freezing (class 3K3 according to EN 61800-5-1).
Storage ambient humidity	From 5% to 95%, from 1g/m ³ to 29g/m ³ , non-condensing and non-freezing (class 1K3 according to EN 61800-5-1).
Ambient humidity during transport	Max. 95%, up to 60g/m ³ ; condensation may appear when the equipment is not running (class 2K3 according to EN 61800-5-1).
Storage and operating atmospheric pressure	From 86 to 106 kPa (classes 3K3 and 1K4 according to EN 61800-5-1).
Atmospheric pressure during transport	From 70 to 106 kPa (class 2K3 according to EN 61800-5-1).



CAUTION

Ambient conditions strongly affect the inverter life. Do not install the equipment in places that do not have the above-mentioned ambient conditions.

3.2.7.2. Cooling System and Dissipated Power

The braking unit is provided with a heat sink reaching a max. temperature of 80°C. Make sure that the bearing surface for the braking unit is capable of withstanding high temperatures. Max. dissipated power is approx. 150 W and depends on the braking cycle required for the operating conditions of the load connected to the motor.



CAUTION

The max. temperature alarm for the braking unit shall be used as a digital signal to control the inverter stop.

3.2.7.3. Mounting

- The braking unit (BU200) must be installed in an upright position inside a cabinet;
- Make sure to allow a min. clearance of 5 cm on both types and 10 cm on top and bottom; use cable-glands to maintain IP20 rating;
- Fix the BU200 with four MA4 screws.

Dimensions (mm)			Distance between fixing points (mm)		Type of screws	Weight (kg)
W	H	D	X	Y	M4	4
139	247	196	120	237		




Figure 18: Dimensions and fixing points of BU200

3.2.7.4. Lay-Out of Power Terminals and Signal Terminals

Remove the cover of the braking unit to gain access to its terminal blocks. Just loosen the four fixing screws of the cover located on the front side and on the bottom side of the braking unit. Loosen the fastening screws to slide off the cover from above. Power terminals consist of copper bars, that can be reached through the three front holes.

Decisive voltage class C according to EN 61800-5-1

Terminal	N.	Type of terminal	Cable cross-section (mm ²)	Connection
+	20	Copper bar	25	Inverter DC side connected to terminal +
B	21	Copper bar	See Resistors table	Connection to braking resistor
-	22	Copper bar	25	Inverter DC side connected to terminal -

Terminal block M1:

Decisive voltage class A according to EN 61800-5-1

N.	Name	Description	Notes	Features	Cable cross-section (mm ²)
M1 : 1		Not used			
M1 : 2	0VE	Signal zero volt		Control board zero volt	0.5÷1
M1 : 3	Vin	Modulation input (0÷10 V)	To be used for special applications	Rin=10kΩ	0.5÷1
M1 : 4	Sin	Logic input for signal sent from Master	The SLAVE brakes if a signal > 6 V is sent	Max. 30V	0.5÷1
M1 : 8	Mout	Digital output for Slave command signal	High level output when the Master is braking	PNP output (0-15V)	0.5÷1
M1 : 9		Not used			
M1 :10		Not used			

Decisive voltage class C according to EN 61800-5-1

M1 : 5	RL-NO	NO contact of "thermoswitch on" relay	The relay energizes when an overtemperature alarm trips for BU200	250Vac, 5A 30Vdc, 5A	0.5÷1
M1 : 6	RL-C	Common of the contact of "thermoswitch on" relay			0.5÷1
M1 : 7	RL-NC	NC contact of "thermoswitch on" relay			0.5÷1





Figure 19: Terminals in BU200

3.2.7.5. Wiring

The braking unit must be connected to the inverter and the braking resistor.

The braking unit is connected directly to the inverter terminals (or copper bars for sizes greater than S32) of the DC voltage output, while the braking resistor must be connected to the inverter on one side and to the braking unit on the other side.

The wiring diagram is shown in the figure below:



P000600-B

Figure 20: Connecting one BU200 to the inverter

The braking resistor must be connected between terminal **B** of BU200 and terminal **+** of the inverter. In that way, no sudden variation in braking current occurs in the supply line between the inverter and BU200. In order to minimize electromagnetic radiated emissions when BU200 is operating, the loop obtained from the wiring connecting terminal **+** of the inverter, the braking resistor, terminals **B** and **-** of BU200 and terminal **-** of the inverter should be as short as possible.



NOTE



NOTE

We recommend installing a 50A fuse with DC voltage of at least 700 Vdc (type URDC SIBA series, NH1 fuse) provided with a safety contact.



CAUTION


Link the safety contact of the fuse being used with the external alarm of BU200.

3.2.7.6. Master – Slave Connection

The Master-Slave connection must be used when multiple braking units are connected to the same inverter. An additional connection must be done between the Master output signal (terminal 8 in M1) and the Slave input signal (terminal 4 in M1); zero volt of the signal connector in the Master module (terminal 2 in M1) must be connected to zero volt of the signal connector in the Slave module (terminal 2 in M1).

The connection of more than two modules must always be done by configuring one module like a master and the other modules like slaves. Use configuration jumpers accordingly.

The max. temperature alarm of the braking unit must be used as a digital signal to control the inverter stop. All contacts (voltage-free contacts) in all braking modules may be series-connected as shown in the diagram below:



P000599-B

Figure 21: Master – Slave multiple connection



NOTE

NEVER connect signal zero volt (terminal 2 in M1) to zero volt of the inverter power supply voltage (-).



NOTE

We recommend installing a 50A fuse with DC current of at least 700 Vdc (type URDC SIBA series, NH1 fuse) provided with a safety contact.



CAUTION

Link the safety contact of the fuse being used with the external alarm of BU200.

3.2.8. Earth Bonding of the BU200

For the earth bonding of the BU200, please refer to the general instructions given in section Inverter and Motor Ground Connection in the Installation Guide.

3.2.9. Scheduled Maintenance of the BU200

For the scheduled maintenance of the BU200, please refer to the general instructions given in section Inverter Scheduled Maintenance in the Installation Guide.



DANGER

Once power supply has been cut off from the drive connected to the BU200, wait at least 20 minutes before operating on the DC circuits to give the capacitors time to discharge.

3.2.10. Braking Resistors for BU200 2T

Refer to the tables below for the connection of the braking resistors.



NOTE The wire cross-sections given in the table relate to one wire per braking resistor.



NOTE The Part Numbers of the braking resistors in the tables are given in the Available Braking Resistors section.



HOT SURFACE The braking resistor case may reach 200°C based on the operating cycle.



CAUTION The cables of the braking resistors shall have insulation features and heat-resistance features suitable for the application. The minimum rated voltage of the cables must be 450/700 V.



CAUTION The power dissipated by the braking resistors may be the same as the rated power of the connected motor multiplied by the braking duty-cycle; use a proper air-cooling system. Do not install braking resistors near heat-sensitive equipment or objects.



CAUTION Do not connect to the inverter any braking resistor with an Ohm value lower than the value given in the tables.



CAUTION Never exceed the maximum operating time of the resistor as given in the Available Braking Resistors section.

3.2.10.1. Applications with DUTY CYCLE 10% - Class 2T

Size	Drive Model	Braking Unit	Braking Resistors						
			Resistors to be used				Type of connection	Value (Ω)	Wire Cross-section mm ² (AWG/kcmils)
			Q.ty	Q.ty	Recommended Value (Ω)	Power (kW)			
S41	0180	2	2	3.3	8	IP20	M	1.65	10(8)
	0202	2	2	3.3	8	IP20	M	1.65	10(8)
	0217	3	3	3.3	8	IP20	N	1.1	10(8)
	0260	3	3	3.3	8	IP20	N	1.1	10(8)
S51	0313	4	4	3.3	8	IP20	O	0.82	10(8)
	0367	5	5	3.3	8	IP20	P	0.66	10(8)
	0402	5	5	3.3	8	IP20	P	0.66	10(8)
S60	0457	6	6	3.3	8	IP20	Q	0.55	10(8)
	0524	6	6	3.3	8	IP20	Q	0.55	10(8)

3.2.10.2. Applications with DUTY CYCLE 20% - Class 2T

Size	Drive Model	Braking Unit	Braking Resistors						
			Resistors to be used				Type of connection	Value (Ω)	Wire Cross-section mm ² (AWG/kcmils)
			Q.ty	Q.ty	Recommended Value (Ω)	Power (kW)			
S41	0180	2	2	3.3	8	IP20	M	1.65	16(6)
	0202	2	2	3.3	8	IP20	M	1.65	16(6)
	0217	3	3	3.3	12	IP20	N	1.1	16(6)
	0260	3	3	3.3	12	IP20	N	1.1	16(6)
S51	0313	4	4	3.3	12	IP20	O	0.82	16(6)
	0367	5	5	3.3	12	IP20	P	0.66	16(6)
	0402	5	5	3.3	12	IP20	P	0.66	16(6)
S60	0457	6	6	3.3	12	IP20	Q	0.55	16(6)
	0524	6	6	3.3	12	IP20	Q	0.55	16(6)

3.2.10.3. Applications with DUTY CYCLE 50% - Class 2T

Size	Drive Model	Braking Unit	Braking Resistors						
			Resistors to be used				Type of connection	Value (Ω)	Wire Cross-section mm ² (AWG/kcmils)
			Q.ty	Q.ty	Recommended Value (Ω)	Power (kW)			
S41	0180	2	4	6.6	12	IP20	V	1.65	25(4)
	0202	2	4	6.6	12	IP20	V	1.65	25(4)
	0217	3	6	6.6	12	IP20	X	1.1	25(4)
	0260	3	6	6.6	12	IP20	X	1.1	25(4)
S51	0313	4	8	6.6	12	IP20	Y	0.82	25(4)
	0367	5	10	6.6	12	IP20	W	0.66	25(4)
	0402	5	10	6.6	12	IP20	W	0.66	25(4)
S60	0457	6	12	6.6	12	IP20	Z	0.55	25(4)
	0524	6	12	6.6	12	IP20	Z	0.55	25(4)

M-Two units, each of them including a braking module connected to its braking resistor

N-Three units, each of them including a braking module connected to its braking resistor

O-Four units, each of them including a braking module connected to its braking resistor

P-Five units, each of them including a braking module connected to its braking resistor

Q-Six units, each of them including a braking module connected to its braking resistor

V-Two units, each of them including a braking module connected to two parallel-connected braking resistors

X-Three units, each of them including a braking module connected to two parallel-connected braking resistors

Y-Four units, each of them including a braking module connected to two parallel-connected braking resistors

W-Five units, each of them including a braking module connected to two parallel-connected braking resistors

Z-Six units, each of them including a braking module connected to two parallel-connected braking resistors



CAUTION

The cable cross-sections given in the table relate to the cable connecting each individual braking resistor. For example, if a braking resistor is connected to N.2 parallel-connected resistors, the cable cross-section in the table is the one for each resistor connected to the braking unit.

3.2.11. Braking Resistors for BU200 4T



NOTE The wire cross-sections given in the table relate to one wire per braking resistor.



NOTE The Part Numbers of the braking resistors in the tables are given in the Available Braking Resistors section.



CAUTION The cables of the braking resistors shall have insulation features and heat-resistance features suitable for the application. The minimum rated voltage of the cables must be 0.6/1kV.



HOT SURFACE Based on the functioning cycle, the surface of the braking resistors may reach 200°C.



CAUTION The power dissipated by the braking resistors may be the same as the rated power of the connected motor multiplied by the braking duty-cycle; use a proper air-cooling system. Do not install braking resistors near heat-sensitive equipment or objects.



CAUTION Do not connect to the inverter any braking resistor with an Ohm value lower than the value given in the tables.



CAUTION Never exceed the maximum operating time of the resistor as given in the Available Braking Resistors section.

3.2.11.1. Applications with DUTY CYCLE 10% - Class 4T

Size	Drive Model	Braking Unit	Braking Resistors						
			Resistors to be used				Type of Connection	Value (Ω)	Wire Cross-section mm ² (AWG/kcmils)
			Q.ty	Q.ty	Recommended Value (Ω)	Power (kW)			
S41	0180	2	2	6.6	12	IP20	M	3.3	16(6)
	0202	2	2	6.6	12	IP20	M	3.3	16(6)
	0217	3	3	6.6	12	IP20	N	2.2	16(6)
	0260	3	3	6.6	12	IP20	N	2.2	16(6)
S51	0313	3	3	6.6	12	IP20	N	2.2	16(6)
	0367	4	4	6.6	12	IP20	O	1.65	16(6)
	0402	4	4	6.6	12	IP20	O	1.65	16(6)
S60	0457	4	4	6.6	12	IP20	O	1.65	16(6)
	0524	5	5	6.6	12	IP20	P	1.32	16(6)
S60P	0598P	6	6	6.6	12	IP20	Q	1.1	16(6)

3.2.11.2. Applications with DUTY CYCLE 20% - Class 4T

Size	Drive Model	Braking Unit	Braking Resistors						
			Resistors to be used				Type of Connection	Value (Ω)	Wire Cross-section mm ² (AWG/kcmils)
			Q.ty	Q.ty	Recommended Value (Ω)	Power (kW)			
S41	0180	2	2	6.6	24	IP23	M	3.3	16(6)
	0202	2	2	6.6	24	IP23	M	3.3	16(6)
	0217	3	3	6.6	24	IP23	N	2.2	16(6)
	0260	3	3	6.6	24	IP23	N	2.2	16(6)
S51	0313	3	3	6.6	24	IP23	N	2.2	16(6)
	0367	4	4	6.6	24	IP23	O	1.65	16(6)
	0402	4	4	6.6	24	IP23	O	1.65	16(6)
S60	0457	4	4	6.6	24	IP23	O	1.65	16(6)
	0524	5	5	6.6	24	IP23	P	1.32	16(6)
S60P	0598P	6	6	6.6	24	IP23	Q	1.1	16(6)

3.2.11.3. Applications with DUTY CYCLE 50% - Class 4T

Size	Drive Model	Braking Unit	Braking Resistors						
			Resistors to be used				Type of Connection	Value (Ω)	Wire Cross-section mm ² (AWG or kcmils)
			Q.ty	Q.ty	Recommended Value (Ω)	Power (kW)			
S41	0180	3	3	10	24	IP23	N	3.3	16(6)
	0202	3	3	10	24	IP23	N	3.3	16(6)
	0217	4	4	10	24	IP23	O	2.5	16(6)
	0260	4	4	10	24	IP23	O	2.5	16(6)
S51	0313	5	5	10	24	IP23	P	2.0	16(6)
	0367	6	6	10	24	IP23	Q	1.7	16(6)
	0402	7	7	10	24	IP23	R	1.4	16(6)
S60	0457	7	7	10	24	IP23	R	1.4	16(6)
	0524	8	8	10	24	IP23	S	1.25	16(6)
S60P	0598P	8	8	10	24	IP23	S	1.25	16(6)

M-Two units, each of them including a braking module connected to its braking resistor

N-Three units, each of them including a braking module connected to its braking resistor

O-Four units, each of them including a braking module connected to its braking resistor

P-Five units, each of them including a braking module connected to its braking resistor

Q-Six units, each of them including a braking module connected to its braking resistor

R-Seven units, each of them including a braking module connected to its braking resistor

S-Eight units, each of them including a braking module connected to its braking resistor



CAUTION

The cable cross-sections given in the table relate to the cable connecting each individual braking resistor. For example, if a braking resistor is connected to N.2 parallel-connected resistors, the cable cross-section in the table is the one for each resistor connected to the braking unit.

3.3. Braking Units for S41..S52 and Their Parallel Configuration and Drives S60-S60P (BU600 4T-5T-6T)

The BU600 4T-5T-6T braking unit is available for the following sizes:

- S41 / S42 / S51 / S52;
- Parallel configuration of S43 (2 x S41) / S53 (2 x S51) / S55 (3 x S51) / S44 (2 x S42) / S54 (2 x S52) / S56 (3 x S52);
- S60 / S60P.

The BU600 may also be used as a stand-alone braking unit to be connected to a suitable DC BUS.

The BU600 is an Open Type Equipment – degree of protection IP00 – that can be installed inside another enclosure featuring degree of protection IP3X as a minimum requirement.

Transporting, handling and unpacking the braking unit is covered in the general instructions given in the “Transport and Handling” and “Unpacking” sections in the Installation Guide.

3.3.1. Delivery Check

Make sure that the equipment is not damaged and that it complies with the equipment you ordered by referring to the nameplate located on the inverter front part (see figure below). If the equipment is damaged, contact the supplier or the insurance company concerned. If the equipment does not comply with the one you ordered, please contact the supplier as soon as possible.

If the equipment is stored before being started, make sure that temperatures range from -25°C to +70°C and that relative humidity is <95% (non-condensing).

The equipment guarantee covers any manufacturing defect. The manufacturer has no responsibility for possible damages occurred while shipping or unpacking the equipment. The manufacturer is not responsible for possible damages or faults caused by improper and irrational uses; wrong installation; improper conditions of temperature, humidity, or the use of corrosive substances. The manufacturer is not responsible for possible faults due to the equipment operation at values exceeding the equipment ratings. The manufacturer is not responsible for consequential and accidental damages.

The braking unit is covered by a two-year guarantee starting from the date of delivery.

3.3.1.1. Nameplate for BU600 4T-5T-6T




Figure 22: Nameplate for BU600 4T-5T-6T

1. Model: BU600 – Braking module 4T-5T-6T
2. Supply ratings: DC supply voltage deriving directly from the inverter terminals or the DC Bus connected to the BU600)
3. Output current: 300A (average) – continuous average current in output cables
600A (max.) – max. current in output cables (may be held for all the time given in column “Max. Duration of Continuous Operation” in the resistors tables below)
4. Min. load: Minimum value of the resistor to be connected to the output terminals (see application tables below)

3.3.2. Operating Mode of the BU600 Connected to Drives S41..S52 and their Configuration in Parallel

As a factory setting, the braking module is powered and controlled directly by the inverter (parameter P200=2:Slave) [*].



NOTE As a factory setting, the signals on terminal M1 of the braking module are to be connected to the signals on the BRAKE connector of the inverter using the cable supplied.



NOTE [*] If this factory setting it so be changed, alter parameter P200 from the RemoteDrive (see BU600 – Programming Guide).



S000135

Figure 23: BRAKE connector supplied with the drive



S000136

Figure 24: Cable connecting the drive to braking unit BU600

3.3.3. Operating Mode of the BU600 when Connected to S60 and S60P Drives or a DC-BUS Made UP of Sinus Penta /Penta Marine Drives from Different Sizes

The braking unit operates independently, i.e. it is not powered and controlled by the drive.



NOTE

In order to make the braking unit operate independently, access the RemoteDrive and change parameter **P200** from 2:Slave to 1:Master; also, change parameters **P201** and **P202** based on the voltage class of the connected drive (see BU600 – Programming Guide).

This voltage class is 4T for S60 and S60P drives.



NOTE

The cable supplied is not required.

Parameters **P201** and **P202** are to be changed in case of applications that for 4T class drives require rated drive supply voltage exceeding 480Vac or that are power supplied by the DC bus from the Regenerative drive. In any case, braking voltage and hysteresis must be consistent with drive parameter **C008** (see the Programming Guide).

Sinus Penta / Penta Marine Parameter	BU600 Parameters			
	P001 Voltage Class	P200 Operating Mode	P201 Braking voltage (V)	P202 Hysteresis (V)
C008				
0: [200 ÷ 240] V 1: 2T Regen.	Not considered	-----	-----	-----
2: [380 ÷ 480] V 3: [481 ÷ 500] V 4: 4T Regen.	4T	0: Master+Slave 1: Master 2: Slave (default)	764.6 (default)	5 (default)
5: [500 ÷ 575] V 6: 5T Regen.	5T	0: Master+Slave 1: Master 2: Slave (default)	956.2 (default)	10 (default)
7: [575 ÷ 690] V 8: 6T Regen	6T	0: Master+Slave 1: Master 2: Slave (default)	1103.2 (default)	10 (default)

3.3.4. BU600 Used as a General-purpose Braking Unit to be Connected to a DC-Bus

The BU600 may be used in all applications featuring a DC-Bus from which energy is to be taken during particular working conditions (presence of alternating loads, electric traction, lifting, etc..). This operating mode is available, but is to be authorized by Enertronica Santerno S.p.A..

3.3.5. Diagnostics

The following diagnostic LEDs are provided:

S000134




Figure 25: Diagnostic LEDs

+24V, -24V: Both “on” when the braking unit is powered on

DSP RUN [*]: “On” when the on-board microcontroller is on

BRAKE ON: “On” when the braking IGBT is ON

TYPE OF FAULT [*]: Code of the active fault indicated by the flashing LED. Please refer to the BU600 – Programming Guide.

BRAKE FAULT: “On” when a fault occurs; it turns off only when the RESET input in terminal board M2 is activated.

OTBR FAULT: “On” when the thermoswitch trips (it comes on in conjunction with the BRAKE FAULT LED). It turns off when the fault condition is reset.

OTBU FAULT: IGBT thermal protection tripped (it comes on in conjunction with the BRAKE FAULT LED). It turns off when the fault condition is reset.



[*] NOTE This function is available from software version 1.000.

Event	Description	Alarm ID	Flashing	OFF
Alarm	A001 User alarm or Checksum Fault or Watchdog Fault	A001+A002+A013	Always on	
Alarm	Brake short circuit	A011	1 blink at 1 Hz	4.5s
Alarm	IGBT fault	A004	2 blinks at 1 Hz	4.5s
Alarm	HW Overcurrent	A005	3 blinks at 1 Hz	4.5s
Alarm	Overvoltage	A012	4 blinks at 1 Hz	4.5s
Alarm	Driver board overtemperature or DSP overtemperature	A008+A009	5 blink at 1 Hz	4.5s
Alarm	DC Link Undervoltage	A007	6 blinks at 1 Hz	4.5s
Warning	Fan1 inactive	W001	7 blinks at 1 Hz	4.5s
Warning	Fan2 inactive	W002	8 blinks at 1 Hz	4.5s
Warning	Heatsink overheated	W003	9 blinks at 1 Hz	4.5s
Warning	Overload braking resistor	W004	10 blinks at 1 Hz	4.5s

Table 3: Alarm ID and Type of fault on BU600 with the TYPE OF FAULT LED

3.3.6. Specifications

MODEL	Max. Braking Current (A)	Average Braking Current (A)	Drive Supply Voltage	Min. Braking Resistor (Ω)	Power Dissipated (at Average Braking Current) (W)	Sound Pressure (dB)
BU600 4T	650	300	380-500Vac	1.2	700	60
BU600 5T	650	300	500-600Vac	1.6	700	60
BU600 6T	600	300	600-690Vac	1.8	700	60

3.3.7. Installing the BU600*3.3.7.1. Environmental Requirements for the BU600 Installation, Storage and Transport*

Maximum surrounding air temperature	-10 to +40°C with no derating From +40°C to +55°C with a 2% derating of the rated current for each degree beyond +40°C.
Ambient temperatures for storage and transport	-25°C to +70°C
Installation environment	Pollution degree 2 or better (according to EN 61800-5-1). Do not install in direct sunlight and in places exposed to conductive dust, corrosive gases, vibrations, water sprinkling or dripping; do not install in salty environments.
Altitude	Max. altitude for installation 2000 m a.s.l. For installation above 2000 m and up to 4000 m, please contact Enertronica Santerno S.p.A.. Above 1000 m, derate the rated current by 1% every 100 m.
Operating ambient humidity	From 5% to 95%, from 1g/m ³ to 29g/m ³ , non-condensing and non-freezing (class 3K3 according to EN 61800-5-1).
Storage ambient humidity	From 5% to 95%, from 1g/m ³ to 29g/m ³ , non-condensing and non-freezing (class 1K3 according to EN 61800-5-1).
Ambient humidity during transport	Max. 95%, up to 60g/m ³ ; condensation may appear when the equipment is not running (class 2K3 according to EN 61800-5-1).
Storage and operating atmospheric pressure	From 86 to 106 kPa (classes 3K3 and 1K4 according to EN 61800-5-1).
Atmospheric pressure during transport	From 70 to 106 kPa (class 2K3 according to EN 61800-5-1).

**CAUTION**

Ambient conditions strongly affect the inverter life. Do not install the equipment in places that do not have the above-mentioned ambient conditions.

3.3.7.2. Mounting the Braking Unit

The braking unit BU600 must be installed in upright position inside a cabinet. Its overall dimensions and fixing points are given in the figure below.

Dimensions (mm)			Fixing Points (mm)				Type of Screws	Weight (kg)
W	H	D	X	Y	D1	D2	M8-M10	72
248	881.5	399	170	845	12	24		




Figure 26: Dimensions and fixing points of braking unit BU600

The location of the BU600 units inside the cabinet is dependent on the number of BUs to be installed. A general criterion is to try to shorten the DC-bus connections as much as possible and to balance power absorption from the BU600 units and the relative braking resistors.

- N.1 BU600 connected to S41, S42, S51, S52, S43 (2 x S41), S44 (2 x S42), S53 (2 x S51) up to size 0749 included, S60 and S60P

It is recommended that the BU600 is installed on the left of the drives.

- N.2 BU600 units connected to S53 (2 x S51) from 0832 included, S55 (3 x S51), S54 (2 x S52) and to S56 (3 x S52) up to size 0960 included

Recommended installation:

The first BU600 on the left of the drives, and the second BU600 between the two drives for the sizes that require two drives;

The first BU600 on the left of the drives, and the second BU600 between the second and the third drive for the sizes that require three drives.

- N.3 BU600 connected to S56 (3 x S52) size 1120:

Recommended installation:

The first BU600 on the left of the drives, the second BU600 between the first and the second drive, the third BU600 between the second and the third drive.

3.3.7.3. Lay-Out of Power Terminals and Signal Terminals

Power connections

Link the braking module to the inverter and to the braking resistor as described below.

Decisive voltage class C according to EN 61800-5-1

Terminal	Type	Tightening Torque (Nm)	Connection Bar Cross-section mm ² (AWG/kcmils)	NOTES
+	Bus bar	30	240 (500kcmils)	To be connected to terminal 47/+ of the inverter and to one terminal of the braking resistor
B	Bus bar	30	See Resistors Table	To be connected to the remaining terminal of the braking resistor
-	Bus bar	30	240 (500kcmils)	To be connected to terminal 49/- of the inverter

Table 4: BU600 Power terminals




Figure 27: Power terminals

Signal connections

Terminals M1 – Connect to the inverter using the cable supplied.

Terminal board specifications

Cable cross-section fitting the terminal mm ² (AWG)	Tightening torque (Nm)
0.25÷1.5mm ² (AWG 24-16)	0.22-0.25

Decisive voltage class A according to EN 61800-5-1

N.	Name	Description	I/O Features	Slave connected to S41, S42, S51, S52	Master connected to S60-S60P or a general- purpose DC-bus	Slave connected to another BU600
1	BRAKE	Braking unit command signal	0-24V (active at +24V)	To be connected to the brake terminals of the inverter using the cable supplied	Do not connect	To be connected to terminal 5 in the Master BU600
2	0V	Ground	0V		To be connected to terminal 2 in another BU600 (if any) operating in parallel	To be connected to terminal 2 in the Master BU600
3	BRERR	Braking unit tripped	0-24V (to +24V with braking unit tripped)		To be used by a controller (if any) of the application	To be used by a controller (if any) of the application
4	BU_PRES	Braking unit present and ready to operate	0-24V (to +24V with braking unit present and ready to operate)		To be connected to terminal 1 in another BU600 (if any) operating in parallel	To be connected to terminal 1 in another BU600 (if any) operating in parallel
5	SLAVE	Braking in progress	0-24V (to +24V with BU600 that is braking)		Ground	Ground
6	0V	Ground	0V	-	-	-
7	CANL	Unavailable	-	-	-	-
8	CANH		-	-	-	-

Terminals M2

Decisive voltage class A according to EN 61800-5-1

N.	Name	Description	I/O Features	NOTES	Cable Cross-section Fitting the Terminal mm ² (AWG)	Tightening Torque (Nm)
9	24VE	Auxiliary 24V voltage generated internally to the braking module	24V 100mA	Available to send the Reset signal	0.25÷1.5mm ² (AWG 24-16)	0.22-0.25
10	RESET	Braking module fault reset command	0-24V (active at 24V)	To be connected to +24VE by means of a push-button for fault reset	0.25÷1.5mm ² (AWG 24-16)	0.22-0.25
11	24VE	Auxiliary 24V voltage generated internally to the braking module	24V 10mA	To be connected to the thermostat in the braking resistor [*]	0.25÷1.5mm ² (AWG 24-16)	0.22-0.25
12	PTR	Input for the braking resistor thermostat	0-24V (with +24V braking resistor OK)	To be connected to the thermostat in the braking resistor [*]	0.25÷1.5mm ² (AWG 24-16)	0.22-0.25



[*] NOTE

If more than one braking resistor is connected to the BU600, all the thermostats are to be series-connected. The thermostats are to be normally closed.

Terminals M3 (functions available from SW version 1.000)

Decisive voltage class C according to EN 61800-5-1

N.	Name	Description	I/O Features	NOTES	Cable Cross-section Fitting the Terminal mm ² (AWG)	Tightening Torque (Nm)
13	RL1-NC	Braking unit present and ready to operate	6A/250Vac 6A/30Vdc	Relay energized with the braking unit present and ready to operate. The relay reproduces the status of terminal 4 in M1.	0.2÷2.5mm ² (AWG 24-14)	0.5-0.6
14	RL1-C					
15	RL1-NO					

Terminals M4 (functions available from SW version 1.000)

Decisive voltage class C according to EN 61800-5-1

N.	Name	Description	I/O Features	NOTES	Cable Cross-section Fitting the Terminal mm ² (AWG/kcmils)	Tightening Torque (Nm)
16	RL2-NC	Braking unit tripped [*]	6A/250Vac 6A/30Vdc	Energized relay with braking unit tripped. The relay reproduces the status of terminal 3 in M1. It is recommended that this relay be used to protect braking resistors in case of BU600 fault.	0.2÷2.5mm ² (AWG 24-14)	0.5-0.6
17	RL2-C					
18	RL2-NO					



[*] NOTE

As a factory setting, the relay energizes only if alarm **A011** (Braking Unit Short-circuit) has tripped. See BU600 – Programming Guide.

Serial port

Decisive voltage class A according to EN 61800-5-1

The BU600 features RS-485 serial interface; for details on serial communications, please refer to the Serial Communications section in this manual and to the BU600 – Programming Guide.




Figure 28: Signal terminals in the BU600


1. Serial port [*]
2. M1 - BRAKE terminals
3. M2 - Reset signal
4. M3 - BU detecting relay [*]
5. M4 - Alarm relay [*]



NOTE [*]

Functions available from SW version 1.000.

3.3.7.4. Wiring Diagram of a BU600 Operating as a Slave




S000159

Figure 29: Wiring diagram of a single drive with braking unit BU600


3.3.7.5. Wiring Diagram of Two BU600 Operating as Slaves

Figure 30 and Figure 31 show the wiring diagram and the location of N.2 BU600 4T operating as slaves for SINUS PENTA/PENTA MARINE S51 drives operating in parallel.



S000834

Figure 30: Signal connections of two BU600 operating as slaves



S000833

Figure 31: Power connections and location of two BU600 operating as slaves

3.3.8. Earth Bonding of the BU600

For the earth bonding of the BU600, please refer to the general instructions given in section Inverter and Motor Ground Connection in the Installation Guide.

3.3.9. Protecting the Braking Resistors

Based on their power and energy ratings, the braking resistors are capable of withstanding a maximum allowable power-on time and a given duty cycle. When operating as slaves, in order not to overload the resistors, the maximum allowable power-on time and a given duty cycle are to be set for the drive controlling braking cycle (see the Available Braking Resistors section and the Programming Guide).

This solution might not be sufficient to protect the braking resistors. The following actions are therefore required:

- Always connect the braking resistor thermoswitch to prevent overheating from occurring due to poor air circulation or wrong setting of the maximum duty cycle parameter;
- Use the safety relay to cut off the power supply to the DC-bus connected to the braking module. Should a short-circuit occur in the braking module, the braking resistors and the relevant connection cables are always live on the DC bus, thus leading to melting risk.



DANGER

Should a short-circuit occur in the braking module, the braking resistors and the relevant connection cables are always live on the DC bus, thus leading to melting risk and fire risk.

Always make sure that a method to cut off power supply from the DC bus is available in case of short-circuit of the braking module.

3.3.10. Scheduled Maintenance of the BU600

For the scheduled maintenance of the BU600, please refer to the general instructions given in section Inverter and Motor Ground Connection in the Installation Guide.



DANGER

Once power supply has been cut off from the drive connected to the BU600, wait at least 20 minutes before operating on the DC circuits to give the capacitors time to discharge.

3.3.11. Braking Resistors to be Applied to BU600 4T



NOTE

The wire cross-sections given in the table relate to one wire per braking resistor.



NOTE

The Part Numbers of the braking resistors in the tables are given in the Available Braking Resistors section.



HOT SURFACE

The braking resistor case may reach 200°C based on the operating cycle.



CAUTION

The cables of the braking resistors shall have insulation features and heat-resistance features suitable for the application. The minimum rated voltage of the cables must be 0.6/1kV.



CAUTION

The power dissipated by the braking resistors may be the same as the rated power of the connected motor multiplied by the braking duty-cycle; use a proper air-cooling system. Do not install braking resistors near heat-sensitive equipment or objects.



CAUTION

Do not connect to the inverter any braking resistor with an Ohm value lower than the value given in the tables.



CAUTION

Never exceed the maximum operating time of the resistor as given in the Available Braking Resistors section.

3.3.11.1. Applications with DUTY CYCLE 10% - Class 4T

DRIVE SIZE	Drive Model	Braking Unit	Braking Resistors						
			Resistors to be used				Type of Connection	Value (Ω)	Wire Cross-section mm ² (AWG)
			Q.ty	Q.ty	Recommended Value (Ω)	Power (kW)			
S41	0180	1	1	3.6	16	IP23	A	3.6	25(4)
	0202	1	1	3.0	24	IP23	A	3.0	25(4)
	0217	1	1	2.4	24	IP23	A	2.4	35(3)
	0260	1	1	2.4	32	IP23	A	2.4	35(3)
S51	0313	1	1	1.8	32	IP23	A	1.8	50(1/0)
	0367	1	1	1.8	32	IP23	A	1.8	50(1/0)
	0402	1	1	1.4	48	IP23	A	1.4	70(2/0)
S60	0457	1	1	1.4	48	IP23	A	1.4	70(2/0)
	0524	1	1	1.2	48	IP23	A	1.2	95(3/0)
S60P	0598P	1	1	1.2	64	IP23	A	1.2	95(3/0)
S43 (2 x S41)	0523	1	1	1.2	48	IP23	A	1.2	95(3/0)
S53 (2 x S51)	0599	1	1	1.2	64	IP23	A	1.2	95(3/0)
	0749	1	1	1.2	64	IP23	A	1.2	95(3/0)
	0832	2	2	1.6	48	IP23	A	0.8	70(1/0)
S55 (3 x S51)	0850	2	2	1.4	48	IP23	A	0.7	70(2/0)
	0965	2	2	1.2	48	IP23	A	0.6	95(3/0)
	1129	2	2	1.2	64	IP23	A	0.6	95(3/0)

3.3.11.2. Applications with DUTY CYCLE 20% - Class 4T

DRIVE SIZE	Drive Model	Braking Unit	Braking Resistors						
			Resistors to be used				Type of Connection	Value (Ω)	Wire Cross-section mm ² (AWG)
			Q.ty	Q.ty	Recommended Value (Ω)	Power (kW)			
S41	0180	1	1	3.6	32	IP23	A	3.6	16(6)
	0202	1	1	3.0	48	IP23	A	3.0	25(3)
	0217	1	1	2.4	48	IP23	A	2.4	50(1/0)
	0260	1	1	2.4	64	IP23	A	2.4	50(1/0)
S51	0313	1	1	1.8	64	IP23	A	1.8	95(3/0)
	0367	1	1	1.8	64	IP23	A	1.8	95(3/0)
	0402	1	2	2.8	48	IP23	B	1.4	50(1)
S60	0457	1	2	2.8	48	IP23	B	1.4	50(1)
	0524	1	2	2.4	48	IP23	A	1.2	50(1/0)
S60P	0598P	1	2	2.4	64	IP23	A	1.2	50(1/0)
S43 (2 x S41)	0523	1	2	2.4	48	IP23	A	1.2	50(1/0)
S53 (2 x S51)	0599	1	2	2.4	64	IP23	A	1.2	50(1/0)
	0749	1	2	2.4	64	IP23	A	1.2	50(1/0)
	0832	2	4	3.6	32	IP23	B	0.9	25(3)
	0850	2	4	2.8	48	IP23	B	0.7	50(1)
S55 (3 x S51)	0965	2	4	2.4	48	IP23	B	0.6	50(1/0)
	1129	2	4	2.4	48	IP23	B	0.6	50(1/0)

3.3.11.3. Applications with DUTY CYCLE 50% - Class 4T

DRIVE SIZE	Drive Model	Braking Unit	Braking Resistors						
			Resistors to be used				Type of Connection	Value (Ω)	Wire Cross-section mm ² (AWG)
			Q.ty	Q.ty	Recommended Value (Ω)	Power (kW)			
S41	0180	1	2	6.6	48	IP23	B	3.3	25(3)
	0202	1	2	6.0	64	IP23	B	3.0	35(2)
	0217	1	2	5.0	64	IP23	B	2.5	35(2)
	0260	1	2	5.0	64	IP23	B	2.5	35(2)
S51	0313	1	3	0.6	48	IP23	C	1.8	240(350)
	0367	1	3	0.6	64	IP23	C	1.8	240(350)
	0402	1	4	1.4	64	IP23	D	1.4	95(3/0)
S60	0457	1	4	1.4	64	IP23	D	1.4	95(3/0)
	0524	1	4	1.2	64	IP23	D	1.2	120(4/0)
S60P	0598P	1	4	1.2	64	IP23	D	1.2	120(4/0)
S43 (2 x S41)	0523	1	4	1.2	64	IP23	D	1.2	120(4/0)
S53 (2 x S51)	0599	1	4	1.2	64	IP23	D	1.2	120(4/0)
	0749	1	4	1.2	64	IP23	D	1.2	120(4/0)
	0832	2	6	5.0	64	IP23	B	0.83	35(2)
S55 (3 x S51)	0850	2	6	4.2	64	IP23	B	0.7	50(1)
	0965	2	8	1.2	64	IP23	D	0.6	120(4/0)
	1129	2	8	1.2	64	IP23	D	0.6	120(4/0)

Type of connection:

- A** - One resistor only
- B** - Two or more parallel-connected resistors
- C** - Two or more series-connected resistors
- D** - Four resistors (parallel connection of two series of two resistors)

**CAUTION**

The wire cross-sections given in the table relate to one wire per braking resistor. For example, if two resistors are connected in parallel to a braking unit, the cross-section in the table is related to the cable connecting each resistor to the module. In case of a different wiring diagram, the cross-section is to be recalculated based on the RMS of the current flowing in the cable.

**NOTE**

If the BU600 is connected to parallel-connected inverters (2 x S41, 2 x S51 and 3 x S51), the number of BUs required and given in the table is the total number of BUs, *not* the number of BUs for each individual inverter in the parallel-connected configuration.

3.3.12. Braking Resistors to be Applied to BU600 5T-6T



NOTE

The wire cross-sections given in the table relate to one wire per braking resistor.



NOTE

The Part Numbers of the braking resistors in the tables are given in the Available Braking Resistors section.



**HOT
SURFACE**

The braking resistor case may reach 200°C based on the operating cycle.



CAUTION

The cables of the braking resistors shall have insulation features and heat-resistance features suitable for the application. The minimum rated voltage of the cables must be 0.6/1kV.



CAUTION

The power dissipated by the braking resistors may be the same as the rated power of the connected motor multiplied by the braking duty-cycle; use a proper air-cooling system. Do not install braking resistors near heat-sensitive equipment or objects.



CAUTION

Do not connect to the inverter any braking resistor with an Ohm value lower than the value given in the tables.



CAUTION

Never exceed the maximum operating time of the resistor as given in the Available Braking Resistors section.

3.3.12.1. Applications with DUTY CYCLE 10% - Class 5T

DRIVE SIZE	Drive Model	Braking Unit	Braking Resistor						
			Resistors to be used				Type of Connection	Value (Ω)	Wire Cross-section mm ² (AWG)
			Q.ty	Q.ty	Recommended Value (Ω)	Power (kW)			
S42	0181	1	1	4.2	32	IP23	A	4.2	25(3)
	0201	1	1	3.6	32	IP23	A	3.6	35(2)
	0218	1	1	3.6	32	IP23	A	3.6	35(2)
	0259	1	1	3.0	32	IP23	A	3.0	35(2)
S52	0290	1	1	3.0	32	IP23	A	3.0	70(2/0)
	0314	1	1	2.4	48	IP23	A	2.4	70(2/0)
	0368	1	1	2.4	48	IP23	A	2.4	70(2/0)
	0401	1	1	1.8	64	IP23	A	1.8	95(3/0)
S44 (2xS42)	0459	1	1	1.6	64	IP23	A	1.6	95(3/0)
S54 (2xS52)	0526	2	2	2.8	48	IP23	A	1.4	35(2)
	0600	2	2	2.4	48	IP23	A	1.2	50(1)
	0750	2	2	2.1	48	IP23	A	1.05	70(1/0)
	0828	2	2	1.8	48	IP23	A	0.9	70(2/0)
S56 (3xS52)	0960	2	2	1.6	64	IP23	A	0.8	95(3/0)
	1128	3	3	1.8	64	IP23	A	0.8	70(2/0)

3.3.12.2. Applications with DUTY CYCLE 50% - Class 5T

DRIVE SIZE	Drive Model	Braking Unit	Braking Resistor						
			Resistors to be used				Type of Connection	Value (Ω)	Wire Cross-section mm ² (AWG)
			Q.ty	Q.ty	Recommended Value (Ω)	Power (kW)			
S42	0181	1	4	4.2	32	IP23	D	4.2	35(2)
	0201	1	4	3.6	48	IP23	D	3.6	50(1/0)
	0218	1	4	3.6	48	IP23	D	3.6	50(1/0)
	0259	1	4	3.0	48	IP23	D	3.0	70(2/0)
S52	0290	1	4	2.4	48	IP23	D	2.4	70(2/0)
	0314	1	4	2.4	48	IP23	D	2.4	70(2/0)
	0368	1	4	2.4	64	IP23	D	2.4	70(2/0)
	0401	1	4	1.8	64	IP23	D	1.8	95(4/0)
S44 (2xS42)	0459	1	6	2.4	48	IP23	E	1.6	50(1/0)
S54 (2xS52)	0526	2	6	8.2	64	IP23	B	1.37	70(2/0)
	0600	2	6	6.6	64	IP23	B	1.1	35/(3)
	0750	2	8	2.1	64	IP23	C	1.05	70(2/0)
	0828	2	8	1.8	64	IP23	C	0.9	95(3/0)
S56 (3xS52)	0960	2	10	0.3	64	IP23	C	0.75	2x120/(2x4/0)
	1128	3	12	1.8	64	IP23	D	0.6	95(3/0)

Type of connection:

- A** - One resistor per braking unit
- B** - Two or more parallel-connected resistors per braking unit
- C** - Two or more series-connected resistors per braking unit
- D** - For resistors per braking unit (parallel connection of two series of two resistors)
- E** - Six resistors per braking unit (parallel connection of three series of two resistors)
- G** - Six resistors (parallel connection of two series of three resistors) per braking unit



CAUTION

The wire cross-sections given in the table relate to one wire per braking resistor. For example, if two resistors are connected in parallel to a braking unit, the cross-section in the table is related to the cable connecting each resistor to the module. In case of a different wiring diagram, the cross-section is to be recalculated based on the RMS of the current flowing in the cable.



NOTE

If the BU600 is connected to parallel-connected inverters (2 x S44, 2 x S52 and 3 x S52), the number of BUs required and given in the table is the total number of BUs, *not* the number of BUs for each individual inverter in the parallel-connected configuration.

3.3.12.3. *Applications with DUTY CYCLE 10% - Class 6T*

DRIVE SIZE	Drive Model	Braking Unit	Braking Resistor						
			Resistors to be used				Type of Connection	Value (Ω)	Wire Cross-section mm ² (AWG)
			Q.ty	Q.ty	Recommended Value (Ω)	Power (kW)			
S42	0181	1	1	5.0	32	IP23	A	5.0	25(3)
	0201	1	1	3.6	32	IP23	A	3.6	35(2)
	0218	1	1	3.6	32	IP23	A	3.6	35(2)
	0259	1	1	3.6	48	IP23	A	3.6	70(2/0)
S52	0290	1	1	3.0	48	IP23	A	3.0	70(2/0)
	0314	1	1	2.4	48	IP23	A	2.4	70(2/0)
	0368	1	1	2.4	64	IP23	A	2.4	95(4/0)
	0401	1	1	1.8	64	IP23	A	1.8	120(250)
S44 (2xS42)	0459	1	2	3.6	48	IP23	B	1.8	35(3)
S54 (2xS52)	0526	2	2	2.8	48	IP23	A	1.4	50(1)
	0600	2	2	2.8	48	IP23	A	1.4	50(1)
	0750	2	2	2.4	48	IP23	A	1.2	70(1/0)
	0828	2	2	1.8	64	IP23	A	0.9	95(3/0)
S56 (3xS52)	0960	2	2	1.8	64	IP23	A	0.9	95(3/0)
	1128	3	3	2.1	64	IP23	A	0.7	70(2/0)

3.3.12.4. Applications with DUTY CYCLE 20% - Class 6T

SIZE	Model	Braking Unit	Braking Resistor						
			Resistors to be used				Type of Connection	Value (Ω)	Wire Cross-section mm ² (AWG)
			Q.ty	Q.ty	Recommended Value (Ω)	Power (kW)			
S42	0181	1	1	5.0	48	IP23	A	4.2	50(1/0)
	0201	1	1	3.6	64	IP23	A	3.6	50(1/0)
	0218	1	1	3.6	64	IP23	A	3.6	50(1/0)
	0259	1	2	6.6	48	IP23	B	3.3	25(3)
S52	0290	1	2	6.0	48	IP23	B	3.0	35(2)
	0314	1	2	5.0	48	IP23	B	2.5	35(2)
	0368	1	2	5.0	64	IP23	B	2.5	50(1/0)
	0401	1	2	3.6	64	IP23	B	1.8	70(2/0)
S44 (2xS42)	0459	1	2	3.6	64	IP23	B	1.8	50(1)
S54 (2xS52)	0526	2	2	2.8	64	IP23	A	1.4	70(2/0)
	0600	2	4	1.4	48	IP23	C	1.4	70(2/0)
	0750	2	4	1.2	48	IP23	C	1.2	95(4/0)
	0828	2	4	3.6	64	IP23	B	0.9	50(1/0)
S56 (3xS52)	0960	2	4	3.6	64	IP23	B	0.9	50(1/0)
	1128	3	6	4.2	64	IP23	B	0.7	95(4/0)

3.3.12.5. Applications with DUTY CYCLE 50% - Class 6T

SIZE	Model	Braking Unit	Braking Resistor						
			Resistors to be used				Type of Connection	Value (Ω)	Wire Cross-section mm ² (AWG)
		Q.ty	Q.ty	Recommended Value (Ω)	Power (kW)	Degree of Protection			
S42	0181	1	4	5	32	IP23	D	5.0	25(3)
	0201	1	4	3.6	48	IP23	D	3.6	70(2/0)
	0218	1	4	3.6	48	IP23	D	3.6	70(2/0)
	0259	1	4	3.6	48	IP23	D	3.6	70(2/0)
S52	0290	1	4	2.8	64	IP23	D	2.8	70(2/0)
	0314	1	4	2.4	64	IP23	D	2.4	70(2/0)
	0368	1	4	2.4	64	IP23	D	2.4	120(250)
	0401	1	4	1.8	64	IP23	D	1.8	120(250)
S44 (2xS42)	0459	1	2	1.2	64	IP23	G	1.8	95(4/0)
S54 (2xS52)	0526	2	8	2.8	64	IP23	D	1.4	50(1/0)
	0600	2	8	2.8	64	IP23	D	1.4	50(1/0)
	0750	2	8	2.4	64	IP23	D	1.2	70(2/0)
	0828	2	8	1.8	64	IP23	D	0.9	95(4/0)
S56 (3xS52)	0960	2	12	2.8	64	IP23	E	0.93	50(1/0)
	1128	3	15	10	64	IP23	B	0.66	95(3/0)

Type of connection:

- A - One resistor per braking unit
- B - Two or more parallel-connected resistors per braking unit
- C - Two or more series-connected resistors per braking unit
- D - Four resistors per braking unit (parallel connection of two series of two resistors)
- E - Six resistors per braking unit (parallel connection of three series of two resistors)
- G - Six resistors (parallel connection of two series of three resistors) per braking unit



CAUTION

The wire cross-sections given in the table relate to one wire per braking resistor. For example, if two resistors are connected in parallel to a braking unit, the cross-section in the table is related to the cable connecting each resistor to the module. In case of a different wiring diagram, the cross-section is to be recalculated based on the RMS of the current flowing in the cable.



NOTE

If the BU600 is connected to parallel-connected inverters (2 x S44, 2 x S52 and 3 x S52), the number of BUs required and given in the table is the total number of BUs, *not* the number of BUs for each individual inverter in the parallel-connected configuration.

3.3.13. Serial Communications

3.3.13.1. General Information

The BU600 may be connected via serial link to external devices, thus enabling both reading and writing all parameters normally accessed through the display/keypad. Two-wire RS485 is used, which ensures better immunity against disturbance even on long cable paths, thus reducing communication errors.

The BU600 typically behaves as a slave device (i.e. it only answers to queries sent by another device). A master device (typically a computer) is then needed to start serial communications. This may be done directly or in a multidrop network of converters featuring a master device (see Figure 32).




Figure 32: Example of direct and multidrop connection

The BU600 is provided with a connector equipped with N.2 pins for each signal of the RS485 pair: this makes multidrop wiring easier without having to connect two conductors to the same pin and avoids adopting star topology that is not recommended for this type of bus.



Enertronica Santerno S.p.A. also supplies the RemoteDrive software package allowing controlling the drive through a computer connected via serial link. The RemoteDrive offers the following functionality: image copy, keypad emulation, oscilloscope functions and multifunction tester, data logger, history data table compiler, parameter setting and data reception–transmission–storage from and to a computer, scan function for the automatic detection of the connected inverters (up to 247 connected inverters). Please refer to the Remote Drive REMOTE CONTROL – User Manual).

3.3.13.2. Direct Connection

Electrical standard RS485 may be connected directly to the computer if this is provided with a special port of this type. In case your computer is provided with a serial port RS232-C or a USB port, a RS232-C/ RS485 converter or a USB/RS485 converter is required.

Enertronica Santerno S.p.A. may supply both converters as optional components.

Logic “1” (normally called a MARK) means that terminal TX/RX A is positive in respect to terminal TX/RX B (vice versa for logic “0”, normally called a SPACE).

3.3.13.3. Multidrop Network Connection

The BU600 may be connected to a network through electrical standard RS485, allowing a bus-type control of each device; up to 247 inverters may be interconnected depending on the link length and baud rate. Each inverter has its own identification number, which can be set in the Serial Network menu as a unique code in the network connected to the PC.

3.3.13.4. Connection

For the connection to the serial link, use the 9-pin, male D connector (see Figure 28). The D connector pins are the following.

Decisive voltage class A according to EN 61800-5-1

PIN	FUNCTION
1 – 3	(TX/RX A) Differential input/output A (bidirectional) according to standard RS485. Positive polarity in respect to pins 2 – 4 for one MARK. Signal D1 according to MODBUS-IDA association.
2 – 4	(TX/RX B) Differential input/output B (bidirectional) according to standard RS485. Negative polarity in respect to pins 1 – 3 for one MARK. Signal D0 according to MODBUS-IDA association.
5 - 7 – 8	(GND) control board zero volt. Common according to MODBUS-IDA association.
6	(VTEST) Auxiliary supply input (see Auxiliary Power Supply)
9	Not connected

The metal frame of the D connector is connected to the metal frame of the BU600, so it is grounded. Connect the cable braiding of the shielded twisted pair data cable to the ground by using the copper cable lug (see Figure 28). To avoid obtaining too high common voltage for RS485 driver of the master or the multidrop-connected devices, connect together terminals GND (if any) for all devices. This ensures equipotentiality for all signal circuits, thus providing the best operating conditions for RS485 drivers; however, if the devices are connected to each other with analog interfaces, this can create ground loops. If disturbance occurs when communication interfaces and analog interface operate at a time, use optional, galvanically isolated RS485 communications interface.

The MODBUS-IDA association (www.modbus.org) defines the type of wiring for MODBUS communications via serial link RS485, adopted by the BU600, as a “2-wire cable”. The following specifications are recommended:

Type of cable	Shielded cable composed of balanced D1/D0 pair + common conductor (“Common”)
Min. cross-section of conductors	AWG24 corresponding to 0.25mm ² . For long cable length, larger cross-sections up to 0.75mm ² are recommended.
Max. length	500 metres (based on the max. distance between two stations)
Characteristic impedance	Better if exceeding 100Ω (120Ω is typically recommended)
Standard colours	Yellow/brown for D1/D0 pair, grey for “Common” signal

The figure below shows the reference wiring diagram recommended from the MODBUS-IDA association for the connection of “2-wire” devices.




Figure 33: Recommended wiring diagram for “2-wire” MODBUS connection

Note that the network comprising the termination resistor and the polarization resistors is integrated into the inverter and can be activated via appropriate DIP-switches. Figure 33 shows the termination network in the devices at both ends of the chain. The terminator must be inserted in those devices only.



NOTE

Four-pair data transfer cables of Category 5 are normally used for serial links. Although their usage is not recommended, cables of Category 5 can be used for short cable paths. Note that the colours of such cables are different from the colours defined by MODBUS-IDA association. One pair is used for D1/D0 signals, one pair is used as a “Common” conductor, while the remaining two pairs must not be connected to any other device, or must be connected to the “Common”.



NOTE

All devices connected to the communication multidrop network should be grounded to the same conductor to minimize any difference of ground potentials between devices that can affect communication.



NOTE

The common terminal for the supply of the inverter control board is isolated from grounding. If one or multiple inverters are connected to a communication device with a grounded common (typically a computer), a low-impedance path between control boards and grounding occurs. High-frequency disturbance could come from the inverter power components and interfere with the communication device operation.

If this happens, provide the communication device with a galvanically isolated interface, type RS485/RS232.

3.3.13.5. *Line Terminators*

Provide a linear wiring (not a star wiring) for RS485 multidrop line. To do so, two pins for each line signal are provided on the inverter connector. The incoming line may be connected to pins 1 and 2, whereas the outgoing line may be connected to pins 3 and 4.

The first device in the multidrop connection will have only one outgoing line, while the last device will have only one incoming line. The line terminator is to be installed on the first device and the last device.

The first and the last device in the network feature only one outgoing line and one incoming line respectively. The line terminator is to be installed on the first device and the last device. The line terminator of the BU600 is selected via the DIP-switch SW2 on the control board by setting selectors 1 and 2 to ON.



NOTE

Communication does not take place or is adversely affected if multidrop terminators are not properly set, especially in case of high baud rate. If more than two terminators are fitted, some drivers can enter the protection mode due to thermal overload, thus stopping dialoguing with some of the connected devices.

3.3.14. Auxiliary Power Supply

The VTEST auxiliary supply pin is located on the serial port connector. The BU600 control board activates when 9VDC voltage (in respect to GND) is delivered to the VTEST input. This allows doing the following:

- 1) read and write the parameters with no need to apply DC power supply;
- 2) keep the control board “on” in case of mains loss (backup power supply).

The auxiliary supply input features are the following:

Features	Min.	Type	Max.	Unit of m.
Auxiliary supply voltage	7.5	9	12	Vdc
Absorbed current		1.1	1.8	A
“Inrush” current at power on			3	A



CAUTION

The power supply unit voltage and current delivery capacity must meet the requirements of the test supply. Lower ratings than the supply test can cause the control board failure and the irreparable loss of the user-defined parameters. On the other hand, higher ratings can cause irreparable damage to the inverter control board. Switching power supply units installed in the control board are characterized by strong “inrush” current at power on. Make sure that the power supply unit being used is capable of delivering such current ratings.

Enertronica Santerno S.p.A. provides a suitable power supply unit as an option; see ES914 Power Supply Unit Board.

3.4. Braking Unit BU1440 for Modular Inverters (BU1440 4T and BU1440 5T-6T)

A braking unit to be applied to modular inverters only is available. The inverter size must be equal to or larger than S65.

The BU1440 is an UL Open Type Equipment – degree of protection IP00 – that can be installed inside another enclosure featuring degree of protection IP3X as a minimum requirement.

Transporting, handling and unpacking the braking unit is covered in the general instructions given in the “Transport and Handling” and “Unpacking” sections in the Installation Guide.

3.4.1. Delivery Check


Make sure that the equipment is not damaged and that it complies with the equipment you ordered by referring to the nameplate located on the inverter front part (see figure below). If the equipment is damaged, contact the supplier or the insurance company concerned. If the equipment does not comply with the one you ordered, please contact the supplier as soon as possible.

If the equipment is stored before being started, make sure that temperatures range from -25°C to +70°C and that relative humidity is <95% (non-condensing).

The equipment guarantee covers any manufacturing defect. The manufacturer has no responsibility for possible damages occurred while shipping or unpacking the equipment. The manufacturer is not responsible for possible damages or faults caused by improper and irrational uses; wrong installation; improper conditions of temperature, humidity, or the use of corrosive substances. The manufacturer is not responsible for possible faults due to the equipment operation at values exceeding the equipment ratings. The manufacturer is not responsible for consequential and accidental damages.

The braking unit is covered by a 12-month guarantee starting from the date of delivery.

3.4.1.1. Nameplate for BU1440 4T



S001012

Figure 34: Nameplate for BU1440 4T

- | | | |
|----|-----------------|---|
| 1. | Model: | BU1440 – Braking module 4T or 5T-6T |
| 2. | Supply ratings: | DC supply voltage deriving directly from the inverter terminals: 400 to 800 Vdc for BU1440 4T; 800÷1200 Vdc for BU1440 5T-6T (*) |
| 3. | Output current: | 800A (average) – continuous average current in output cables
1600A (max.) – max. current in output cables (may be held for all the time given in column “Max. Duration of Continuous Operation” in the resistors tables below) |
| 4. | Min. load: | Minimum value of the resistor to be connected to the output terminals (see application tables below) |

3.4.2. Operation

Each size of the braking unit can be used with a braking resistor avoiding exceeding the max. instant current stated in its specifications.

The braking unit is controlled directly by the control unit. Braking units cannot be parallel-connected when applied to modular inverters.

3.4.3. Ratings

SIZE	Max. braking current (A)	Average braking current (A)	Inverter supply voltage	Min. braking resistor (Ω)	Dissipated power (at average braking current) (W)	Sound Pressure (dB)
BU1440-4T	1600	800	380-500Vac	0.48	1800	65
BU1440-5T	1600	800	500-600Vac	0.58	2100	65
BU1440-6T	1600	800	600-690Vac	0.69	2200	65

AUXILIARY INPUT (Fans supply)

AC Voltage	Frequency	Current consumption
230 V	50-60 Hz	1.48 Arms

3.4.4. Installing the BU1440*3.4.4.1. Environmental Requirements for the BU1440 Installation, Storage and Transport*

Maximum surrounding air temperature	-10 to +40°C with no derating From +40°C to +55°C with a 2% derating of the rated current for each degree beyond +40°C.
Ambient temperatures for storage and transport	-25°C to +70°C
Installation environment	Pollution degree 2 or better (according to EN 61800-5-1 and UL 508C Open Type Equipment). Do not install in direct sunlight and in places exposed to conductive dust, corrosive gases, vibrations, water sprinkling or dripping; do not install in salty environments.
Altitude	Max. altitude for installation 2000 m a.s.l. For installation above 2000 m and up to 4000 m, please contact Enertronica Santerno S.p.A.. Above 1000 m, derate the rated current by 1% every 100 m.
Operating ambient humidity	From 5% to 95%, from 1g/m ³ to 29g/m ³ , non-condensing and non-freezing (class 3K3 according to EN 61800-5-1).
Storage ambient humidity	From 5% to 95%, from 1g/m ³ to 29g/m ³ , non-condensing and non-freezing (class 1K3 according to EN 61800-5-1).
Ambient humidity during transport	Max. 95%, up to 60g/m ³ ; condensation may appear when the equipment is not running (class 2K3 according to EN 61800-5-1).
Storage and operating atmospheric pressure	From 86 to 106 kPa (classes 3K3 and 1K4 according to EN 61800-5-1).
Atmospheric pressure during transport	From 70 to 106 kPa (class 2K3 according to EN 61800-5-1).

**CAUTION**

Ambient conditions strongly affect the inverter life. Do not install the equipment in places that do not have the above-mentioned ambient conditions.

3.4.4.2. Mounting the Braking Unit

Install braking unit BU1440 for modular inverters in an upright position inside a cabinet, next to the other inverter modules. Its overall dimensions are the same as those of an inverter arm. For more details, please refer to the paragraph relating to the mechanical installation of the modular inverter in the Installation Guide.

Dimensions (mm)			Fixing points (mm)				Screws	Weight (kg)
W	H	D	X	Y	D1	D2		
230	1400	480	120	237	11	25	M10	110




Figure 35: Dimensions and fixing points of BU1440

3.4.4.3. *Wiring Diagram***Power connections**


The braking unit must be connected to the inverter and the braking resistor.

The connection to the inverter is direct through 60*10mm copper plates connecting the different inverter modules. The braking resistor is connected to the + bar and to the braking unit.

Also connect the single-phase 230Vac supply of the cooling fan.

Decisive voltage class C according to EN 61800-5-1

Terminal	Type	Tightening Torque (Nm)	Connection cable cross-section mm ² (AWG/kcmils)	NOTES
+	Bar	30	600 mm ²	To be connected to bus bar + of the drive
-	Bar			To be connected to bus bar – of the drive
+	Cord	30	See sections 3.4.7 and 3.4.8	To be connected to Braking Resistor
B	Cord			To be connected to Braking Resistor
61	Wire	0.6-0.8	1 mm ² (AWG18)	To be connected to 230 Vac supply
62	Wire			To be connected to 230 Vac supply




P000561-B

Figure 36: External power connections for modular inverters S65-S70 provided with BU1440



NOTE Power supply unit n.2 (power supply 2) is available for size S70.



P000560-B

Figure 37: External power connections for modular inverters S75-S80 provided with BU1440



NOTE Power supply unit n. 3 is available for size S80.

Signal connections



CAUTION

Make sure that the control device is properly set-up when using the braking arm. When ordering the inverter, always state the inverter configuration you want to obtain.

Because the braking arm is controlled directly by the control device, the following wiring is required:

- connect +24V supply of gate unit ES841 of the braking unit through a pair of unipolar wires (AWG17-18 - 1mm²)
- connect braking IGBT to the fault IGBT signal through 2 optical fibres (diameter: 1mm) made of plastic (typical attenuation coefficient: 0.22dB/m) provided with Agilent HFBR-4503/4513 connectors.

The wiring diagram is as follows:

Signal	Type of wiring	Wire marking	Component	Board	Connector	Component	Board	Connector
+24VD Driver board ES841 power supply	Unipolar wire 1mm ²	24V-GB	Phase W	ES841	MR1-3	Braking unit	ES841	MR1-1
0VD Driver board ES841 power supply	Unipolar wire 1mm ²		Phase W	ES841	MR1-4	Braking unit	ES841	MR1-2
Brake IGBT command	Single optical fibre	G-B	Control unit	ES842	OP-4	Braking unit	ES841	OP5
Brake IGBT fault	Single optical fibre	FA-B	Control unit	ES842	OP-3	Braking unit	ES841	OP3



CAUTION

Do not remove the cap of connector OP4 in ES841 control board of the the braking module.




Figure 38: ES841 Unit gate board for the braking unit

1. OP1: Green LED – Board OK
2. MR1: 24V gate unit supply
3. OP2: Red LED - Board faulty[*]
4. OP3: IGBT Fault [*]
5. OP4-OP5: IGBT gate commands. OP4 MUST BE SEALED – DO NOT CONNECT
6. CN3: MUST NOT BE CONNECTED



NOTE [*]

The “IGBT Fault” signal, if the OP2 LED remains OFF, indicates that the thermoswitch has tripped.




Figure 39: Connection points on ES842 for the braking unit optical fibres

7. OP4: Gate command for IGBT Brake
8. OP3: IGBT Fault Signal

The figure below shows the internal wiring of inverters S65-S70 provided with a braking unit.




Figure 40: Internal wiring of inverters S65-S70 provided with a braking unit

3.4.5. Earth Bonding of the BU1440

For the earth bonding of the BU1440, please refer to the general instructions given in section Inverter and Motor Ground Connection in the Installation Guide.

3.4.6. Scheduled Maintenance of the BU1440

For the BU1440 scheduled maintenance, please refer to the general instructions given in section Inverter and Motor Ground Connection in the Installation Guide.



DANGER

Once power supply has been cut off from the drive connected to the BU1440, wait at least 20 minutes before operating on the DC circuits to give the capacitors time to discharge.

3.4.7. Braking Resistors for BU1440 4T



NOTE

The wire cross-sections given in the table relate to one wire per braking resistor.



NOTE

The Part Numbers of the braking resistors in the tables are given in the Available Braking Resistors section.



HOT SURFACE

The braking resistor case may reach 200°C based on the operating cycle.



CAUTION

The cables of the braking resistors shall have insulation features and heat-resistance features suitable for the application. The minimum rated voltage of the cables must be 0.6/1kV.



CAUTION

The power dissipated by the braking resistors may be the same as the rated power of the connected motor multiplied by the braking duty-cycle; use a proper air-cooling system. Do not install braking resistors near heat-sensitive equipment or objects.



CAUTION

Do not connect to the inverter any braking resistor with an Ohm value lower than the value given in the tables.



CAUTION

Never exceed the maximum operating time of the resistor as given in the Available Braking Resistors section.

3.4.7.1. Applications with DUTY CYCLE 10% - Class 4T

SIZE	Drive Model	Braking Unit	Braking Resistor						
			Resistors to be used				Type of Connection	Value (Ω)	Wire Cross-section mm ² (AWG or kcmils)
			Q.ty	Q.ty	Recommended Value (Ω)	Power (kW)			
S65	0598	1	1	1.2	64	IP23	A	1.2	95(4/0)
	0748	1	1	1.2	64	IP23	A	1.2	95(4/0)
	0831	1	2	1.6	48	IP23	B	0.8	120(250)
S75	0964	1	2	1.2	48	IP23	B	0.6	120(250)
	1130	1	2	1.2	64	IP23	B	0.6	120(250)
	1296	2	4	1.8	32	IP23	V	0.45	95(4/0)
S90	1800	2	4	1.6	48	IP23	V	0.4	120(250)
	2076	2	4	1.2	48	IP23	V	0.3	120(250)

3.4.7.2. Applications with DUTY CYCLE 20% - Class 4T

SIZE	Drive Model	Braking Unit	Braking Resistor						
			Resistors to be used				Type of Connection	Value (Ω)	Wire Cross-section mm ² (AWG or kcmils)
			Q.ty	Q.ty	Recommended Value (Ω)	Power (kW)			
S65	0598	1	2	2.4	64	IP23	B	1.2	120(250)
	0748	1	2	2.4	64	IP23	B	1.2	120(250)
	0831	1	3	2.4	48	IP23	B	0.8	120(250)
S75	0964	1	4	2.4	64	IP23	B	0.6	120(250)
	1130	1	4	2.4	64	IP23	B	0.6	120(250)
	1296	2	4	1.8	64	IP23	V	0.45	120(250)
S90	1800	2	6	2.4	48	IP23	V	0.4	120(250)
	2076	2	8	2.4	64	IP23	V	0.3	120(250)

3.4.7.3. Applications with DUTY CYCLE 50% - Class 4T

SIZE	Drive Model	Braking Unit	Braking Resistor						
			Resistors to be used				Type of Connection	Value (Ω)	Wire Cross-section mm ² (AWG or kcmils)
		Q.ty	Q.ty	Recommended Value (Ω)	Power (kW)	Degree of Protection			
S65	0598	1	4	1.2	64	IP23	D	1.2	120(250)
	0748	1	4	1.2	64	IP23	D	1.2	120(250)
	0831	1	6	1.2	64	IP23	E	0.8	120(250)
S75	0964	1	8	1.2	64	IP23	F	0.6	120(250)
	1130	1	8	1.2	64	IP23	F	0.6	120(250)
	1296	2	12	1.4	64	IP23	ME	0.47	120(250)
S90	1800	2	12	1.2	64	IP23	ME	0.4	120(250)
	2076	2	16	1.2	64	IP23	MF	0.3	120(250)

A - One resistor

B - Two or multiple parallel-connected resistors

C - Two series-connected resistors

D - Four resistors (parallel-connection of two series of two resistors)

E - Six resistors (parallel-connection of three series of two resistors)

F - Eight resistors (parallel-connection of four series of two resistors)

V - Two units, each of them including a braking module connected to two or more parallel-connected braking resistors

ME - Two units, each of them including a braking module connected to six braking resistors (parallel-connection of three series of two resistors)

MF - Two units, each of them including a braking module connected to eight braking resistors (parallel-connection of four series of two resistors)



CAUTION

The cable cross-sections given in the table relate to the cable connecting each individual braking resistor. For example, if a braking resistor is connected to N.2 parallel-connected resistors, the cable cross-section in the table is the one for each resistor connected to the braking unit.

In case of a different wiring diagram, the cross-section is to be recalculated based on the RMS of the current flowing in the cable.

3.4.8. Braking Resistors for BU1440 5T-6T



NOTE

The wire cross-sections given in the table relate to one wire per braking resistor.



NOTE

The Part Numbers of the braking resistors in the tables are given in the Available Braking Resistors section.



HOT SURFACE

The braking resistor case may reach 200°C based on the operating cycle.



CAUTION

The cables of the braking resistors shall have insulation features and heat-resistance features suitable for the application. The minimum rated voltage of the cables must be 0.6/1kV.



CAUTION

The power dissipated by the braking resistors may be the same as the rated power of the connected motor multiplied by the braking duty-cycle; use a proper air-cooling system. Do not install braking resistors near heat-sensitive equipment or objects.



CAUTION

Do not connect to the inverter any braking resistor with an Ohm value lower than the value given in the tables.



CAUTION

Never exceed the maximum operating time of the resistor as given in the Available Braking Resistors section.

3.4.8.1. Applications with DUTY CYCLE 10% - Class 5T

SIZE	Drive Model	Braking Unit	Braking Resistor						
			Resistors to be used				Type of Connection	Value (Ω)	Wire Cross-section mm ² (AWG or kcmils)
			Q.ty	Q.ty	Recommended Value (Ω)	Power (kW)			
S65	0457	1	1	1.6	64	IP23	A	1.6	95(1/0)
	0524	1	2	2.8	48	IP23	B	1.4	50(1/0)
	0598	1	2	2.4	48	IP23	B	1.2	50(1/0)
	0748	1	2	2.1	48	IP23	B	1.05	95(4/0)
S70	0831	1	2	1.8	64	IP23	B	0.9	95(4/0)
S75	0964	1	3	2.4	48	IP23	B	0.8	50(1/0)
	1130	1	3	1.8	64	IP23	B	0.6	95(4/0)
S80	1296	1	3	1.6	64	IP23	B	0.53	95(4/0)
S90	1800	2	4	1.8	64	IP23	V	0.45	95(4/0)
	2076	2	6	2.4	48	IP23	V	0.4	50(1/0)

3.4.8.2. Applications with DUTY CYCLE 20% - Class 5T

SIZE	Drive Model	Braking Unit	Braking Resistor						
			Resistors to be used				Type of Connection	Value (Ω)	Wire Cross-section mm ² (AWG or kcmils)
			Q.ty	Q.ty	Recommended Value (Ω)	Power (kW)			
S65	0457	1	2	3.6	64	IP23	B	1.8	95(4/0)
	0524	1	3	4.2	64	IP23	B	1.4	50(1/0)
	0598	1	3	3.6	64	IP23	B	1.2	50(1/0)
	0748	1	3	2.8	64	IP23	B	0.93	70(2/0)
S70	0831	1	3	2.4	64	IP23	B	0.8	95(4/0)
S75	0964	1	4	2.8	64	IP23	B	0.7	70(2/0)
	1130	1	6	3.6	64	IP23	B	0.6	50(1/0)
S80	1296	1	6	3	64	IP23	B	0.5	70(2/0)
S90	1800	2	6	2.4	64	IP23	V	0.4	95(4/0)
	2076	2	8	2.8	64	IP23	V	0.35	70(2/0)

3.4.8.3. Applications with DUTY CYCLE 50% - Class 5T

SIZE	Drive Model	Braking Unit	Braking Resistor						
			Resistors to be used				Type of Connection	Value (Ω)	Wire Cross-section mm ² (AWG or kcmils)
			Q.ty	Q.ty	Recommended Value (Ω)	Power (kW)			
S65	0457	1	6	2.4	64	IP23	E	1.6	70(4/0)
	0524	1	6	2.1	64	IP23	E	1.4	95(4/0)
	0598	1	8	2.4	64	IP23	F	1.2	70(2/0)
	0748	1	8	1.8	64	IP23	F	0.9	95(4/0)
S70	0831	1	8	1.8	64	IP23	F	0.9	95(4/0)
S75	0964	1	10	1.8	64	IP23	G	0.7	95(4/0)
	1130	1	12	1.8	64	IP23	H	0.6	95(4/0)
S80	1296	1	14	1.8	64	IP23	I	0.51	95(4/0)
S90	1800	2	16	1.8	64	IP23	MF	0.45	95(4/0)
	2076	2	20	1.8	64	IP23	MG	0.35	95(4/0)

A - One resistor

B - Two or more parallel-connected resistors

D - Four resistors (parallel-connection of two series of two resistors)

E - Six resistors (parallel-connection of three series of two resistors)

F - Eight resistors (parallel-connection of four series of two resistors)

G - Ten resistors (parallel-connection of five series of two resistors)

H - Twelve resistors (parallel-connection of six series of two resistors)

I - Fourteen resistors (parallel-connection of seven series of two resistors)

V - Two units, each of them including a braking module connected to two or more parallel-connected braking resistors

MF - Two units, each of them including a braking module connected to eight braking resistors (parallel-connection of four series of two resistors)

MG - Two units, each of them including a braking module connected to ten braking resistors (parallel-connection of five series of two resistors)



CAUTION

The cable cross-sections given in the table relate to the cable connecting each individual braking resistor. For example, if a braking resistor is connected to N.2 parallel-connected resistors, the cable cross-section in the table is the one for each resistor connected to the braking unit.

In case of a different wiring diagram, the cross-section is to be recalculated based on the RMS of the current flowing in the cable.

3.4.8.4. Applications with DUTY CYCLE 10% - Class 6T

SIZE	Drive Model	Braking Unit	Braking Resistor						
			Resistors to be used				Type of Connection	Value (Ω)	Wire Cross-section mm ² (AWG or kcmils)
			Q.ty	Recommended Value (Ω)	Power (kW)	Degree of Protection			
S65	0457	1	2	3.6	48	IP23	B	1.8	70(2/0)
	0524	1	2	2.8	48	IP23	B	1.4	70(2/0)
	0598	1	2	2.8	48	IP23	B	1.4	70(2/0)
	0748	1	2	2.4	48	IP23	B	1.2	70(2/0)
S70	0831	1	2	1.8	64	IP23	B	0.9	120(250)
S75	0964	1	3	2.4	64	IP23	B	0.8	70(2/0)
	1130	2	4	2.4	64	IP23	V	0.6	70(2/0)
S80	1296	2	4	2.1	64	IP23	V	0.52	95(4/0)
S90	1800	2	4	1.8	64	IP23	V	0.45	120(250)
	2076	2	6	2.4	64	IP23	V	0.4	70(2/0)

3.4.8.5. Applications with DUTY CYCLE 20% - Class 6T

SIZE	Drive Model	Braking Unit	Braking Resistor						
			Resistors to be used				Type of Connection	Value (Ω)	Wire Cross-section mm ² (AWG or kcmils)
			Q.ty	Recommended Value (Ω)	Power (kW)	Degree of Protection			
S65	0457	1	3	5	64	IP23	B	1.7	50(1/0)
	0524	1	3	4.2	64	IP23	B	1.4	50(1/0)
	0598	1	3	4.2	64	IP23	B	1.4	70(2/0)
	0748	1	3	3.6	64	IP23	B	1.2	70(2/0)
S70	0831	1	4	3.6	64	IP23	B	0.9	70(2/0)
S75	0964	1	6	1.2	64	IP23	E	0.8	120(250)
	1130	2	8	1.2	64	IP23	MD	0.6	120(250)
S80	1296	2	8	1.2	64	IP23	MD	0.6	120(250)
S90	1800	2	8	3.6	64	IP23	V	0.45	70(2/0)
	2076	2	12	1.2	64	IP23	ME	0.4	120(250)

3.4.8.6. Applications with DUTY CYCLE 50% - Class 6T

Size	Drive Model	Braking Unit	Braking Resistor						
			Resistors to be used				Type of Connection	Value (Ω)	Wire Cross-section mm ² (AWG or kcmils)
			Q.ty	Recommended Value (Ω)	Power (kW)	Degree of Protection			
S65	0457	1	6	2.4	64	IP23	E	1.6	95(4/0)
	0524	1	8	2.8	64	IP23	F	1.4	70(2/0)
	0598	1	8	2.8	64	IP23	F	1.4	70(2/0)
	0748	1	8	2.4	64	IP23	F	1.2	95(4/0)
S70	0831	1	10	2.4	64	IP23	G	0.96	95(4/0)
S75	0964	1	12	2.4	64	IP23	H	0.8	70(2/0)
	1130	2	16	2.4	64	IP23	MF	0.6	95(4/0)
S80	1296	2	16	2.1	64	IP23	MF	0.52	120(250)
S90	1800	2	20	2.4	64	IP23	MG	0.48	95(4/0)
	2076	2	24	2.4	64	IP23	MH	0.4	70(2/0)

A - One resistor

B - Two or more parallel-connected resistors

D - Four resistors (parallel-connection of two series of two resistors)

E - Six resistors (parallel-connection of three series of two resistors)

F - Eight resistors (parallel-connection of four series of two resistors)

G - Ten resistors (parallel-connection of five series of two resistors)

H - Twelve resistors (parallel-connection of six series of two resistors)

V - Two units, each of them including a braking resistor connected to two or more parallel-connected braking resistors

MD - Two units, each of them including a braking module connected to four braking resistors (parallel-connection of two series of two resistors)

MF - Two units, each of them including a braking module connected to eight braking resistors (parallel-connection of four series of two resistors)

MG - Two units, each of them including a braking module connected to ten braking resistors (parallel-connection of five series of two resistors)

MH - Two units, each of them including a braking module connected to twelve braking resistors (parallel-connection of six series of two resistors)



CAUTION

The cable cross-sections given in the table relate to the cable connecting each individual braking resistor. For example, if a braking resistor is connected to N.2 parallel-connected resistors, the cable cross-section in the table is the one for each resistor connected to the braking unit. In case of a different wiring diagram, the cross-section is to be recalculated based on the RMS of the current flowing in the cable.

3.5. Available Braking Resistors

The specifications given for each resistor model also include the mean power to be dissipated and the max. operating time, depending on the inverter voltage class.

Based on these values, parameters **C211** and **C212** (concerning braking features) in the Resistor Braking menu can be set up. (See relevant section in the Programming Guide).

The max. operating time set in **C211** is factory-set in order not to exceed the allowable time for each resistor model (see section below).

Parameter **C212** represents the max. duty-cycle of the resistor and is to be set to a value lower than or equal to the value stated in the dimensioning table (see sections above).



**HOT
SURFACE**

Braking resistors may reach temperatures higher than 200°C.



**FIRE
HAZARD**

For parameters **C211** and **C212**, do not set values exceeding the max. allowable values stated in the tables above. Failure to do so will cause irreparable damage to the braking resistors; also, fire hazard exists.



CAUTION

Braking resistors may dissipate up to 50% of the rated power of the connected motor; use a proper air-cooling system. Do not install braking resistors near heat-sensitive equipment or objects.

3.5.1. 350W Models (IP55)





Figure 41: Overall dimensions, 350W resistor

Type	Weight (g)	Average Power to be Dissipated (W)	Max. Duration of Continuous Operation for 200-240Vac (s)*
56Ω/350W RE2643560	400	350	3.5
100Ω/350W RE2644100	400	350	6

(*) Max. value to be set in parameter **C211** for single resistors or parallel-connected configurations. That duration is longer for different configurations (two or more series-connected resistors). When setting the braking duty cycle in **C212**, make sure that the maximum power dissipated from the braking resistor being used is not exceeded.

3.5.2. 550W Models (IP33)



P000549-0

Figure 42: Overall dimensions for 550W braking resistor

Type	L (mm)	D (mm)	Weight (g)	Mean power to be dissipated (W)	Max. duration of continuous operation for 380-500Vac (s)*
75Ω/550W RE3063750	195	174	500	550	4

(*) Max. value to be set in parameter **C211** for single resistors or parallel-connected configurations. That duration is longer for different configurations (two or more series-connected resistors). When setting the braking duty cycle in **C212**, make sure that the maximum power dissipated from the braking resistor being used is not exceeded.

3.5.3. IP54 Models from 1100W to 2200W




Figure 43: Overall dimensions for braking resistors from 1100W to 2200W

RESISTOR	A (mm)	B (mm)	L (mm)	I (mm)	P (mm)	Weight (g)	Average power that can be dissipated (W)	Max. duration of continuous operation (s) (*)			
								at 200- 240Vac	at 380- 500Vac	at 500- 575Vac	at 660- 690Vac
15Ω/1100W RE3083150	95	30	320	80-84	240	1250	950	3	Not applicable		
20Ω/1100W RE3083200								4	Not applicable		
50Ω/1100W RE3083500								11	3	Not applicable	
180Ω/1100W RE3084180								Not limited	10	6	4
250Ω/1100W RE3084250									14	9	6
10Ω/1500W RE3093100	120	40	320	107- 112	240	2750	1100	3	Not applicable		
39Ω/1500W RE3093390								12	3	Not applicable	
50Ω/1500W RE3093500								16	4	Not applicable	
180Ω/1500W RE3094180								Not limited	14	8	6
250Ω/1500W RE3094250									20	12	8
25Ω/1800W RE3103250	120	40	380	107- 112	300	3000	1300	9	3	Not applicable	
120Ω/1800W RE3104120								Not limited	11	7	4
250Ω/1800W RE3104250									24	14	10
15Ω/2200W RE3113150	190	67	380	177- 182	300	7000	2000	8	3	Not applicable	
50Ω/2200W RE3113500								29	7	4	3
75Ω/2200W RE3113750								Not limited	11	6	4
100Ω/2200W RE3114100									14	9	6
150Ω/2200W RE3114150									22	13	9
180Ω/2200W RE3114180									26	16	11
250Ω/2200W RE3114250									36	22	15

(*) Max. value to be set in parameter **C211** for single resistors or parallel-connected configurations. That duration is longer for different configurations (two or more series-connected resistors), and “Not applicable” in the table may no longer be true. When setting the braking duty cycle in **C212**, make sure that the maximum power dissipated from the braking resistor being used is not exceeded.

3.5.4. IP20 Models from 4kW-8kW-12kW




Figure 44: Overall dimensions for braking resistors 4kW, 8kW, 12kW

RESISTOR	A (mm)	B (mm)	L (mm)	I (mm)	P (mm)	Weight (g)	Average power that can be dissipated (W)	Max. duration of continuous operation (s) (*)			
								at 200- 240Vac	at 380- 500Vac	at 500- 575Vac	at 660- 690Vac
5Ω/4kW RE3482500	620	600	100	250	40	5.5	4000	7	Not applicable		
15Ω/4kW RE3483150								21	5	Not applicable	
20Ω/4kW RE3483200								28	7	4	3
25Ω/4kW RE3483250								35	8	5	3
39Ω/4kW RE3483390								Not limited	13	8	5
50Ω/4kW RE3483500									17	11	7
60Ω/4kW RE3483600									21	13	9
82Ω/4kW RE3483820									29	18	12
100Ω/4kW RE3484100									35	22	15
120Ω/4kW RE3484120									42	26	18
150Ω/4kW RE3484150									Not limited	33	22
180Ω/4kW RE3484180										39	27
250Ω/4kW RE3484250								Not limited	Not limited	37	
3.3Ω/8kW RE3762330								620	600	160	250
5Ω/8kW RE3762500	14										
10Ω/8kW RE3763100	28	7	4	3							
45Ω/8kW RE3763450	Not limited	32	19	13							
82Ω/8kW RE3763820		Not limited	36	24							
120Ω/8kW RE3764120		Not limited	Not limited	36							
3.3Ω/12kW RE4022330	620	600	200	250	80	13.7	12000	14	Not applicable		
6.6Ω/12kW RE4022660								28	7	4	3
10Ω/12kW RE4023100								42	10	6	4
45Ω/12kW RE4023450								Not limited	48	29	20

(*) Max. value to be set in parameter **C211** for single resistors or parallel-connected configurations. That duration is longer for different configurations (two or more series-connected resistors), and “Not applicable” in the table may no longer be true. When setting the braking duty cycle in **C212**, make sure that the maximum power dissipated from the braking resistor being used is not exceeded.



CAUTION

Because the metal frame of the braking resistor can reach high temperatures, appropriate cables capable of withstanding high temperatures must be used.

3.5.5. IP23 Boxes from 4kW to 64kW




Figure 45: Overall dimensions of IP23 Box resistors




Figure 46: Position of electrical connections in box resistors

Remove the grids to gain access to wiring terminals (loosen fastening screws).



NOTE

The figure shows 20Ω/12kW resistor. In certain models, remove both panels to gain access to the wiring terminals.



CAUTION

Because the metal frame of the braking resistor can reach high temperatures, appropriate cables capable of withstanding high temperatures must be used.

3.5.5.1. Insulation Resistors, 1 kV (to be used in conjunction with 2T and 4T drives)

RESISTOR	P (mm)	P1 (mm)	P2 (mm)	L (mm)	H (mm)	Weight (kg)	Average power (W) that can be dissipated	Max. duration of continuous operation (s) (*)	
								at 200-240Vac	at 380-500Vac
30Ω/4kW RE3503300	650	530	710	320	375	23	4000	85	21
45Ω/4kW RE3503450								128	32
50Ω/4kW RE3503500								not limited	35
60Ω/4kW RE3503600									42
82Ω/4kW RE3503820									58
100Ω/4kW RE3504100									71
120Ω/4kW RE3504120									85
150Ω/4kW RE3504150									not limited
180Ω/4kW RE3504180									
15Ω/8kW RE3783150	650	530	710	380	375	30	8000	85	21
18Ω/8kW RE3783180								not limited	25
22Ω/8kW RE3783220									31
30Ω/8kW RE3783300									42
45Ω/8kW RE3783450									64
50Ω/8kW RE3783500									71
60Ω/8kW RE3783600									85
82Ω/8kW RE3783820									not limited
10Ω/12kW RE4053100									650
12Ω/12kW RE4053120	not limited	25							
15Ω/12kW RE4053150		32							
18Ω/12kW RE4053180		38							
20Ω/12kW RE4053200		42							
22Ω/12kW RE4053220		46							
30Ω/12kW RE4053300		64							
45Ω/12kW RE4053450		96							
60Ω/12kW RE4053600		not limited							

RESISTOR	P (mm)	P1 (mm)	P2 (mm)	L (mm)	H (mm)	Weight (kg)	Average power (W) that can be dissipated	Max. duration of continuous operation (s) (*)	
								at 200-240Vac	at 380-500Vac
3.6Ω/16kW RE4162360	650	530	710	550	375	40	16000	40	10
5Ω/16kW RE4162500								57	14
6.6Ω/16kW RE4162660								75	18
8.2Ω/16kW RE4162820								Not limited	23
10Ω/16kW RE4163100									28
12Ω/16kW RE4163120									34
15Ω/16kW RE4163150									42
18Ω/16kW RE4163180									51
20Ω/16kW RE4163200									57
22Ω/16kW RE4163220									62
30Ω/16kW RE4163300									85
45Ω/16kW RE4163450								Not limited	
2.4Ω/24kW RE4292240	650	530	710	750	375	50	24000	40	10
3Ω/24kW RE4292300								50	12
5Ω/24kW RE4292500								85	21
6.6Ω/24kW RE4292660								Not limited	28
8.2Ω/24kW RE4292820									34
10Ω/24kW RE4293100									42
15Ω/24kW RE4293150									64
18Ω/24kW RE4293180									76
22Ω/24kW RE4293220									93
30Ω/24kW RE4293300									Not limited

RESISTOR	P (mm)	P1 (mm)	P2 (mm)	L (mm)	H (mm)	Weight (kg)	Average power (W) that can be dissipated	Max. duration of continuous operation (s) (*)		
								at 200-240Vac	at 380-500Vac	
1.8Ω/32kW RE4362180	650	530	710	990	375	60	32000	60	16	
2.4Ω/32kW RE4362240								54	13	
2.8Ω/32kW RE4362280								63	15	
3Ω/32kW RE4362300								68	17	
3.6Ω/32kW RE4362360								82	20	
4.2Ω/32kW RE4362420								96	23	
5Ω/32kW RE4362500								114	28	
6Ω/32kW RE4362600								Not limited	34	
6.6Ω/32kW RE4362660									37	
10Ω/32kW RE4363100									56	
15Ω/32kW RE4363150									85	
18Ω/32kW RE4363180									102	
0.45Ω/48W RE4451450								650	530	710
0.6Ω/48kW RE4451600	20									
0.8Ω/48kW RE4451800	27									
1.2Ω/48kW RE4452120	40	10								
1.4Ω/48kW RE4452140	47	11								
1.6Ω/48kW RE4452160	54	13								
1.8Ω/48kW RE4452180	60	15								
2.1Ω/48kW RE4452210	71	17								
2.4Ω/48kW RE4452240	81	20								
2.8Ω/48kW RE4452280	95	23								
3Ω/48kW RE4452300	Not limited	25								
3.6Ω/48kW RE4452360		30								
4.2Ω/48kW RE4452420		35								
5Ω/48kW RE4452500		42								

RESISTOR	P (mm)	P1 (mm)	P2 (mm)	L (mm)	H (mm)	Weight (kg)	Average power (W) that can be dissipated	Max. duration of continuous operation (s) (*)	
								at 200-240Vac	at 380-500Vac
6Ω/48kW RE4452600	650	530	710	750	730	95	48000	Not limited	51
6.6Ω/48kW RE4452660									56
10Ω/48kW RE4453100									85
12Ω/48kW RE4453120									Not limited
15Ω/48kW RE4453150									
0.3Ω/64kW RE4551300	650	530	710	990	730	115	64000	13	Not applicable
0.45Ω/64W RE4551450								20	
0.6Ω/64kW RE4551600								27	
0.8Ω/64kW RE4551800								36	
1.2Ω/64kW RE4552120								54	13
1.4Ω/64kW RE4552140								63	15
1.6Ω/64kW RE4552160								72	18
1.8Ω/64kW RE4552180								81	20
2.1Ω/64kW RE4552210								95	23
2.4Ω/64kW RE4552240								109	27
2.8Ω/64kW RE4552280								Not limited	31
3Ω/64kW RE4552300									34
3.6Ω/64kW RE4552360									40
4.2Ω/64kW RE4552420									47
5Ω/64kW RE4552500									56
6Ω/64kW RE4552600									68
6.6Ω/64kW RE4552660									75
8.2Ω/64kW RE4552820									93
10Ω/64kW RE4553100									not limited

(*) Max. value to be set in parameter **C211** for single resistors or parallel-connected configurations. That duration is longer for different configurations (two or more series-connected resistors), and “Not applicable” in the table may no longer be true. When setting the braking duty cycle in **C212**, make sure that the maximum power dissipated from the braking resistor being used is not exceeded.

3.5.5.2. Insulation Resistors, 3 kV (to be used in conjunction with 5T and 6T drives)

RESISTOR	P (mm)	P1 (mm)	P2 (mm)	L (mm)	H (mm)	Wgt (kg)	Average power (W) that can be dissipated	Max. duration of continuous operation (s) (*)	
								at 500- 575Vac	at 660- 690Vac
30Ω/4kW RE3553300	650	530	710	460	375	35	4000	13	9
45Ω/4kW RE3553450								19	13
50Ω/4kW RE3553500								22	15
60Ω/4kW RE3553600								26	18
82Ω/4kW RE3553820								36	24
100Ω/4kW RE3554100								44	30
120Ω/4kW RE3554120								53	36
150Ω/4kW RE3554150								66	45
180Ω/4kW RE3554180								79	54
15Ω/8kW RE3793150								650	530
18Ω/8kW RE3793180	15	10							
22Ω/8kW RE3793220	19	13							
30Ω/8kW RE3793300	26	18							
45Ω/8kW RE3793450	39	27							
50Ω/8kW RE3793500	44	30							
60Ω/8kW RE3793600	53	36							
82Ω/8kW RE3793820	72	49							
10Ω/12kW RE4063100	650	530	710	550	375	40	12000	13	9
12Ω/12kW RE4063120								15	10
15Ω/12kW RE4063150								19	13
18Ω/12kW RE4063180								23	16
20Ω/12kW RE4063200								26	18
22Ω/12kW RE4063220								29	19
30Ω/12kW RE4063300								39	27
45Ω/12kW RE4063450								59	40
60Ω/12kW RE4063600								79	54

RESISTOR	P (mm)	P1 (mm)	P2 (mm)	L (mm)	H (mm)	Wgt (kg)	Average power (W) that can be dissipated	Max. duration of continuous operation (s) (*)	
								at 500- 575Vac	at 660- 690Vac
6.6Ω/16kW RE4172660	650	530	710	650	375	45	16000	11	not applicable
8.2Ω/16kW RE4172820								14	9
10Ω/16kW RE4173100								18	12
12Ω/16kW RE4173120								21	14
15Ω/16kW RE4173150								27	18
18Ω/16kW RE4173180								31	21
20Ω/16kW RE4173200								35	24
22Ω/16kW RE4173220								39	26
30Ω/16kW RE4173300								53	36
45Ω/16kW RE4173450								79	54
5Ω/24kW RE4302500	650	530	710	850	375	55	24000	13	9
6.6Ω/24kW RE4302660								17	11
8.2Ω/24kW RE4302820								21	14
10Ω/24kW RE4303100								27	18
15Ω/24kW RE4303150								40	27
18Ω/24kW RE4303180								47	32
22Ω/24kW RE4303220								58	39
30Ω/24kW RE4303300								79	54

RESISTOR	P (mm)	P1 (mm)	P2 (mm)	L (mm)	H (mm)	Wgt (kg)	Average power (W) that can be dissipated (W)	Max. duration of continuous operation (s) (*)	
								at 500-575Vac	at 660-690Vac
3Ω/32kW RE4372300	650	530	710	650	730	78	32000	10	Not applicable
3.6Ω/32kW RE4372360								12	
4.2Ω/32kW RE4372420								14	10
5Ω/32kW RE4372500								17	12
6Ω/32kW RE4372600								21	14
6.6Ω/32kW RE4372660								23	15
10Ω/32kW RE4373100								35	24
15Ω/32kW RE4373150								53	36
18Ω/32kW RE4373180								63	43
1.8Ω/48kW RE4462180								650	530
2.1Ω/48kW RE4462210	11								
2.4Ω/48kW RE4462240	12								
2.8Ω/48kW RE4462280	14	10							
3Ω/48kW RE4462300	16	10							
3.6Ω/48kW RE4462360	19	13							
4.2Ω/48kW RE4462420	22	15							
5Ω/48kW RE4462500	26	18							
6Ω/48kW RE4462600	31	21							
6.6Ω/48kW RE4462660	35	23							
10Ω/48kW RE4463100	53	36							
12Ω/48kW RE4463120	63	43							
15Ω/48kW RE4463150	79	54							

RESISTOR	P (mm)	P1 (mm)	P2 (mm)	L (mm)	H (mm)	Wgt (kg)	Average power (W) that can be dissipated (W)	Max. duration of continuous operation (s) (*)	
								at 500-575Vac	at 660-690Vac
1.4Ω/64kW RE4562140	650	530	710	750	1085	130	64000	10	Not applicable
1.6Ω/64kW RE4562160								11	
1.8Ω/64kW RE4562180								12	10
2.1Ω/64kW RE4562210								14	10
2.4Ω/64kW RE4562240								17	11
2.8Ω/64kW RE4562280								19	13
3Ω/64kW RE4562300								21	14
3.6Ω/64kW RE4562360								25	17
4.2Ω/64kW RE4562420								29	20
5Ω/64kW RE4562500								35	24
6Ω/64kW RE4562600								42	29
6.6Ω/64kW RE4562660								46	31
8.2Ω/64kW RE4562820								58	39
10Ω/64kW RE4563100								70	48

(*) Max. value to be set in parameter **C211** for single resistors or parallel-connected configurations. That duration is longer for different configurations (two or more series-connected resistors), and “Not applicable” in the table may no longer be true.

When setting the braking duty cycle in **C212**, make sure that the maximum power dissipated from the braking resistor being used is not exceeded.

4. NEMA 1 GLANDKIT


Product-Accessory Compatibility		
Product	NEMA 1 GLANDKIT	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	√	
Solardrive Plus	√	

Table 5: Product – NEMA 1 GLANDKIT compatibility

In accordance with **UL 508C**, the SINUS PENTA may be provided with the special “NEMA 1 Glandkit” UL Category Number NMMS by Enertronica Santerno S.p.A. against accidental contacts. This optional kit installed directly on SINUS PENTA drives with UL Open Type degree of protection, provides IP21/UL Type 1 degree of protection. The definitions of UL Type 1 / NEMA 1 degree of protection are given by NEMA and UL standards.

Enclosure Rating	National Electrical Manufacturers Association (NEMA Standard 250)	Underwriters Laboratories, Inc. (UL 50 and UL 508C)
NEMA 1/ UL Type 1	Indoor use to provide a degree of protection to personnel against access to hazardous parts and to provide a degree of protection of the equipment inside the enclosure against ingress of solid foreign objects (falling dirt).	Indoor use to provide a degree of protection to personnel against incidental contact with the enclosed equipment and to provide a degree of protection against falling dirt

4.1.1. Nameplate NEMA 1 GLANDKIT



S001011

Figure 47: Typical nameplate for SINUS PENTA NEMA KIT accessory

The UL-approved kit is given in the tables below for models from S05 to S52:

4.2. Identification Data

4.2.1. 2T-4T Voltage Classes

Inverter Frame Size	Part Number
S05	ZZ0102805
S12	ZZ0124812
S15	ZZ0102815
S20	ZZ0102820
S30	ZZ0102830
S41	ZZ1124907
S51	ZZ0124850

4.2.2. 5T-6T Voltage Classes

Inverter Frame Size	Part Number
S12	ZZ0124812
S14	ZZ0102810
S22	ZZ0124822
S32	ZZ0124832
S42	ZZ1124907
S52	ZZ0124850



CAUTION

The installer is responsible for the utilization of safe materials able to preserve the equipment degree of protection. It is recommended that the cables do not enter into contact with sharp metal parts that may compromise isolation.




Figure 48: Example of a NEMA 1 Kit installed on a SINUS PENTA

4.2.3. Overall Dimensions when Installing an Inverter with the NEMA 1 Glandkit

4.2.3.1. 2T-4T Voltage Classes

Inverter Frame Size	Kit Dimensions (mm)			Inverter + Kit Overall Height [mm]	Kit Weight (kg)
	W	H	D	H	
S05	149	71	43	402	0.4
S12	179	74	56	460	0.4
S15	169	74	71	525	0.5
S20	275	98	104	659	0.9
S30	296	131	117	809	1.0
S41	504	295	186	1098	5.6
S51	579	295	186	1098	6.2

4.2.3.1. 5T-6T Voltage Classes

Inverter Frame Size	Kit Dimensions (mm)			Inverter + Kit Overall Height [mm]	Kit Weight (kg)
	W	H	D	H	
S12	179	74	56	460	0.4
S14	235	74	56	588	0.5
S22	232	99	95	873	0.7
S32	322	130	142	940	1.3
S42	504	295	186	1187	5.6
S52	579	295	186	1187	6.2



NOTE

The W and D dimensions of the inverter are not affected. See relevant tables provided on the **Installation Guide**.

5. KEYPAD REMOTING KIT

Product-Accessory Compatibility		
Product	Keypad remoting kit	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	√	
Solardrive Plus	√	

Table 6: Product – Keypad remoting kit compatibility

5.1. Remoting the Keypad on the Cabinet

The inverter keypad may be remoted. A special kit is supplied, which includes the following:

- plastic frame allowing installing the keypad on the front wall of the cabinet,
- keypad jig allowing installing the keypad on the front door of the cabinet,
- seal between keypad frame and cabinet,
- remoting cable (length: 5 m).

If the kit supplied is properly assembled, degree of protection IP54 is obtained for the front panel in the cabinet.

For any details on how to remote the keypad, please refer to the Operating and Remoting the Keypad in the Installation Guide.

DESCRIPTION	PART NUMBER
SINUS PENTA kit remote keypad, 3mt	ZZ0095699
SINUS PENTA kit remote keypad, 5mt	ZZ0095700

6. INDUCTORS

Product-Accessory Compatibility		
Product	Inductors	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	√	The DC inductors may be installed only on S05 2T and S12 2T/4T
Solardrive Plus	√	AC input inductors and DC inductors – only if a power supply source other than the PV field is envisaged

Table 7: Product – Inductors compatibility




Figure 49: Wiring diagram for optional inductors

6.1. Input Inductors

We suggest that a three-phase inductor, or a DC-BUS DC inductor, be installed on the supply line to obtain the following benefits:

- limit input current peaks on the input circuit of the inverter and value di/dt due to the input rectifier and to the capacitive load of the capacitors set;
- reducing supply harmonic current;
- increasing power factor, thus reducing line current;
- increasing the duration of line capacitors inside the inverter.

Harmonic currents

The shapes of the different waves (current or voltage) may be expressed as the sum of the basic frequency (50 or 60Hz) and its multiples. In balanced, three-phase systems, only odd harmonic current exists, as even current is neutralized by symmetrical considerations.

Harmonic current is generated by non-linear loads absorbing non-sinusoidal current. Typical sources of this type are bridge rectifiers (power electronics), switching power supply units and fluorescent lamps. Three-phase rectifiers absorb line current with a harmonic content

$n=6K\pm 1$ with $K=1,2,3,\dots$ (e.g. 5th,7th,11th,13th,17th,19th, etc.). Harmonic current amplitude decreases when frequency increases. Harmonic current carries no active power; it is additional current carried by electrical cables. Typical effects are: conductor overload, power factor decrease and measurement systems instability. Voltage generated by current flowing in the transformer inductor may also damage other appliances or interfere with mains-synchronized switching equipment.



Solving the problem

Harmonic current amplitude decreases when frequency increases; as a result, reducing high-amplitude components determines the filtering of low-frequency components. The better way is to increase low-frequency impedance by installing an inductor. Power drive systems with no mains-side inductor generate larger harmonic currents than power drives which do have an inductor.

The inductor may be installed both on AC-side, as a 3-phase inductor on the supply line, and on DC-side, as a single-phase inductor installed between the rectifier bridge and the capacitor bank inside the inverter. Even greater benefits are obtained if an inductor is installed both on AC-side and on DC-side.

Unlike DC inductors, AC inductors filter high-frequency components as well as low-frequency components with greater efficiency.



CAUTION

A DC inductor can be connected to inverters sizes S15, S20, S30. This must be specified when ordering the equipment (see the Power Terminals Modified for a DC Inductor in the Installation Guide).



CAUTION

No DC inductor can be installed in S05(4T) inverters.



CAUTION

When a DC inductor is used, it can happen that no braking resistor can be connected when an external braking unit is connected, and vice versa (see the Power Terminals Modified for a DC Inductor in the Installation Guide).

Harmonic currents in the inverter power supply

The amplitude of harmonic currents and their incidence on the mains voltage is strongly affected by the features of the mains where the equipment is installed. The ratings given in this manual fit most applications. For special requirements, please contact Enertronica Santerno's Customer service.




Figure 50: Amplitude of harmonic currents (approximate values)

Use the input inductor under the following circumstances:



CAUTION

- mains instability;
- converters installed for DC motors;
- loads generating strong voltage variations at startup;
- power factor correction systems.

Use the input inductor under the following circumstances:



CAUTION

- when drives up to size S12 included are connected to grids with a short-circuit power greater than 500kVA;
- with drives from size S15 to size S60P when the short-circuit power is 20 fold the inverter power;
- when using parallel-connected inverters;
- with Penta drives size S65 or greater, unless the inverter is powered via a dedicated transformer featuring $V_{dc}=5\%$ or greater;
- with modular inverters provided with multiple power supply units (sizes S70, S75, S80 and S90).

The ratings of optional inductor recommended based on the inverter model are detailed in the section below.

6.2. Output Inductors (DU/DT Filters)

Installations requiring cable lengths over 100m between the inverter and the motor may cause overcurrent protections to frequently trip. This is due to the wire parasite capacity generating current pulses at the inverter output; those current pulses are generated from the high du/dt ratio of the inverter output voltage. The current pulses may be limited by an inductor installed on the inverter output. Shielded cables even have a higher capacity and may cause problems with shorter cable lengths.

The maximum distance between the motor and the inverter is given as an example, as parasite capacity is also affected by the type of wiring path and wiring system. For instance, when several inverters and their connected motors are networked, segregating the inverter wires from the motor wires will avoid capacitive couplings between the wiring of each motor.

An adverse effect can also be the stress produced on the motor insulation due to the high du/dt ratio at the inverter output.



CAUTION

Using du/dt filters is always recommended when the motor cable length is over 100m (50m with shielded cables). It is recommended that Sine Filters be used (see Sine Filters) for lengths exceeding 300m (150m with shielded cables).



NOTE

When using parallel-connected motors, always consider the total length of the cables being used (sum of the cable length of each motor).



CAUTION

The output inductor is always required when using modular inverters and parallel-connected inverters.



CAUTION

The inductors stated in the tables below may be used when the inverter output frequency is not over 120Hz. For higher output frequency, a special inductor for the max. allowable operating frequency must be used. Please contact Enertronica Santerno S.p.A..




Figure 51: Output inductor wiring

6.3. Applying the Inductor to the Inverter



NOTE IP54 rated 3-phase inductors are available for inverters up to S32 included, because basically inductors are IP00 rated.

6.3.1. Class 2T – AC and DC Inductors

SIZE	Drive MODEL	INPUT AC 3-PHASE INDUCTOR	DC INDUCTOR MODEL	THREE-PHASE OUTPUT AC INDUCTOR	MAX. OUTPUT FREQ. (Hz)
S05	0007	IM0126044 1.27mH–17Arms	IM0140104 5.1mH–17A/21Apeak	IM0126044 1.27mH–17Arms	60
	0008				
	0010				
	0013	IM0126084 0.7mH–32Arms	IM0140154 2.8mH–32.5A/40.5Apeak	IM0126084 0.7mH–32Arms (3-phase)	60
	0015				
	0016				
	0020				
S12	0023	IM0126124 0.51mH–45Arms	IM0140204 2.0mH–47A/58.5Apeak	IM0126124 0.51mH–45Arms	60
	0033	IM0126144 0.3mH–68Arms	IM0140254 1.2mH–69A/87Apeak	IM0126144 0.32mH–68Arms	60
	0037				
S15	0040	IM0126164 0.24mH–92Arms	IM0140284 (*) 0.96mH–100A/160Apeak	IM0126164 0.24mH–92Arms	60
	0049				
S20	0060	IM0126204 0.16mH–145Arms	IM0140304 (*) 0.64mH–160A/195Apeak	IM0126204 0.16mH–145Arms	60
	0067				
	0074				
	0086				
S30	0113	IM0126244 0.09mH–252Arms	IM0140404 (*) 0.36mH–275A/345Apeak	IM0126244 0.09mH–252Arms	60
	0129				
	0150				
	0162				
S41	0180	IM0126282 (**) 0.063mH–360Arms	IM0140454 0.18mH–420A/520Apeak	IM0138200 0.070mH–360Arms	120
	0202	IM0126332 (**) 0.05 mH–455Arms	IM0140604 0.14mH–520A/650Apeak	IM0138250 0.035mH–445Arms	120
	0217				
	0260				
S51	0313	IM0126372 0.031mH–720Arms	IM0140664 0.09mH–830A/1040Apeak	IM0138300 0.025mH–700Arms	120
	0367				
	0402				
S60	0457	IM0126404 0.023mH–945Arms	IM0140754 0.092mH– 1040A/1300Apeak	IM0126404 0.023mH–945Arms	60
	0524				



CAUTION (*)

For the inverter sizes S15, S20, S30, the DC inductors required are to be specified when ordering the equipment as they involve hardware modifications.



CAUTION ()**

Use the inductors described in section Inductors to be Applied to the Drive and the SU465 for 12-pulse power supply.

6.3.2. Class 4T – AC and DC Inductors

SIZE	Drive Model	INPUT AC 3-PHASE INDUCTOR	DC INDUCTOR MODEL	OUTPUT 3-PHASE AC INDUCTOR	MAX. OUTPUT FREQ. (Hz)
S05	0005	IM0126004 2.0mH–11Arms	Non applicabile	IM0126004 2.0mH–11Arms	60
	0007	IM0126044 1.27mH–17Arms		IM0126044 1.27mH–17Arms	60
	0009				
	0011				
	0014				
S12	0016	IM0126084 0.7mH–32Arms	IM0140154 2.8mH–32.5A	IM0126084 0.7mH–32Arms	60
	0017				
	0020				
	0025	IM0126124 0.51mH–45Arms	IM0140204 2.0mH–47A	IM0126124 0.51mH–45Arms	60
	0030	IM0126144 0.3mH–68Arms	IM0140254 1.2mH–69A	IM0126144 0.3mH–68Arms	60
	S15	0040	IM0126164 0.24mH–92Arms	IM0140284 (*) 0.96mH–100A	IM0126164 0.24mH–92Arms
0049					
S20	0060	IM0126204 0.16mH–145Arms	IM0140304 (*) 0.64mH–160A	IM0126204 0.16mH–145Arms	60
	0067				
	0074				
	0086				
S30	0113	IM0126244 0.09mH–252Arms	IM0140404 (*) 0.36mH–275A	IM0126244 0.09mH–252Arms	60
	0129				
	0150				
	0162				
S41	0180	IM0126282 (**) 0.063mH–360Arms	IM0140454 0.18mH–420A	IM0138200 0.070mH–360Arms	120
	0202	IM0126332 (**) 0.05 mH–455Arms	IM0140604 0.14mH–520A	IM0138250 0.035mH–445Arms	120
	0217	IM0126372 (**) 0.031mH–720Arms	IM0140664 0.09mH–830A	IM0138300 0.025mH–700Arms	120
	0260				
S51	0313	IM0126404 0.023mH–945Arms	IM0140754 0.092mH–1040A	IM0126404 0.023mH–945Arms	60
	0367				
S60	0457	IM0126444 0.018mH–1260Arms	IM0140854 (*) 0.072mH–1470A	IM0126444 0.018mH–1260Arms	60
	0524				
S60P	0598P				
S65	0598	IM0126444 0.018mH–1260Arms	IM0140854 (*) 0.072mH–1470A	IM0126444 0.018mH–1260Arms	60
	0748				
	0831				
S75	0964	2 x IM0126404 0.023mH–945A	2 x IM0140754 (*) 0.092mH–1040A	6 x IM0141782 0.015mH–1250Arms (single-phase)	60
	1130	2 x IM0126444 0.018mH–1260A	2 x IM0140854 (*) 0.072mH–1470A		
	1296	3 x IM0126404 0.023mH–945Arms	3 x IM0140754 (*) 0.092mH–1040A		
S90	1800	3 x IM0126444 0.018mH–1260Arms	3 x IM0140854 (*) 0.072mH–1470A	9 x IM0141782 0.015mH–1250Arms (single-phase)	60
	2076				



CAUTION (*)

For the inverter sizes S15, S20, S30 and modular inverters from S65 to S90, the DC inductors required are to be specified when ordering the equipment as they involve hardware modifications.



CAUTION ()**

Use the inductors described in section Inductors to be Applied to the Drive and the SU465 for 12-pulse power supply.

6.3.3. Class 5T-6T – AC and DC Inductors

SIZE	Drive Model	INPUT AC 3-PHASE INDUCTOR	DC INDUCTOR MODEL	THREE-PHASE OUTPUT AC INDUCTOR	MAX. OUTPUT FREQ. (Hz)							
S12 5T S14 6T	0003	IM0127042 6.4mH–6.5Arms	Please contact Enertronica Santerno S.p.A.	IM0138000 1.9mH–9.3Arms	120							
	0004	IM0127062		IM0138010 1.4mH–13.4Arms	120							
	0006	4.1mH–10.5Arms			IM0138020 1.0mH–17.5Arms	120						
	0012	IM0127082				IM0138030 0.70mH–25.6Arms	120					
	0018	2.6mH–16Arms					IM0138040 0.42mH–41Arms	120				
S14	0019	IM0127102			IM0138045 0.28mH–62Arms	120						
	0021	1.8mH–23Arms		IM0138050 0.17mH–105Arms (3-phase)	120							
	0022	IM0127122			IM0141404 1.2mH–110A	120						
	0024	1.1mH–40Arms				IM0138100 0.11mH–165Arms (3-phase)	120					
	0032	IM0127142					IM0138150 0.075mH–240Arms (3-phase)	120				
0042	0.7mH–57Arms	IM0138200 0.070mH –360Arms (3-phase)	120									
S22	0051	IM0127167 0.43mH–95Arms	IM0141424 0.66mH–240A	IM0138250 0.035mH –440Arms (3-phase)	120							
	0062					IM0127202 0.29mH–140Arms	IM0141434 0.32mH–375A	120				
	0069								IM0127227 0.19mH–210Arms	IM0141554 0.27mH–475A	120	
S32	0076	IM0127330 (**) 0.096mH–415Arms	IM0141664 0.17mH–750A	IM0138300 0.025mH–700Arms (3-phase)	120							
	0088					IM0127274 (**) 0.12mH–325A	IM0141804 (*) 0.160mH–1170A	IM0127404 0.040mH–945Arms (3-phase)				60
	0131											
	0164								2 x IM0127364 0.058mH–662Arms	2 x IM0141704 (*) 0.232mH–830A	60	
S42	0181	IM0127350 (**) 0.061mH–650Arms	2 x IM0141804 (*) 0.160mH–1170A	6 x IM0141782 0.015mH–1250Arms (single-phase)	60							
	0201					IM0127404 0.040mH–945Arms	3 x IM0141804 (*) 0.160mH–1170A	9 x IM0141782 0.015mH–1250Arms (single-phase)	60			
	0218									IM0127444 0.030mH–1260Arms	3 x IM0141904 (*) 0.120mH–1290A	60
	0259											
S52	0290	IM0127444 0.030mH–1260Arms	3 x IM0141904 (*) 0.120mH–1290A	60								
	0314				2 x IM0127404 0.040mH–945Arms	3 x IM0141804 (*) 0.160mH–1170A	60					
	0368							2 x IM0127444 0.030mH–1260Arms	3 x IM0141904 (*) 0.120mH–1290A	60		
	0401										2 x IM0127404 0.040mH–945Arms	3 x IM0141804 (*) 0.160mH–1170A
S65	0457	IM0127404 0.040mH–945Arms	3 x IM0141804 (*) 0.160mH–1170A	60								
	0524				2 x IM0127404 0.040mH–945Arms	3 x IM0141804 (*) 0.160mH–1170A	60					
	0598							2 x IM0127444 0.030mH–1260Arms	3 x IM0141904 (*) 0.120mH–1290A	60		
	0748										2 x IM0127364 0.058mH–662Arms	2 x IM0141704 (*) 0.232mH–830A
S70	0831	2 x IM0127404 0.040mH–945Arms	2 x IM0141804 (*) 0.160mH–1170A	60								
	S75				0964	2 x IM0127444 0.030mH–1260Arms	3 x IM0141804 (*) 0.160mH–1170A	60				
S80		1130	3 x IM0127404 0.040mH–945Arms	3 x IM0141904 (*) 0.120mH–1290A	60							
	S90	1296				3 x IM0127404 0.040mH–945Arms	3 x IM0141804 (*) 0.160mH–1170A	60				
S90		1800	3 x IM0127444 0.030mH–1260Arms	3 x IM0141904 (*) 0.120mH–1290A	60							
	S90	2076				3 x IM0127444 0.030mH–1260Arms	3 x IM0141904 (*) 0.120mH–1290A	60				



CAUTION (*)

For the modular inverters from S65 to S90, the DC inductors required are to be specified when ordering the equipment as they involve hardware modifications.



CAUTION ()**

Use the inductors described in section Inductors to be Applied to the Drive and the SU465 for 12-pulse power supply.


6.4. Inductance Ratings

6.4.1. Class 2T-4T – AC 3-Phase Inductors

INDUCTOR MODEL	TYPE	INDUCTANCE RATINGS		DIMENSIONS							FIXING HOLES	WGT	LOSSES
		mH	A	TYPE	L	H	P	M	E	G	mm	kg	W
IM0126004	Input-output	2.00	11	A	120	125	75	25	67	55	5	2.9	29
IM0126044	Input-output	1.27	17	A	120	125	75	25	67	55	5	3	48
IM0126084	Input-output	0.70	32	B	150	130	115	50	125	75	7x14	5.5	70
IM0126124	Input-output	0.51	45	B	150	130	115	50	125	75	7x14	6	105
IM0126144	Input-output	0.30	68	B	180	160	150	60	150	82	7x14	9	150
IM0126164	Input-output	0.24	92	B	180	160	150	60	150	82	7x14	9.5	183
IM0126204	Input-output	0.16	145	B	240	210	175	80	200	107	7x14	17	280
IM0126244	Input-output	0.090	252	B	240	210	220	80	200	122	7x14	25	342
IM0126282	Input only	0.063	360	C	300	286	205	100	250	116	9x24	44	350
IM0126332	Input only	0.050	455	C	300	317	217	100	250	128	9x24	54	410
IM0126372	Input only	0.031	720	C	360	342	268	120	325	176	9x24	84	700
IM0126404	Input-output	0.023	945	C	300	320	240	100	250	143	9x24	67	752
IM0126444	Input-output	0.018	1260	C	360	375	280	120	250	200	12	82	1070

6.4.2. Class 5T-6T – AC 3-Phase Inductors

INDUCTOR MODEL	INPUT/OUTPUT	INDUCTANCE RATINGS		DIMENSIONS							FIXING HOLES	WGT	LOSSES
		mH	A	TYPE	L	H	P	M	E	G	mm	kg	W
IM0127042	Input only	6.4	6.5	A	150	170	101	-	90	70	7x10	3	22
IM0127062	Input only	4.1	10.5	A	180	173	110	-	150	73	8.5x15	4.5	28
IM0127082	Input only	2.6	16	A	180	173	120	-	150	83	8.5x15	6.5	45
IM0127102	Input only	1.8	23	A	180	173	130	-	150	93	8.5x15	9	52
IM0127122	Input only	1.1	40	A	240	228	140	-	200	80	8x15	14	96
IM0127142	Input only	0.70	57	A	240	228	175	-	200	115	8x15	19	122
IM0127167	Input only	0.43	95	B	240	224	187	80	200	122	7x18	27	160
IM0127202	Input only	0.29	140	B	300	254	190	100	250	113	9x24	35	240
IM0127227	Input only	0.19	210	B	300	285	218	100	250	128	9x24	48	260
IM0127274	Input only	0.12	325	C	300	286	234	100	250	143	9x24	60	490
IM0127330	Input only	0.096	415	C	360	340	250	120	325	166	9x24	80	610
IM0127364	Input-output	0.058	662	C	360	310	275	120	325	166	9x24	79	746
IM0127350	Input only	0.061	650	C	360	411	298	120	240	220	9x24	113	920
IM0127404	Input-output	0.040	945	C	360	385	260	120	250	200	12	88	1193
IM0127444	Input-output	0.030	1260	C	420	440	290	140	300	200	12	110	1438



P000539-B


Figure 52: Mechanical features of a 3-phase inductor

6.4.3. Class 2T-4T – DC Inductors

INDUCTOR MODEL	USE	INDUCTANCE RATINGS		DIMENSIONS							FIXING HOLE	WEIGHT	LOSSES
		mH	A	TYPE	L	H	P	M	E	G			
IM0140054	DC BUS	8.0	10.5	A	110	125	100	60	90	65	7x10	4.5	20
IM0140104	DC BUS	5.1	17	A	110	125	100	60	90	65	7x10	5	30
IM0140154	DC BUS	2.8	32.5	A	120	140	160	60	100	100	7x10	8	50
IM0140204	DC BUS	2.0	47	A	160	240	160	80	120	97	7x14	12	80
IM0140254	DC BUS	1.2	69	A	160	240	160	80	120	97	7x14	13	90
IM0140284	DC BUS	0.96	100	A	170	240	205	80	155	122	7x18	21	140
IM0140304	DC BUS	0.64	160	A	240	260	200	120	150	121	9x24	27	180
IM0140404	DC BUS	0.36	275	A	260	290	200	130	150	138	9x24	35	320
IM0140454	DC BUS	0.18	420	B	240	380	220	120	205	156	9x24	49	290
IM0140604	DC BUS	0.14	520	B	240	380	235	120	205	159	9x24	57	305
IM0140664	DC BUS	0.090	830	B	260	395	270	130	225	172	9x24	75	450
IM0140754	DC BUS	0.092	1040	C	310	470	320	155	200	200	12	114	780
IM0140854	DC BUS	0.072	1470	C	330	540	320	165	250	200	12	152	950

6.4.4. Class 5T-6T – DC Inductors

INDUCTOR MODEL	USE	INDUCTANCE RATINGS		DIMENSIONS							FIXING HOLE	WEIGHT	LOSSES
		mH	A	TYPE	L	H	P	M	E	G			
IM0141404	DC BUS	1.2	110	A	170	205	205	80	155	122	7x18	21	165
IM0141414	DC BUS	0.80	160	A	200	260	215	100	150	111	9x24	27	240
IM0141424	DC BUS	0.66	240	A	240	340	260	120	205	166	9x24	53	370
IM0141434	DC BUS	0.32	375	B	240	380	235	120	205	159	9x24	56	350
IM0141554	DC BUS	0.27	475	B	240	380	265	120	205	179	9x24	66	550
IM0141664	DC BUS	0.17	750	B	260	395	295	130	225	197	9x24	90	580
IM0141704	DC BUS	0.232	830	C	330	550	340	165	250	200	12	163	800
IM0141804	DC BUS	0.16	1170	C	350	630	360	175	250	200	12	230	1200
IM0141904	DC BUS	0.12	1290	C	350	630	360	175	250	200	12	230	1300




P000978-B

Figure 53: Mechanical features of a DC inductor

6.4.5. Class 2T, 4T, 5T, 6T – 3-Phase DU/DT Inductors

INDUCTOR MODEL	USE	INDUCTANCE RATINGS		TYPE	DIMENSIONS						FIXING HOLE mm	WGT kg	LOSSES W
		mH	A		L	H	P	M	E	G			
IM0138000	Output only	1.9	9.3	A	180	180	110	-	150	75	8.5x15	6	55
IM0138010	Output only	1.4	13.4	A	180	180	120	-	150	85	8.5x15	8	75
IM0138020	Output only	1.0	17.5	A	180	180	120	-	150	85	8.5x15	9	85
IM0138030	Output only	0.70	25.6	A	180	180	130	-	150	95	8.5x15	10	120
IM0138040	Output only	0.42	41	A	240	230	140	-	200	100	8x15	12	180
IM0138045	Output only	0.28	62	A	240	230	175	80	200	115	8x15	15	235
IM0138050	Output only	0.17	105	A	300	259	192	100	250	123	9x24	39	270
IM0138100	Output only	0.11	165	A	300	258	198	100	250	123	9x24	42	305
IM0138150	Output only	0.075	240	A	300	321	208	100	250	123	9x24	52	410
IM0138200	Output only	0.070	360	B	360	401	269	120	250	200	12x25	77	650
IM0138250	Output only	0.035	445	B	360	401	268	120	250	200	12x25	75	720
IM0138300	Output only	0.025	700	B	360	411	279	120	250	200	12x25	93	875



P000979-B

Figure 54: Mechanical features of the 3-phase du/dt inductors

6.5. Class 2T – 3-Phase AC Inductors in IP54 Cabinet

SIZE	Drive Model	INDUCTOR MODEL	USE	MECHANICAL DIMENSIONS (see Figure 56)	WEIGHT	LOSSES
				TYPE	kg	W
S05	0007	ZZ0112020	Input-output	A	7	48
	0008					
	0010					
	0015	ZZ0112030	Input-output	A	9.5	70
	0016					
0020						
S12	0023	ZZ0112040	Input-output	A	10	96
	0033	ZZ0112045	Input-output	B	14	150
	0037					
S15	0040	ZZ0112050	Input-output	B	14.5	183
	0049					
S20	0060	ZZ0112060	Input-output	C	26	272
	0067					
	0074					
	0086					
S30	0113	ZZ0112070	Input-output	C	32.5	342
	0129					
	0150					
	0162					

6.6. Class 4T – 3-Phase AC Inductors in IP54 Cabinet

SIZE	Drive Model	INDUCTOR MODEL	USE	MECHANICAL DIMENSIONS (see Figure 56)	WEIGHT	LOSSES
				TYPE	kg	W
S05	0005	ZZ0112010	Input-output	A	6.5	29
	0007	ZZ0112020	Input-output	A	7	48
	0009					
	0011					
	0014					
S12	0016	ZZ0112030	Input-output	A	9.5	70
	0017					
	0020					
	0025	ZZ0112040	Input-output	A	10	96
	0030					
	0034	ZZ0112045	Input-output	B	14	150
0036						
S15	0040	ZZ0112050	Input-output	B	14.5	183
	0049					
S20	0060	ZZ0112060	Input-output	C	26	272
	0067					
	0074					
	0086					
S30	0113	ZZ0112070	Input-output	C	32.5	342
	0129					
	0150					
	0162					




Figure 55: Mechanical features of three-phase inductors for Class 2T-4T in IP54 cabinet

6.7. Class 5T-6T – 3-Phase AC Inductors In IP54 Cabinet

SIZE	Drive Model	INDUCTOR MODEL	USE	MECHANICAL DIMENSIONS (see Figure 56)	WEIGHT	LOSSES
				TYPE	kg	W
S12 5T S14 6T	0003	ZZ0112110	Input only	A	Contact Enertronica Santerno S.p.A.	
	0004	ZZ0112120	Input only	A		
	0006					
	0012	ZZ0112130	Input only	A		
0018						
S14	0019	ZZ0112140	Input only	A		
	0021					
	0022	ZZ0112150	Input only	B		
	0024					
S22	0032	ZZ0112160	Input only	B		
	0042	ZZ0112170	Input only	B		
	0051					
	0062					
S32	0069	ZZ0112180	Input only	C		
	0076					
	0088	ZZ0112190	Input only	C		
	0131					
	0164					

SIZE	Drive Model	INDUCTOR MODEL	USE	MECHANICAL DIMENSIONS (see Figure 56)	WEIGHT	LOSSES
				TYPE	kg	W
S12 5T S14 6T	0003	ZZ0112115	Output only	A	Contact Enertronica Santerno S.p.A.	
	0004					
	0006	ZZ0112125	Output only	A		
	0012					
0018	ZZ0112135	Output only	A			
S14	0019	ZZ0112145	Output only	A		
	0021					
	0022	ZZ0112155	Output only	B		
	0024					
S22	0032	ZZ0112165	Output only	B		
	0042	ZZ0112175	Output only	B		
	0051					
	0062					
S32	0069	ZZ0112185	Output only	C		
	0076					
	0088	ZZ0112195	Output only	C		
	0131					
	0164					





Figure 56: Mechanical features of a 3-phase inductor for Class 5T-6T in IP54 cabinet

6.8. Output Single-Phase Inductors for Modular Inverters S75, S80, S90

6.8.1. AC single-phase Inductors – Class 4T-5T-6T

INDUCTOR MODEL	USE	INDUCTOR RATINGS		DIMENSIONS							FIXING HOLE	WEIGHT	LOSSES
		mH	A	L	H	P	P1	M	E	G	mm	kg	W
IM0141782	Output S75, S80, S90	0.015	1250	260	430	385	310	136	200	270	9x24	100	940



P000980-B

Figure 57: Mechanical features of a single-phase output inductor

6.9. Sine Filters

The sine filter is a system component to be installed between the inverter and the motor to enhance the equipment performance:

- The sine filter reduces the voltage peak in the motor terminals:** The overvoltage in the motor terminals may reach 100% under certain load conditions.
- The sine filter reduces the motor losses.**
- The sine filter reduces the motor noise:** The motor noise can be reduced of approx. 8 dBA because the high-frequency component of the current flowing in the motor and the cables is reduced. A noiseless motor is particularly suitable for residential environments.
- The sine filter reduces the probability of EMC disturbance:** When the cables between the inverter and the motor are too long, the square-wave voltage produced by the inverter is a source of electromagnetic disturbance.
- The sine filter allows controlling transformers:** "Normal" transformers can be powered directly from the inverter that do not need to be properly dimensioned to withstand the carrier frequency voltage.
- The inverter can be used as a **voltage generator at constant voltage and constant frequency.**




Figure 58: Sine filter

It is recommended that sine filters manufactured by Enertronica Santerno S.p.A. be used.

See the Sine Filters – User Manual.

Please contact Enertronica Santerno S.p.A. if sine filters from other manufacturers are used, as it may be necessary to change the drive parameterization.

The sine filters may be damaged if the drive parameters are not set accordingly.



CAUTION

6.10. Output Toroidal Filters

Output toroidal filters are high-permeable ferromagnetic materials used to weaken cable disturbance.

See the “EMC” section in the **Installation Guide**.

See the section related to the cross-sections of the power cables and sizes of the protective devices in the **Installation Guide**.

Part Number	TOROIDAL FILTER MODEL	Inverter Model	Cable Cross-section (mm ²)
AC1810402	2xL0674-X830	0003-0021	2.5-6
AC1810503	3xL0082-X830	0022-0034	10-16
AC1810603	3xL0040-X830	0036-0086	25-50
AC1811004	4xL0084-X830	0088-0164	70-150
AC1811202	2xL0705-X830	0180-0202	185-240
AC1811202	2xL0705-X830	0216-0368	2x120-2x185
AC1811402	2xA0711-X830	0401-0402	2x240

- If the connections table shows only one set of three cables (or N. 1 three-pole cable), the three cables shall go through the ferrite.
- In case of N. 2 sets of three cables (or N. 2 three-pole cables) both cable sets may go through the ferrite, or one ferrite may be mounted on each cable set.
- Where N. 3 sets of three cables are required, one ferrite shall be mounted on each individual cable set.

Examples:

Sinus Penta 0180 S41 4T: the recommended motor cable cross-section is 185 mm² ⇒ the cable set shall go through one ferrite, P/N AC1811202.

Sinus Penta 0260 S41 4T: the recommended motor cable cross-section is 2x120 mm² ⇒ both cable sets can either go through one ferrite, P/N AC1811202, or they can go through a separate ferrite, P/N AC1811004.

Sinus Penta 0524 S60 4T: the recommended motor cable cross-section is 3x185 mm² ⇒ each of the three cable sets shall go through a separate ferrite, P/N AC1811202.




Figure 59: Output toroidal filter

7. ES836/2 ENCODER BOARD (SLOT A)

Product-Accessory Compatibility		
Product	ES836/2 Encoder Board	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	-	
Solardrive Plus	-	

Table 8: Product – ES836/2 Encoder board compatibility

Board for incremental, bidirectional encoder to be used as a speed feedback for inverters of the Sinus Penta and Penta Marine series.

It allows the acquisition of encoders with power supply ranging from 5 to 15VDC (adjustable output voltage) with complementary outputs (line driver, push-pull, TTL outputs). It can also be connected to 24VDC encoders with both complementary and single-ended push-pull or PNP/NPN outputs.

The encoder board is to be installed into SLOT A. See section Installing ES836/2 Encoder Board on the Inverter (Slot A).




Figure 60: Encoder board (ES836/2)

7.1. Identification Data

Description	Part Number	COMPATIBLE ENCODERS	
		POWER SUPPLY	OUTPUT
ES836/2 Encoder board	ZZ0095834	5Vdc÷15Vdc, 24Vdc	LINE DRIVER, NPN, PNP, complementary PUSH-PULL, NPN, PNP, single-ended PUSH-PULL

7.2. Environmental Requirements

Operating temperature	-10 to +55°C ambient temperature (contact Enertronica Santerno S.p.A. for higher ambient temperatures)
Relative humidity	5 to 95% (non-condensing)
Max. operating altitude	2000 m a.s.l. For installation above 2000 m and up to 4000 m, please contact Enertronica Santerno S.p.A.

7.3. Electrical Specifications

Decisive voltage class A according to EN 61800-5-1.

<i>Electrical Specifications</i>	<i>Ratings</i>			
	<i>Min.</i>	<i>Type</i>	<i>Max.</i>	<i>Unit</i>
Encoder supply current, + 24 V, protected with resettable fuse			200	mA
Electronically protected encoder supply current, +12V			350	mA
Electronically protected encoder supply current, +5V			900	mA
Adjustment range for encoder supply voltage (5V mode)	4.4	5.0	7.3	V
Adjustment range for encoder supply voltage (12V mode)	10.3	12.0	17.3	V
Input channels	Three channels: A, B, and zero notch Z			
Type of input signals	Complementary or single-ended			
Voltage range for encoder input signals	4		24	V
Pulse max. frequency with noise filter "on"	77kHz (1024pls @ 4500rpm)			
Pulse max. frequency with noise filter "off"	155kHz (1024pls @ 9000rpm)			
Input impedance in NPN or PNP mode (external pull-up or pull-down resistors required)		15k		Ω
Input impedance in push-pull or PNP and NPN mode when internal load resistors (at max. frequency) are connected		3600		Ω
Input impedance in line-driver mode or complementary push-pull signals with internal load resistors activated via SW3 (at max. frequency) (see Configuration DIP-switches)		780		Ω

ISOLATION:

The encoder supply line and inputs are galvanically isolated from the inverter control board grounding for a 500 VAC/1-minute test. The encoder supply grounding is in common with control board digital inputs available in the terminal board.

7.4. Installing ES836/2 Encoder Board on the Inverter (Slot A)



DANGER

Before gaining access to the components inside the inverter, remove voltage from the inverter and wait at least 20 minutes. Wait for a complete discharge of the internal capacitors to avoid any electric shock hazard.



CAUTION

Electric shock hazard: do not connect/disconnect the signal terminals or the power terminals when the inverter is on. This also prevents the inverter from being damaged.



NOTE

All the screws used to fasten removable parts (terminals cover, serial interface connector, cable plates, etc.) are black, round-head, cross-head screws. When wiring the inverter, remove only this type of screws. If different screws or bolts are removed, the inverter warranty will be no longer valid.

1. Remove voltage from the inverter and wait at least 20 minutes.
2. Remove the cover to gain access to the inverter control terminals. The fixing spacers and the signal connector are located on the left.




Figure 61: Position of slot A for the installation of the encoder board

3. Fit the encoder board and make sure that all contacts enter the relevant housing in the signal connector. Fasten the encoder board to the fixing spacers using the screws supplied.
4. Configure the DIP-switches and the jumper located on the encoder board based on the connected encoder. Check that the supply voltage delivered to the terminal output is correct.
5. Close the inverter frame by reassembling the cover allowing gaining access to the inverter control terminals.




Figure 62: Encoder board fastened to its slot

7.5. Terminals in Encoder Board

A 9-pole terminal board is located on the front side of the encoder board for the connection to the encoder.

Terminal board specifications

Cable cross-section fitting the terminal mm ² (AWG)	Tightening torque (Nm)
0.2÷2.5mm ² (AWG 24-14)	0.5-0.6


Decisive voltage class A according to EN 61800-5-1

Terminal board, pitch 3.81 mm in two separate extractable sections (6-pole and 3-pole sections)		
Terminal	Signal	Type and Features
1	CHA	Encoder input channel A true polarity
2	$\overline{\text{CHA}}$	Encoder input channel A inverse polarity
3	CHB	Encoder input channel B true polarity
4	$\overline{\text{CHB}}$	Encoder input channel B inverse polarity
5	CHZ	Encoder input channel Z (zero notch) true polarity
6	$\overline{\text{CHZ}}$	Encoder input channel Z (zero notch) inverse polarity
7	+VE	Encoder supply output 5V...15V or 24V
8	GNDE	Encoder supply ground
9	GNDE	Encoder supply ground

For the encoder connection to the encoder board, see wiring diagrams on the following pages.

7.6. Configuration DIP-switches

Encoder board ES836/2 is provided with two DIP-switch banks to be set up depending on the type of connected encoder. The DIP-switches are located in the front left corner of the encoder board and are adjusted as shown in the figure below.



P000589-B

Figure 63: Positions of DIP-switches and their factory-setting

DIP-switch functionality and factory-settings are detailed in the table below.

Switch (factory- setting)	OFF - open	ON - closed
SW2.1	Channel B, NPN or PNP	Channel B, Line driver or Push-Pull (default)
SW2.2	Channel B with complementary signals (default)	Channel B with only one single-ended signal
SW2.3	Channel B with no band limit	Channel B with band limit (default)
SW2.4	Channel Z, NPN or PNP	Channel Z, Line driver or Push-Pull (default)
SW2.5	Channel Z with complementary signals (default)	Channel Z with only one single-ended signal
SW2.6	Channel Z with no band limit	Channel Z with band limit (default)
SW1.1	12V Supply voltage (J1 in pos. 2-3)	5V Supply Voltage (J1 in pos. 2-3) (default)
SW1.2	Channel A, NPN or PNP	Channel A, Line driver or Push-Pull (default)
SW1.3	Channel A with complementary signals (default)	Channel A with only one single-ended signal
SW1.4	Channel A with no band limit	Channel A with band limit (default)
SW3.1	Load resistors disabled	Load resistors towards ground enabled for all encoder signals (required for 5V Line driver or Push-pull encoders, especially if long cables are used – default setting)
SW3.2		
SW3.3		
SW3.4		
SW3.5		
SW3.6		



CAUTION

Keep SW3 contacts “ON” only if a complementary Push-pull or Line-driver encoder is used (power supply: 5V or 12V). Otherwise, set contacts to OFF.



NOTE

Put ALL contacts in DIP-switch SW3 to ON or OFF. Different configurations may cause the malfunctioning of the encoder board.

7.7. Jumper Selecting the Type of Encoder Supply

Two-position jumper J1 installed on encoder board ES836/2 allows setting the encoder supply voltage. It is factory-set to pos. 2-3. Set jumper J1 to position 1-2 to select non-tuned, 24V encoder supply voltage. Set jumper J1 to position 2-3 to select tuned, 5/12V encoder supply voltage. Supply values of 5V or 12V are to be set through DIP-switch SW1.1 (see table above).

7.8. Adjusting Trimmer

Trimmer RV1 installed on ES836/2 allows adjusting the encoder supply voltage. This can compensate voltage drops in case of long distance between the encoder and the encoder board, or allows feeding an encoder with intermediate voltage values if compared to factory-set values.

Tuning procedure:

1. Put a tester on the encoder supply connector (encoder side of the connecting cable); make sure that the encoder is powered.
2. Rotate the trimmer clockwise to increase supply voltage. The trimmer is factory set to deliver 5V and 12V (depending on the DIP-switch selection) to the power supply terminals. For a power supply of 5V, supply may range from 4.4V to 7.3V; for a power supply of 12V, supply may range from 10.3V to 17.3V.



NOTE

Output voltage cannot be adjusted by trimmer RV1 (jumper J1 in pos. 1-2) for 24V power supply.



CAUTION

Power supply values exceeding the encoder ratings may damage the encoder. Always use a tester to check voltage delivered from ES836 board before wiring.



CAUTION

Do not use the encoder supply output to power other devices. Failure to do so would increase the hazard of control interference and short-circuits with possible uncontrolled motor operation due to the lack of feedback.



CAUTION

The encoder supply output is isolated from the common terminal of the analog signals incoming to the terminals of the control board (CMA). Do not link the two common terminals together.

7.9. Encoder Wiring and Configuration

The figures below show how to connect and configure the DIP-switches for the most popular encoder types.



CAUTION

A wrong encoder-board connection may damage both the encoder and the board.



NOTE

In all the figures below, DIP-switches SW1.4, SW2.3, SW2.6 are set to ON, i.e. 77 kHz band limit is on. If a connected encoder requires a higher output frequency, set DIP-switches to OFF.



NOTE

The max. length of the encoder wire depends on the encoder outputs, not on the encoder board (ES836). Please refer to the encoder ratings.




NOTE

DIP-switch SW1.1 is not shown in the figures below because its setting depends on the supply voltage required by the encoder. Refer to the DIP-switch setting table to set SW1.1.



NOTE

Zero notch connection is optional and is required only for particular software applications. However, for those applications that do not require any zero notch, its connection does not affect the inverter operation. See the Programming Guide for details.




P000590-B

Figure 64: LINE DRIVER or PUSH-PULL encoder with complementary outputs



CAUTION

Put SW3 contacts to ON only if a complementary Push-pull or Line driver encoder is used (power supply: 5V or 12V). If a 24V push-pull encoder is used, put contacts to OFF.



P000591-B

Figure 65: PUSH-PULL encoder with single-ended outputs




CAUTION

Because settings required for a single-ended encoder deliver a reference voltage to terminals 2, 4, 6, the latter are not to be connected. Failures will occur if terminals 2, 4, 6 are connected to encoder conductors or to other conductors.



NOTE

Only push-pull, single-ended encoders may be used, with an output voltage equal to the supply voltage. Only differential encoders may be connected if their output voltage is lower than the supply voltage.



P000592-B

Figure 66: PNP or NPN encoder with single-ended outputs and external load resistors



NOTE

NPN or PNP encoder outputs require a pull-up or pull-down resistive load to the supply or to the common. As load resistor ratings are defined by the manufacturer of the encoder, external wiring is required, as shown in the figure above. Connect the resistor common to the supply line for NPN encoders supply or to the common for PNP encoders.




Figure 67: PNP or NPN encoder with single-ended outputs and internal load resistors



NOTE

Incorporated load resistors may be used only if NPN or PNP encoders are compatible with pull-up or pull-down external resistors (4.7kΩ).



NOTE

NPN or PNP encoders cause pulse distortions due to a difference in ramp up and ramp down edges. Distortion depends on the load resistor ratings and the wire stray capacitance. PNP or NPN encoders should not be used for applications with an encoder output frequency exceeding a few kHz dozens. For such applications, use encoders with Push-Pull outputs, or better with a differential line-driver output.

7.10. Wiring the Encoder Cable

Use a shielded cable to connect the encoder to its control board; shielding should be grounded to both ends of the cable. Use the special clamp to fasten the encoder wire and ground the cable shielding to the inverter.




Figure 68: Wiring the encoder cable

Do not stretch the encoder wire along with the motor supply cable.

Connect the encoder directly to the inverter using a cable with no intermediate devices, such as terminals or return connectors.

Use a model of encoder suitable for your application (as for connection length and max. rev number).

Preferably use encoder models with complementary LINE-DRIVER or PUSH-PULL outputs. Non-complementary PUSH-PULL, PNP or NPN open-collector outputs offer a lower immunity to noise.

The encoder electrical noise occurs as difficult speed adjustment or uneven operation of the inverter; in the worst cases, it can lead to the inverter stop due to overcurrent conditions.

8. ES913 LINE DRIVER ENCODER BOARD (SLOT A)

Product-Accessory Compatibility		
Product	ES913 Encoder Board	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	-	
Solardrive Plus	-	

Table 9: Product – ES913 Encoder board compatibility

Board for incremental, bidirectional encoder to be used as a speed feedback for inverters of the Sinus Penta and Penta Marine series.

It allows the acquisition of encoders with power supply ranging from 5 to 24VDC (adjustable output voltage) with line driver outputs.

The encoder board is to be installed into SLOT A. See Installing the Line Driver Board on the Inverter (Slot A).

P001034-B




Figure 69: ES913 Encoder board

8.1. Identification Data

	Part Number	COMPATIBLE ENCODERS	
		POWER SUPPLY	OUTPUT
HTL Encoder board	ZZ0095837	5Vdc-24Vdc	LINE DRIVER

8.2. Environmental Requirements

Operating temperature	-10 to +55°C ambient temperature (contact Enertronica Santerno S.p.A. for higher ambient temperatures)
Relative humidity	5 to 95% (non-condensing)
Max. operating altitude	2000 m a.s.l. For installation above 2000 m and up to 4000 m, please contact Enertronica Santerno S.p.A..

8.3. Electrical Specifications**Decisive voltage class A according to EN 61800-5-1**

<i>Electrical Specifications</i>	<i>Value</i>			
	<i>Min.</i>	<i>Typ.</i>	<i>Max.</i>	<i>Unit</i>
Encoder supply current, + 24 V, protected with resettable fuse			200	mA
Electronically protected encoder supply current, +12V			400	mA
Electronically protected encoder supply current, +5V			1000	mA
Adjustment range for encoder supply voltage (5V mode)	4.4	5.0	7.3	V
Adjustment range for encoder supply voltage (12V mode)	10.4	12.0	17.3	V
Input channels	Three channels: A, B and zero notch Z			
Type of input signals	Complementary (line driver)			
Voltage range for encoder input signals	4		30	V
Pulse max. frequency with noise filter "On"	77kHz (1024pls @ 4500rpm)			
Pulse max. frequency with noise filter "Off"	155kHz (1024pls @ 9000rpm)			

ISOLATION:

The encoder supply line and inputs are galvanically isolated from the inverter control board grounding for a 500VAC test voltage for 1 minute. The encoder supply grounding is in common with control board digital inputs available in the terminal board.

8.4. Installing the Line Driver Board on the Inverter (Slot A)



DANGER

Before gaining access to the components inside the inverter, remove voltage from the inverter and wait at least 20 minutes. Wait for a complete discharge of the internal capacitors to avoid any electric shock hazard.



CAUTION

Electric shock hazard: do not connect/disconnect the signal terminals or the power terminals when the inverter is on. This also prevents the inverter from being damaged.



NOTE

All the screws used to fasten removable parts (terminals cover, serial interface connector, cable plates, etc.) are black, round-head, cross-head screws. When wiring the inverter, remove only this type of screws. If different screws or bolts are removed, the inverter warranty will be no longer valid.

- 1) Remove voltage from the inverter and wait at least 20 minutes.
- 2) Remove the cover allowing gaining access to the inverter control terminals. The fixing spacers and the signal connector are located on the left.




Figure 70: Position of slot A for the installation of the encoder board

Fit the encoder board and make sure that all contacts enter the relevant housing in the signal connector. Fasten the encoder board to the fixing spacers using the screws supplied.

- 4) Configure the DIP-switches and the jumper located on the encoder board based on the connected encoder. Check that the supply voltage delivered to the terminal output is correct.
- 5) Power on the inverter and set up parameters relating to the encoder feedback (see the Programming Guide).




Figure 71: Encoder board fastened to its slot

8.5. Terminals in the Line Driver Encoder Board

A 9-pole terminal board is located on the front side of the encoder board for the connection to the encoder.

Terminal board specifications

Cable cross-section fitting the terminal mm ² (AWG)	Tightening torque (Nm)
0.2÷2.5mm ² (AWG 24-14)	0.5-0.6

Decisive voltage class A according to EN 61800-5-1

Terminal board, pitch 3.81mm in two separate extractable sections (6-pole and 3-pole sections)		
Terminal	Signal	Type and Features
1	CHA	Encoder input channel A true polarity
2	$\overline{\text{CHA}}$	Encoder input channel A inverse polarity
3	CHB	Encoder input channel B true polarity
4	$\overline{\text{CHB}}$	Encoder input channel B inverse polarity
5	CHZ	Encoder input channel Z (zero notch) true polarity
6	$\overline{\text{CHZ}}$	Encoder input channel Z (zero notch) inverse polarity
7	+VE	Encoder supply output 5V...15V or 24V
8	GNDE	Encoder supply ground
9	GNDE	Encoder supply ground

For the encoder connection to the encoder board, see wiring diagrams on the following pages.

8.6. Configuration DIP-switches

The encoder board (ES913) is provided with two DIP-switch banks. The DIP-switches are located in the front left corner of the board and are adjusted as shown in the figure below.




Figure 72: Location of the configuration DIP-switches

DIP-switch functionality and factory-settings are detailed in the table below.

SW1.1	SW1.2	
OFF	OFF	Channel A band limit disabled
OFF	ON	Min. channel A band limit
ON	OFF	Average channel A band limit
ON	ON	Max. channel A band limit (default)

SW1.3	SW1.4	
OFF	OFF	Channel B band limit disabled
OFF	ON	Min. channel B band limit
ON	OFF	Average channel B band limit
ON	ON	Max. channel B band limit (default)

SW1.5	SW1.6	
OFF	OFF	Channel Z band limit disabled
OFF	ON	Min. channel Z band limit
ON	OFF	Average channel Z band limit
ON	ON	Max. channel Z band limit (default)

SW2.1	OFF	Termination resistor between A and A# = 13.6kΩ (default)
	ON	Termination resistor between A and A# = 110Ω (only for input signals at 5V)
SW2.2	OFF	Termination resistor between B and B # = 13.6kΩ (default)
	ON	Termination resistor between B and B # = 110Ω (only for input signals at 5V)
SW2.3	OFF	Termination resistor between Z and Z# = 13.6kΩ (default)
	ON	Termination resistor between Z and Z# = 110Ω (only for input signals at 5V)
SW2.4	OFF	Termination capacitor between A and A# off
	ON	Termination capacitor between A and A# = 110pF (default)
SW2.5	OFF	Termination capacitor between B and B# off
	ON	Termination capacitor between B and B# = 110pF (default)
SW2.6	OFF	Termination capacitor between Z and Z# off
	ON	Termination capacitor between Z and Z# = 110pF (default)



CAUTION Do not select any termination resistor equal to 110Ω for encoder signal amplitude over 7.5V.

8.7. Encoder Supply Selection Jumper

Jumpers J1 and J2 select the encoder voltage supply among +5V, +12V, +24V:

Jumper J1	Jumper J2	Encoder Supply Voltage
X	2-3	+24V
Open	1-2	+12V
Closed (default)	1-2 (default)	+5V




Figure 73: Location of the jumpers selecting the encoder supply voltage

8.8. Adjusting Trimmer

Trimmer RV1 located on ES913 board allows adjusting the encoder supply voltage. This can compensate voltage drops in case of long distance between the encoder and the encoder board, or allows feeding an encoder with intermediate voltage values if compared to factory-set values.

Tuning procedure:

1. Put a tester on the encoder supply connector (encoder side of the connecting cable); make sure that the encoder is powered.
2. Rotate the trimmer clockwise to increase supply voltage. The trimmer is factory set to deliver 5V and 12V (depending on the DIP-switch selection) to the power supply terminals. For a power supply of 5V, supply may range from 4.4V to 7.3V; for a power supply of 12V, supply may range from 10.4V to 17.3V.



NOTE

The output voltage cannot be adjusted by trimmer RV1 (jumper J1 in pos. 1-2) for 24V power supply.



CAUTION

Power supply values exceeding the encoder ratings may damage the encoder. Always use a tester to check voltage delivered from the ES913 board before wiring.



CAUTION

Do not use the encoder supply output to power other devices. Failure to do so will increase the hazard of control interference and short-circuits with possible uncontrolled motor operation due to the lack of feedback.



CAUTION

The encoder supply output is isolated from the common terminal of the analog signals incoming to the terminals of the control board (CMA). Do not link the two common terminals together.

9. ES860 SIN/COS ENCODER BOARD (SLOT A)

Product-Accessory Compatibility		
Product	ES860 Encoder Board	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	-	
Solardrive Plus	-	

Table 10: Product – ES860 Encoder board compatibility

The ES860 Sin/Cos Encoder board allows interfacing encoders provided with 1Volt peak-to-peak analog outputs. Those encoders may be used to provide speed feedback and/or position feedback for Santerno drives.



NOTE

Please refer to the Programming Guide and the Guide to the Synchronous Motor Application for the available control algorithms.

The ES860 board may be configured to operate in two acquisition modes as follows:

- **Three-channel mode:** increments low speed resolution and is suitable for slow rotation speed actuators requiring very accurate measurement of speed and position.
- **Five-channel mode:** detects the absolute mechanical position as soon as the inverter is first started up.

The board features are given below:

- Acquisition of five 1Volt peak-to-peak analog inputs on balanced line
- Two channels acquired via zero crossing and bidirectional digital counter with quadrature direction discriminator and x4 resolution multiplication factor (e.g. 1024 ppr to 4096 ppr)
- Zero index control for accurate alignment
- Two channels acquired in analog mode for absolute angle detection (12-bit resolution)
- Max. 140kHz input frequency in zero crossing channels for speeds up to 800rpm with 1024 ppr; alternatively up to 2000rpm with 4096 ppr
- Maximum 1kHz input frequency in analog channels
- Ability to re-direct analog signals to zero crossing channels
- Galvanic isolation in all channels for both digital and analog inputs
- 5V and 12V power supply output allowing fine tuning of the output voltage, isolated from the common for power supply output and signal output of the inverter.




Figure 74: ES860 Sin/Cos Encoder board

9.1. Identification Data

Description	Part Number	COMPATIBLE ENCODERS	
		POWER SUPPLY	OUTPUT
ES860 Encoder SIN/COS Interface	ZZ0101830	5V, 12V, 15V, (5÷15V)	Sin/Cos encoder, 1Vpp, on three or five differential channels

9.2. Installing ES860 Board on the Inverter (Slot A)

1. Remove voltage from the inverter and wait at least 20 minutes.
2. The electronic components in the inverter and the communications board are sensitive to electrostatic discharge. Take any safety measure before operating inside the inverter and before handling the board. The board should be installed in a workstation equipped with proper grounding and provided with an antistatic surface. If this is not possible, the installer must wear a ground bracelet properly connected to the PE conductor.



3. Remove the protective cover of the inverter terminal board by unscrewing the two screws on the front lower part of the cover. Slot A where the ES860 board will be installed is now accessible, as shown in the figure below.




Figure 75: Location of Slot A inside the drive terminal board covers

4. Insert ES860 board into Slot A. Carefully align the contact pins with the two connectors in the slot. If the board is properly installed, the three fixing holes are aligned with the housing of the relevant fixing spacers screws. Check if alignment is correct, then fasten the three fixing screws as show in the figure below.




Figure 76: Fitting the ES860 board inside the drive

5. Set the correct encoder power supply and the DIP-switch configuration.
6. Power the inverter and check if the supply voltage delivered to the encoder is appropriate. Set up the parameters relating to "Encoder A" as described in the Programming Guide.
7. Remove voltage from the inverter, wait until the inverter has come to a complete stop and connect the encoder cable.



DANGER

Before gaining access to the components inside the inverter, remove voltage from the inverter and wait at least 20 minutes. Wait for the complete discharge of the internal capacitors to avoid electric shock hazard.



CAUTION

Do not connect or disconnect signal terminals or power terminals when the inverter is powered to avoid electric shock hazard and to avoid damaging the inverter.



NOTE

All fastening screws for removable parts (terminal cover, serial interface connector, cable path plates, etc.) are black, rounded-head, cross-headed screws.

Only these screws may be removed when connecting the equipment. Removing different screws or bolts will void the product guarantee.

9.2.1. Sin/Cos Encoder Connector

High density D-sub 15-pin female connector (three rows). The figure shows a front view of the pin layout.




Figure 77: Pin layout on the high density connector

Decisive voltage class A according to EN 61800-5-1

No.	Name	Description
1	C-	Negative sine signal (absolute position)
2	D-	Negative cosine signal (absolute position)
3	A-	Negative sine signal
4	B-	Negative cosine signal
5	n.c.	
6	C+	Positive sine signal (absolute position)
7	D+	Positive cosine signal (absolute position)
8	A+	Positive sine signal
9	B+	Positive cosine signal
10	n.c.	
11	n.c.	
12	+VE	Encoder power output
13	0VE	Common for power supply and signals
14	R-	Negative zero index signal acquired with zero crossing
15	R+	Zero index signal acquired with zero crossing
Shell	PE	Connector shield connected to Inverter PE conductor

9.3. ES860 Configuration and Operating Modes

The ES860 Encoder Interface Board may power both 5V and 12V encoders and allows acquiring two types of encoders with 1Volt peak-to-peak sinusoidal outputs:

Three-channel mode: signals A (sine), B (cosine), R (zero index).

Input signals C+, C-, D+, D- are not used in three-channel mode. DIP-switch SW1 is to be set as in the figure below: odd-numbered switches to ON and the even-numbered switches to OFF.




Figure 78: DIP-switch SW1 setting in three-channel mode

Five-channel mode: signals A (sine), B (cosine), R (zero index), C (sine, absolute position), D (cosine, absolute position).

All input signals are used in five-channel mode. DIP-switch SW1 shall be set as in the figure below: even-numbered switches to ON, odd-numbered switches to OFF.




Figure 79: DIP-switch SW1 setting for five-channel mode



CAUTION

Do not alter the DIP-switch configuration and do not enable the configuration switches when the inverter is powered. Unexpected changes in switch settings, even of short duration, cause irreparable damage to the board and the encoder.

9.3.1. Configuring and Adjusting the Encoder Supply Voltage

The ES860 board may power encoders having different power supply voltage ratings. A selection Jumper and a power supply voltage regulation Trimmer are available, as shown in the figure below.




Figure 80: Position of the jumper and voltage adjusting trimmer

The ES860 board is factory-set with a minimum output voltage of 4.5V for the power supply of 5V rated encoders. Take account of $\pm 10\%$ due to voltage drops in cables and connector contactors. By using the trimmer, 8V voltage may be supplied.

Set the jumper to 12V to supply 12V or 15V encoders. It is now possible to operate on the trimmer to adjust voltage from 10.5 to 15.7V. Turn the trimmer clockwise to increase output voltage.

Power supply voltage is to be measured at the encoder supply terminals, thus taking account of cable voltage drops, particularly if a long cable is used.



CAUTION

Supplying the encoder with inadequate voltage may damage the component. Before connecting the cable and after configuring ES860 board, always use a tester to check the voltage supplied by the board itself.



NOTE

The encoder power supply circuit is provided with an electronic current limiter and a resettable fuse. Should a short-circuit occur in the supply output, shut down the inverter and wait a few minutes to give the resettable fuse time to reset.

9.4. Connecting the Encoder Cable

State-of-the-art connections are imperative. Use shielded cables and correctly connect cable shielding. The recommended connection diagram consists in a multipolar, dual shielded cable. The inner shield shall be connected to the connector case connected to the ES860 board, while the outer shield shall be connected to the encoder frame, usually in common with the motor frame. If the inner shield is not connected to the encoder frame, this can be connected to the inner braid. The motor must always be earthed as instructed with a dedicated conductor connected directly to the inverter earthing point and routed parallel to the motor power supply cables. It is not advisable to route the Encoder cable parallel to the motor power cables. It is preferable to use a dedicated signal cable conduit. The figure below illustrates the recommended connection method.




Figure 81: Recommended dual shielded connection for encoder cable



NOTE

The encoder supply output and the encoder signal common are isolated in respect to the common of the analog signals fitted in the inverter terminal board (CMA). Do not connect any conductors in common between the encoder signals and the signals in the inverter terminal board. This prevents isolation from being adversely affected.



CAUTION

The connector of the ES860 board shall be connected exclusively to the encoder using one single cable.

Correctly fasten the cable and the connectors both on the encoder side and on ES860 board side. The disconnection of one cable or even a single conductor may lead to inverter malfunction and may cause the motor to run out of control.

9.5. Environmental Requirements

Operating temperatures	-10 to +55°C ambient temperature (contact Enertronica Santerno S.p.A. for higher ambient temperatures)
Relative humidity	5 to 95% (non-condensing)
Max. allowable operating altitude	2000 m a.s.l. For installation above 2000 m and up to 4000 m, please contact Enertronica Santerno S.p.A..

9.6. Electrical Ratings

Class A voltage according to EN 61800-5-1

<i>Encoder supply output</i>	<i>Ratings</i>			
	<i>Min</i>	<i>Typ</i>	<i>Max</i>	<i>Unit</i>
Encoder output current, +12V configuration			300	mA
Encoder output current, +5V configuration			500	mA
Short-circuit protection level			900	mA
Encoder supply voltage adjusting range in 5V Mode	4.5	5.3	8.0	V
Encoder supply voltage adjusting range in 12V Mode	10.5	12.0	15.7	V

<i>Static characteristics for signal inputs</i>	<i>Ratings</i>			
	<i>Min</i>	<i>Typ</i>	<i>Max</i>	<i>Unit</i>
Type of input signals, A,B	Differential analog type ~1Vpp			
Differential peak-to-peak input voltage range	0.8	1.0	1.2	Vpp
Input common mode voltage range	0		5	V
Input impedance	120			ohm
Type of input signals, C,D	Differential analog type ~1Vpp			
Differential input voltage range	0.8	1.0	1.2	Vpp
Input common mode voltage range	0		5	V
Input impedance	1			Kohm
Type of input signal R	Differential analog type ~0.5Vpp/1Vpp			
Differential encoder signal input voltage range	0.2	0.5	1.1	Vpp
Input common mode voltage range	0		5	V
Input impedance	120			ohm

<i>Max. absolute values</i>	<i>Value</i>			
	<i>Min</i>	<i>Typ</i>	<i>Max</i>	<i>Unit</i>
Maximum allowable common mode voltage amplitude causing no damage	-20		+25	V
Maximum allowable differential voltage amplitude on channels A, B, R	-3.5		+3.5	V
Maximum allowable differential voltage amplitude on channels C and D	-10		+10	V



CAUTION

Exceeding the maximum differential input or common mode voltages will result in irreparable damage to the apparatus.

<i>Dynamic characteristics of the input signals</i>	<i>Value</i>
Maximum frequency of the signals acquired in analog mode – channels C, D or channels A, B in three-channel mode	1000Hz (60,000rpm @ 1 p/rev) (60 rpm @ 1,024 p/rev)
Maximum frequency of signals acquired with digital counting on zero crossing – channels A, B	140kHz (1,024pls @ 8,200rpm)
Minimum duration of zero crossing pulse – channel R	3.5 μs (1,024pls @ 8,200rpm)



CAUTION

Exceeding the input signal frequency limits will result in a wrong measurement of the encoder position and speed. Depending on the control method selected for the inverter, it may also cause the motor to run out of control.

10. ES822 ISOLATED SERIAL BOARD (SLOT B)

Product-Accessory Compatibility		
Product	ES822 Optoisolated serial board	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	√	
Solardrive Plus	√	

Table 11: Product – ES822 Optoisolated serial board compatibility

The isolated serial board RS232/485 controlling Santerno drives allows connecting a computer through RS232 interface or allows a multidrop connection of Modbus devices through RS485 interface. It provides galvanic isolation of interface signals relating to both the control board ground and the terminal board common of the control board.




Figure 82: ES822 board

10.1. Identification Data

Description	Part Number
Isolated serial board - RS232/485	ZZ0095850

10.2. Environmental Requirements

Operating temperature	-10 to +55°C ambient temperature (contact Enertronica Santerno S.p.A. for higher ambient temperatures)
Relative humidity	5 to 95% (non-condensing)
Max. operating altitude	2000 m a.s.l. For installation above 2000 m and up to 4000 m, please contact Enertronica Santerno S.p.A..

10.3. Electrical Features**WIRING:**

Once ES822 board is fitted, connector RS485 installed on the inverter will automatically disable. D-type, 9-pole male connector (RS485) or female connector (RS232-DTE) located on ES822 board activate depending on the position of J1.

Contacts of CN3, D-type, 9-pole male connector (RS485) are as follows:

Decisive voltage class A according to EN 61800-5-1

PIN	FUNCTION
1 - 3	(TX/RX A) Differential input/output A (bidirectional) according to standard RS485. Positive polarity in respect to pins 2 – 4 for one MARK.
2 - 4	(TX/RX B) Differential input/output B (bidirectional) according to standard RS485. Negative polarity in respect to pins 1 – 3 for one MARK.
5	(GND) control board zero volt
6 - 7	Not connected
8	(GND) control board zero volt
9	+5 V, max 100mA for the power supply of an auxiliary RS485/RS232 converter (if any)

Contacts of CN2, D-type, 9-pole female connector (RS232-DCE) are as follows:

Decisive voltage class A according to EN 61800-5-1

PIN	FUNCTION
1 - 9	Not connected
2	(TX A) Output according to standard RS232
3	(RX A) Input according to standard RS232
5	(GND) zero volt
4 - 6	To be connected together for loopback DTR-DSR
7 - 8	To be connected together for loopback RTS-CTS

10.4. Installing ES822 Board on the Inverter (Slot B)



DANGER

Before gaining access to the components inside the inverter, remove voltage from the inverter and wait at least 20 minutes. Wait for a complete discharge of the internal capacitors to avoid any electric shock hazard.



CAUTION

Electric shock hazard: do not connect/disconnect the signal terminals or the power terminals when the inverter is on. This also prevents the inverter from being damaged.



NOTE

All the screws used to fasten removable parts (terminals cover, serial interface connector, cable plates, etc.) are black, round-head, cross-head screws. When wiring the inverter, remove only this type of screws. If different screws or bolts are removed, the inverter warranty will be no longer valid.

1. Turn off the inverter and wait at least 20 minutes.
2. Remove the cover to access to the inverter control terminals. The fixing spacers for the encoder board and signal connector are located on the right.




Figure 83: Position of the slot for the installation of the serial isolated board

3. Fit ES822 board and make sure that all contacts enter the relevant housing in the signal connector. Fasten the encoder board to the fixing spacers using the screws supplied.
4. Configure DIP-switches and the jumper located on the encoder board based on the connected encoder.
5. Close the inverter frame by reassembling the cover allowing gaining access to the inverter control terminals.

10.5. Jumper for RS232/RS485 Selection

Jumper J1 sets ES822 board to operate as RS485 interface or as RS232 interface. The corresponding positions are silk-screened on the board.

With a jumper between pins 1-2, CN3-(RS485) is enabled (default).

With a jumper between pins 2-3, CN2-(RS232) is enabled.




Figure 84: Jumper setting RS232/RS485

10.6. DIP-switch for RS485 Terminator

Please refer to the Serial Communications section in the Installation Guide.

For serial link RS485 in ES822 board, the line terminator is selected through DIP-switch SW1 as shown in the figure below.

When the line master (computer) is located at the beginning or at the end of the serial link, the line terminator of the farthest inverter from the master computer (or the only inverter in case of direct connection to the master computer) shall be enabled.

Line terminator enables by setting selector switches 1 and 2 to ON in DIP-switch SW1. The line terminator of the other inverters in intermediate positions shall be disabled: DIP-switch SW1, selector switches 1 and 2 in position OFF (default setting).

In order to use RS232-DTE link, no adjustment of DIP-switch SW1 is required.




Figure 85: Configuration of terminator DIP-switch for line RS485


11. OPTION BOARDS FOR FIELDBUS (SLOT B)

Product-Accessory Compatibility		
Product	Fieldbus boards B40 series	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	√	
Solardrive Plus	√	
Product	Anybus-S Fieldbus boards	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	√	
Solardrive Plus	√	

Table 12: Product – Fieldbus board compatibility

Several interface boards (optional) are available for the connection of Santerno drives to automation systems based on Fieldbus. Option boards allow interfacing systems based on:

- Profibus-DP®,
- PROFIdrive®,
- DeviceNet® (CAN),
- CANopen® (CAN),
- Modbus/TCP,
- EtherNet/IP,
- Profinet IRT,
- EtherCAT,



The drives compatible with this accessory can house only one option board per fieldbus. This board allows controlling the inverter through the desired bus starting from a control device (PLC, industrial computer, etc.). The control method from fieldbus integrates the control methods from local terminals, remote terminals (through MODBUS serial link) and from keypad, which are provided from the inverter. For more details on the inverter command modes and the possible matching among the different sources, refer to the Programming Guide (Control Method menu and Fieldbus menu). The sections below cover the installation procedure and the configuration and diagnostics of the different types of option boards.



NOTE

The read/write scan rate for the drives compatible with this accessory is 2ms. Please refer to the Programming Guide for details.



CAUTION

Other communications protocols are available. Please refer to ES919 Communications Board (Slot B).

11.1. Identification Data

The utilities and configuration files for the fieldbus option boards are available for download from santerno.com, Software tab of the product sheet concerned.

Two series of option boards for fieldbuses are available: the B40 series and the Anybus-S series. The newest B40 series adds more Ethernet-based fieldbuses.

B40 Series Boards

Type of Fieldbus	Connector	Electric Interface	Part Number	Motorola Firmware Version	See
Profibus-DP®	9-pin D-Sub	Profibus®	ZZ4600200	≥ 4.110	B40 Series Board for PROFIBUS-DP®
DeviceNet®	5-pin Terminal board	CAN Bus	ZZ4600210	≥ 4.110	B40 Series Board for DeviceNet®
Modbus/TCP	RJ-45	Ethernet	ZZ4600220	≥ 4.110	B40 Series Boards Featuring Ethernet Interface (Profinet IRT, Modbus/TCP, EtherCAT, Ethernet/IP)
EtherNet/IP	RJ-45	Ethernet	ZZ4600221	≥ 4.113	
Profinet IRT	RJ-45	Ethernet	ZZ4600222	≥ 4.110	
EtherCAT	RJ-45	Ethernet	ZZ4600223	≥ 4.113	

Anybus-S Boards

Type of fieldbus	Connector	Electric interface	Part Number	Motorola Firmware Version	See
Profibus-DP®	9-pin D-Sub	Profibus®	ZZ4600045	Any	Anybus-S PROFIBUS-DP® Board
PROFIdrive®	9-pin D-Sub	Profibus®	ZZ4600042	Any	Anybus-S PROFIdrive® Board
DeviceNet®	5-pin Terminal board	CAN Bus	ZZ4600055	Any	Anybus-S DeviceNet® Board
CANOpen®	5-pin Terminal board	CAN Bus	ZZ4600070	Any	Anybus-S CANOpen® Fieldbus Board
Modbus/TCP	RJ-45	Ethernet	ZZ4600100	Any	Anybus-S Ethernet Board for Modbus/TCP

11.2. Installing the Fieldbus Board on the Inverter (Slot B)



DANGER

Before gaining access to the components inside the inverter, remove voltage from the inverter and wait at least 20 minutes. Wait for a complete discharge of the internal capacitors to avoid any electric shock hazard.



CAUTION

Electric shock hazard: do not connect/disconnect the signal terminals or the power terminals when the inverter is on. This also prevents the inverter from being damaged.



NOTE

All the screws used to fasten removable parts (terminals cover, serial interface connector, cable plates, etc.) are black, round-head, cross-head screws. When wiring the inverter, remove only this type of screws. If different screws or bolts are removed, the inverter warranty will be no longer valid.

- 1) Remove voltage from the inverter and wait at least 20 minutes.
- 2) The electronic components in the inverter and the communications board are sensitive to electrostatic discharge. Be careful when you reach the component parts inside the inverter and when you handle the communications board. The board should be installed in a workstation equipped with proper grounding and provided with an antistatic surface. If this is not possible, the installer must wear a ground bracelet properly connected to the PE conductor.



- 3) Loosen the two front screws located in the lower part of the inverter cover to remove the covering of the terminal board. In the drive control board, you can then reach the slot B, where you can install the Profibus communications board.




Figure 86: Location of the slot B inside the terminal board cover of Santerno drives

- 4) Insert the communications board in the slot B; make sure that the connector bar in the board is inserted in the front part of the slot only, and that the last 6 pins are not connected. If installation is correct, the three fastening holes will match with the housings of the fastening screws for the fixing spacers. Tighten the board fixing screws as shown in Figure 87 and Figure 88.




Figure 87: Checking contacts in the slot B




Figure 88: Fastening the communications board to slot B

- 5) Configure the DIP-switches and rotary-switches following the instructions given in the relevant section.
- 6) Connect the Fieldbus cable by inserting its connector or by connecting the wires to the terminals.
- 7) Close the inverter frame by reassembling the cover allowing gaining access to the inverter control terminals.

11.3. Status LEDs on the B40 Series Boards

Each B40 Fieldbus board is equipped with two red/green LEDs (NSTA L4 and MSTA L5 LEDs). Their meaning depends on the communications bus as from the tables below:

11.3.1. NSTA/MSTA LEDs - Profibus DP

L4/Operation Mode		L5/Status Mode	
LED State	Indication	LED State	Indication
Off	Not online / No power	Off	Not initialized
Green	Online, data exchange	Green	Initialized
Flashing Green	Online, clear	Flashing Green	Initialized, diagnostic event(s) present
Flashing Red (1 flash)	Parameterization error	Red	Exception error
Flashing Red (2 flash)	PROFIBUS Configuration error		

11.3.2. NSTA/MSTA LEDs - DeviceNet

L4/Network Status		L5/Module Status	
LED State	Indication	LED State	Indication
Off	Not online / No network power	Off	Not operating
Green	On-line, one or more connections are established	Green	Operating in normal condition
Flashing Green (1 Hz)	On-line, no connections established	Flashing Green (1 Hz)	Missing, incorrect or incomplete configuration, device needs commissioning.
Red	Critical link failure, fatal event	Red	Unrecoverable Fault(s)
Flashing Red (1 Hz)	One or more connections timed-out	Flashing Red (1 Hz)	Recoverable Fault(s)
Alternating Red/Green	Executing self test	Alternating Red/Green	Executing self test

11.3.3. NSTA/MSTA LEDs - Profinet

L4/Network Status		L5/Module Status	
LED State	Indication	LED State	Indication
Off	Offline	Off	Not Initialized
Green	Online (RUN)	Green	Normal Operation
Green, 1 flash	Online (STOP)	Green, 1 flash	Diagnostic Event(s)
Green, blinking	Used by engineering tools to identify the node on the network	Red	Exception error
Red	Fatal event	Red	Fatal event
Red, 1 flash	Station Name error	Alternating Red/Green	Firmware update
Red, 2 flashes	IP address error		
Red, 3 flashes	Configuration error		

11.3.4. NSTA/MSTA LEDs LEDs - Modbus/TCP

L4/Network Status		L5/Module Status	
LED State	Indication	LED State	Indication
Off	No IP address or in state EXCEPTION	Off	No power
Green	At least one Modbus message received	Green	Normal operation
Green, flashing	Waiting for first Modbus message	Red	Major fault, FATAL
Red	IP address conflict detected, FATAL ERROR	Red, flashing	Minor fault
Red, flashing	Connection timeout. No Modbus message has been received within the configured "process active timeout" time	Alternating Red/Green	Firmware update from file system in progress

11.3.5. NSTA/MSTA LEDs - Ethernet IP

L4/Network Status		L5/Module Status	
LED State	Indication	LED State	Indication
Off	No power or no IP address	Off	No power
Green	Online, one or more connections established (CIP Class 1 or 3)	Green	Controlled by a Scanner in Run state
Green, flashing	Online, no connections established	Green, flashing	Not configured, or Scanner in Idle state
Red	Duplicate IP address, FATAL error	Red	Major fault (EXCEPTION-state, FATAL error etc.)
Red, flashing	One or more connections timed out (CIP Class 1 or 3)	Red, flashing	Recoverable fault(s).

11.3.6. NSTA/MSTA LEDs - EtherCAT

L4/RUN LED		L5/ERR LED	
LED State	Indication	LED State	Indication
Off	INIT	Off	No error (or no power)
Green	OPERATIONAL	Red, blinking	Invalid configuration
Green, blinking	PRE-OPERATIONAL	Red, single flash	Unsolicited state change
Green, single flash	SAFE-OPERATIONAL	Red, double flash	Sync Manager watchdog timeout
Flickering	BOOT	Red	Application controller failure
Red	Fatal Event time	Flickering	Booting error detected

The models featuring serial comms (Profibus and DeviceNET) are provided with two additional LEDs indicating the bus status when transmitting (yellow TX LED L2) and receiving (green RX LED L3).

The models featuring Ethernet comms have the line LINK/Activity LEDs mounted directly on the bus connector, as described in the Ethernet Connector section.

11.3.7. Profinet Link LEDs

LINK/Activity LED	
LED State	Indication
Off	No Link
Green	Link
Green, flickering	Activity

11.3.8. Modbus/TCP Link LEDs


LINK/Activity LED	
LED State	Indication
Off	No link, no activity
Green	Link (100 Mbit/s) established
Green, flickering	Activity (100 Mbit/s)
Yellow	Link (10 Mbit/s) established
Yellow, flickering	Activity (10 Mbit/s)

11.3.9. Ethernet IP Link LEDs

LINK/Activity LED	
LED State	Indication
Off	No link, no activity
Green	Link (100 Mbit/s) established
Green, flickering	Activity (100 Mbit/s)
Yellow	Link (10 Mbit/s) established
Yellow, flickering	Activity (10 Mbit/s)

11.3.10. EtherCAT Link LEDs

LINK/Activity LED	
LED State	Indication
Off	No Link
Green	Link sensed, no activity
Green, flickering	Link sensed, activity



S000750-B

Figure 89: Position of the status LEDs on the B40 series board

11.4. Status LEDs on the Anybus-S Boards

Each option fieldbus board of the Anybus-S series is equipped with a column provided with four LEDs installed on its front edge to monitor the bus status and with one LED (red/green) installed on the communications board for debugging, as shown in the figure below.




Figure 90: Position of indicator LEDs on the board

The red/green LED mounted on the board relates to all interface models, whereas the LEDs mounted on the board column have different meanings based on the type of fieldbus being used.

11.4.1. **LEDs for Fieldbus Interface CPU Diagnostics**

The LED located on the printed circuit of any version of the interface board indicates the status of the CPU dedicated to communication. The table below shows the possible type of signals.

N. & Name	Function
5. Board diagnostics	Red – Unknown internal error, or module operating in bootloader mode 1 Hz Red blinker – RAM fault 2 Hz Red blinker – ASIC or FLASH fault 4 Hz Red blinker – DPRAM fault 2 Hz Green blinker – Module not initialized 1 Hz Green blinker – Module initialized and operating.

11.4.2. LEDs for PROFIBUS-DP® Board Diagnostics

In the PROFIBUS-DP board, LED 1 is inactive; the remaining LEDs are described below:

N. & Name	Function
2. On-Line	It indicates that the inverter is on-line on the fieldbus: Green – The module is on-line; data exchange is allowed. Off – The module is not on-line.
3. Off-Line	It indicates that the inverter is off-line on the fieldbus: Red – The module is off-line; data exchange is not allowed. Off – The module is not off-line.
4. Fieldbus Diagnostics	It indicates some possible errors: 1 Hz Red blinker – Configuration error: the length of IN messages and OUT messages set while initializing the module does not match with the message length set while initializing the network. 2 Hz Red blinker – User Parameter error: the data length and/or contents for the User Parameters set while initializing the module does not match with the data length and/or contents set while initializing the network. 4 Hz Flash blinker – Error while initializing the Fieldbus communications ASIC. Off – No error found.

11.4.3. LEDs for DeviceNet® Board Diagnostics

In the DeviceNet® board, LEDs 1 and 4 are not used; the remaining LEDs are described below:

N. & Name	Function
2. Network status	It indicates the status of the DeviceNet communications: Off – The module is not On-Line Green – DeviceNet communications in progress and correct Flashing green – The module is ready for communication but is not connected to the network Red – A critical error occurred (too erroneous data items) and the module switched to the “link failure” status Flashing red – A timeout occurred when exchanging data
3. Module status	It indicates the status of the communication module: Off – The module is off Green – The module is operating Flashing green – The length of the two data packets exceeds the preset value Red – An unresettable event error occurred Flashing red – A resettable event error occurred

11.4.4. LEDs for CANopen® Board Diagnostics

In the CANopen board, LED 1 is not used; the remaining LEDs are described below:

N. & Name	Function
2. Run	It indicates the status of the CANopen interface of the module: Off – The interface is off One flash – The interface status is STOP Flashing – The interface is being initialized On – The interface is operating
3. Error	It indicates the error status of the CANopen interface: Off – No error One flash – The frame error counter has reached the warning limit Two flashes – A Control Error event (guard event or heartbeat event) occurred Three flashes – A synchronisation error event occurred: the SYNC message was not received within the time-out On – The bus is disabled due to an unresettable event error
4. Power	Off – The module is off On – The module is on

The word “Flashing” in the table indicates a LED that comes on for 200ms every 200ms; “One flash”, “Two flashes” and “Three flashes” indicate a LED that comes on one, twice or three times for 200ms every 200ms and with an inactivity time of 1000ms.

11.4.5. LEDs for Ethernet Board Diagnostics

In the Ethernet board, the diagnostics LEDs indicate the status of the connection to the LAN:

N. & Name	Function
1. Link	Off – The module has not detected any legal carrier signal and is not in the LINK status On – The module has detected a legal carrier signal and is in the LINK status
2. Module status	Off – The module is off Green – The module is properly operating Flashing green – The module was not configured and communication is in stand-by Flashing red – the module has detected a resettable event error Red – the module has detected an unresettable event error Flashing red/green – the module is performing a self-test at power on
3. Network status	Off – The IP address has not yet been assigned Green – At least one active Ethernet/IP connection is in progress Flashing green – No active Ethernet/IP connection is in progress Flashing red – “Timeout” of one or more links performed directly to the module Red – The module has detected that its IP is used by another device in the LAN Flashing red/green – The module is performing a self-test at power on
4. Activity	Flashing green – A data packet is being transmitted or received

11.5. B40 Series Board for PROFIBUS-DP®


PROFIBUS-DP® is a registered trademark of PROFIBUS International.

The B40 series Profibus® communications board allows interfacing between a drive and an external control unit, such as a PLC, using a PROFIBUS-DP communications interface.

The drive operates as a Slave device and is controlled by a Master device (PLC) through command messages and reference values which are equivalent to the ones sent via terminal board. The Master device is also capable of detecting the operating status of the inverter. More details about Profibus communications are given in the Programming Guide.

The Profibus® communications board has the following features:

- Type of fieldbus: PROFIBUS-DP EN 50170 (DIN 19245 Part 1) with protocol version 1.10
- Automatic detection of the baud rate ranging from 9600 bits/s to 12 Mbits/s
- Communications device: PROFIBUS bus link, type A or B as mentioned in EN50170
- Type of fieldbus: Master-Slave communications; max. 126 stations in multidrop connection
- Fieldbus connector: female, 9-pin, DSUB connector
- Wire: copper twisted pair (EIA RS485)
- Max. length of the bus: 200m @ 1.5Mbits/s (can be longer if repeaters are used)
- Isolation: the bus is galvanically isolated from the electronic devices via a DC/DC converter
- The bus signals (link A and link B) are isolated via optocouplers
- Status indicators: indicator Led for board status and indicator Led for fieldbus status



S000759-B

Figure 91: PROFIBUS-DP® fieldbus communications board

11.5.1. PROFIBUS® Fieldbus Connector

Female, 9-pin, D-sub connector.

Pin layout:

Decisive voltage class A according to EN 61800-5-1

N.	Name	Description
–	Shield	Connector frame connected to PE
1	N.C.	
2	N.C.	
3	B-Line	Positive RxD/TxD according to RS 485 specifications
4	RTS	Request To Send – active high level when sending
5	GND	Bus ground isolated from control board 0V
6	+5V	Bus driver supply isolated from control board circuits
7	N.C.	
8	A-Line	Negative RxD/TxD according to RS 485 specifications
9	N.C.	

11.5.2. Bus Configuration

The figure shows a common configuration where the first device is the Master (PLC, Bus Bridge or Repeater), but this device can be connected also in central position. Anyway, the rule stating that termination should always be connected to first or last device, is always valid.




Figure 92: Example of a Profibus network (the correct setting of the line terminators is highlighted)

The termination is inserted directly by the switch on the loose male connector specific to the Profibus® cable.

11.5.3. Connection to the Fieldbus

Make sure that wiring is correct, especially if the fieldbus operates at high baud rates (higher than or equal to 1.5Mb/s).

Figure 92 is an example of a Profibus® link connecting multiple devices.

Use special Profibus cables (“Profibus Standard Bus Cable”, Type A); do not exceed the max. allowable connection length based on the baud rate; use proper connectors.

The table below shows the standard baud rate values and the corresponding max. length of the bus if cables of Type A are used.

<i>Allowable Baudrate</i>	<i>Max. Length for Cable of Type A</i>
9.6 kbit/s	1.2 km
19.2 kbit/s	1.2 km
45.45 kbit/s	1.2 km
93.75 kbit/s	1.2 km
187.5 kbit/s	1 km
500 kbit/s	400 m
1.5 Mbit/s	200 m
3 Mbit/s	100 m
6 Mbit/s	100 m
12 Mbit/s	100 m

We recommend that Profibus® FC (FastConnect) connectors be used. They offer the following benefits:

- No soldering required for the connections inside the cable
- One ingoing cable and one outgoing cable can be used, so that connections of intermediate nodes can be stubless, thus avoiding signal reflections
- The internal resistors can be connected through a switch located on the connector frame
- Profibus FC connectors are provided with an internal impedance adapting network to compensate for the connector capacity.



Figure 93: Profibus® FC (FastConnect) connector with line termination settings

**NOTE**

A more comprehensive overview of the Profibus is given at <http://www.profibus.com/>. In particular, you can download the “Installation Guideline for PROFIBUS DP/FMS”, containing detailed wiring information, and the document named “Recommendations for Cabling and Assembly” containing important guidelines to avoid the most common wiring errors.

**NOTE**

Please refer to the Programming Guide for details on Profibus board settings: addresses, baudrate, etc.

11.6. **B40 Series Boards Featuring Ethernet Interface (Profinet IRT, Modbus/TCP, EtherCAT, Ethernet/IP)**

All the Fieldbus communications boards, B40 series featuring Ethernet interface share the same construction principles and installation/wiring procedure.

Four different part numbers are available for these boards. They allow interfacing a drive with an external control unit featuring one of the following comms protocols:

- Profinet IRT,
- Modbus/TCP,
- EtherCAT,
- Ethernet/IP.

For details on drive control options implemented by Fieldbus boards please refer to the Programming Guide.

The communications board performs automatic negotiation with the mains if the baud rate is set to 10 or 100 Mbits/s.

The main features of the interface board are the following:

- Autonegotiation of the baud rate and the type of cable (Auto MDI/MDIX)
- Configuration of the Ethernet parameters from the drive display (please refer to the Programming Guide)
- Ethernet interface galvanically isolated through a transformer




Figure 94: B40 series Fieldbus comms board with Ethernet interface



NOTE

The Ethernet connectors shown in the figure are equivalent for any protocols except for the EtherCAT protocol, where the right-hand connector is INPUT only and the left-hand connector is OUTPUT only.

11.6.1. Ethernet Connector


The board is provided with a standard RJ-45 connector (IEEE 802) for Ethernet connection 10/100 (100Base-T, 10Base-T).

The yellow LED indicates the Link/Operation with 10Mbps baud rate, whereas the green LED indicates the Link/Operation with 100Mbps baud rate.

The pin layout is the same as the one used for each network board computers are equipped with.

Decisive voltage class A according to EN 61800-5-1

N.	Name	Description
1	TD+	Positive signal transmission line
2	TD-	Negative signal transmission line
3	RD+	Line receiving positive signals
4	Term	Terminated pair – not used
5	Term	Terminated pair – not used
6	RD-	Line receiving negative signals
7	Term	Terminated pair – not used
8	Term	Terminated pair – not used



S000748-0

11.6.2. Connection to the Network

The Ethernet interface board can be connected to a master device (PC or PLC) either through a LAN (Ethernet business network) or a direct point-to-point connection.

The board connection through a LAN is similar to a computer connection. Use a standard cable for a Switch or Hub connection or a Straight-Through Cable TIA/EIA-568-B of class 5 UTP (Patch cable for LAN).



NOTE

The inverter is typically installed with other electric/electronic devices inside a cubicle. Normally, the electromagnetic pollution inside the cubicle is remarkable and is due to both radiofrequency disturbance caused by the inverters and to bursts caused by the electromechanical devices. To avoid propagating disturbance to Ethernet cables, they must be segregated and kept as far as possible from the other power cables and signal cables in the cubicle.

Disturbance propagation to Ethernet cables may affect the correct operation of the inverter and the other devices (computers, PLCs, Switches, Routers) connected to the same LAN.



NOTE

The maximum length of the LAN cable, cat. 5 UTP allowed by IEEE 802 standards results from the max. transit time allowed from the protocol and is equal to 100m. The longer the cable length, the higher the risk of communications failure.



NOTE

For Ethernet wiring, only use cables certified for LAN cables of 5 UTP category or higher. For standard wiring, avoid creating your own cables; Straight-Through or Cross-Over cables should be purchased from an authorised dealer.



NOTE

For a proper configuration and utilisation of the communications board, the user should know the basics of the TCP/IP protocol and should get familiar with the MAC address, the IP address and the ARP (Address Resolution Protocol). The basic document on the Web is "RFC1180 – A TCP/IP Tutorial".

11.6.3. Configuring B40 Series Boards with Ethernet Interface


Default: At first power on, the drive is allocated to the following IP address

192.168.0.2	IP
255.255.255.0	subnet mask
0.0.0.0	gateway
DHCP disable	


Configure your PC for the point-to-point connection, similarly to what is detailed in the Configuration of the Ethernet Board for Modbus/TCP section, by assigning the address 192.168.0.1\255.255.255.0\0.0.0.0 DHCP disable and connect an Ethernet cable from the board to the PC.

Open the browser and enter `http://192.168.0.2` in the address bar.

The window below appears, showing the details of the comms module:



Choose Configuration and enter the IP address. 10.100.120.4 with 255.255.255.0 netmask is set in the figure below.



Afterwards, click on “Save Settings” and send a Reset command.



CAUTION

The configuration of any address is done via this interface, except for the following address:
0.0.0.0\0.0.0.0\0.0.0.0 DHCP disable.

In that case, the address is overwritten by
192.168.0.2\255.255.255.0\0.0.0.0 DHCP disable.

In case the board IP address is not known and the DHCP is not enabled, it is possible to resume control of the board by restoring the default IP address.

To restore the default address, write parameter **I080** to the drive from Modbus RTU serial interface. Write **I080 = 1** and reset the drive to restore the TCP/IP to 192.168.0.2\255.255.255.0\0.0.0.0 DHCP disable.



NOTE

Unlike the Modbus RTU connection through the serial link, the Modbus/TCP connection with B40 board series is characterised by an offset of 800h (2048) for read variables. This is because the Ethernet board dialogues with the inverter and splits a buffer shared for two segments of 2 kbytes; one segment is dedicated to the messages sent from the inverter to the Fieldbus, the other is dedicated to the messages sent from the Fieldbus to the inverter. For instance, in order to read Word 1 Status+Alarms from Sinus Penta (refer to the Programming Guide), the Modbus/TCP transaction must be addressed to log 2049, not to log 1. On the other hand, writing occurs without any offset.

11.7. B40 Series Board for DeviceNet®

The DeviceNet® communications board allows interfacing a drive with an external control unit through a communications interface using a CAN protocol of the DeviceNet type. Refer to the Programming Guide for more details on the inverter control modes through the DeviceNet fieldbus board.

The main features of the interface board are the following:

- CIP Parameters Object Support
- Explicit messages
- Cyclic I/O or polling management
- Automatically detectable baud rate
- Optically isolated CAN interface
- DIP-Switch for line termination insertion




Figure 95: DeviceNET Fieldbus Comms Board

11.7.1. Fieldbus DeviceNET Terminal Board

The DeviceNet Fieldbus communications board is provided with a removable, screwable terminal board (pitch 5.08). The bus interface circuitry has an external supply of 24VDC ±10%, as prescribed from the CAN DeviceNet specifications.

Terminal layout as stated in the table:

Decisive voltage class A according to EN 61800-5-1

N.	Name	Description
1	GND	Common of the CAN driver circuit
2	CAN_L	CAN_L link
3	CAN_SH	Cable shielding
4	CAN_H	CAN_H link
5	V_BUS	24V±10% power supply for bus driver circuit input

The cross-sections of the allowable conductors ranges from 0.25mm² to 1.5mm² (AWG 22..14). A special terminal is required for the cable shielding conductor, so it is not necessary to connect the cable shielding to the drive earth through the tightening conductor collar.

11.7.2. Connection to the Fieldbus

The wiring quality is fundamental for the best reliability of the bus operation. For CANopen wiring, a shielded twisted pair with known resistance and impedance is recommended. The conductor unit is also fundamental for the quality of the signal. The higher the baud rates, the shortest the bus lengths allowed. The maximum length of the bus is also affected by the number of nodes. The tables below indicate the cable specifications based on the cable length and the variation features of the max. length based on the number of nodes and the cross-section of the conductors.

Tables refer to copper wires with a characteristic impedance of 120Ω and a typical propagation delay of 5ns/m.

Bus length [m]	Max. specific resistance of the cable [mΩ/m]	Recommended cross-section for conductors [mm ²]	Recommended terminator resistance [Ω]	Max. baud rate [Kbit/s]
0÷40	70	0.25÷0.34	124	1000 kbit/s
40÷300	60	0.34÷0.60	150÷300	500 kbit/s (max 100m)
300÷600	40	0.50÷0.75	150÷300	100 kbit/s (max 500m)
600÷1000	26	0.75÷0.80	150÷300	50 kbit/s

The total resistance of the cable and number of nodes determine the max. allowable length for the cable as per static features, not for dynamic features. Indeed, the max. voltage delivered by a node with a dominant bus is reduced by the resistive divider consisting of the cable resistor and the terminator resistors. The residual voltage must exceed the dominant voltage of the receiving node. The table below indicates the max. length values based on the cable cross-section, i.e. the cable resistance, and the number of nodes.

Cross-section of the conductors [mm ²]	Max. wiring length [m] based on the number of nodes		
	n. nodes < 32	n. nodes < 64	n. nodes < 100
0.25	200	170	150
0.50	360	310	270
0.75	550	470	410

The B40 Fieldbus DeviceNET board is equipped with a DIP-switch allowing inserting the termination resistor on the bus. This DIP-switch is to be inserted only in the first and last device in a DeviceNET trunk.



NOTE

Each DeviceNET trunk line must meet some geometric requirements and must provide two terminator nodes provided with suitable resistors. Consult document PUB00027R1 "Planning and Installation Manual - DeviceNet™ Cable System" and all the application notes available from ODVA web site (<http://www.odva.org>).

11.8. Anybus-S PROFIBUS-DP® Board

PROFIBUS-DP® is a registered trademark of PROFIBUS International.

The Profibus communications board allows interfacing between a drive and an external control unit, such as a PLC, using a PROFIBUS-DP communications interface.

The drive operates as a Slave device and is controlled by a Master device (PLC) through command messages and reference values which are equivalent to the ones sent via terminal board. The Master device is also capable of detecting the operating status of the inverter. More details about Profibus communications are given in the Programming Guide.

Profibus communications board has the following features:

- Type of fieldbus: PROFIBUS-DP EN 50170 (DIN 19245 Part 1) with protocol version 1.10
- Automatic detection of the baud rate ranging from 9600 bits/s to 12 Mbits/s
- Communications device: PROFIBUS bus link, type A or B as mentioned in EN50170
- Type of fieldbus: Master-Slave communications; max. 126 stations in multidrop connection
- Fieldbus connector: female, 9-pin, DSUB connector
- Wire: copper twisted pair (EIA RS485)
- Max. length of the bus: 200m @ 1.5Mbits/s (can be longer if repeaters are used)
- Isolation: the bus is galvanically isolated from the electronic devices via a DC/DC converter
- The bus signals (link A and link B) are isolated via optocouplers
- PROFIBUS –DP communications ASIC: chip Siemens SPC3
- Hardware configurability: bus terminator switch and rotary-switch assigning the address to the node
- Status indicators: indicator Led for board status and indicator Led for fieldbus status.




Figure 96: PROFIBUS-DP® fieldbus communications board

11.8.1. Profibus® Fieldbus Connector

Female, 9-pin, D-sub connector.

Pin layout:


Decisive voltage class A according to EN 61800-5-1

N.	Name	Description
-	Shield	Connector frame connected to PE
1	N.C.	
2	N.C.	
3	B-Line	Positive RxD/TxD according to RS 485 specifications
4	RTS	Request To Send – active high level when sending
5	GND	Bus ground isolated from control board 0V
6	+5V	Bus driver supply isolated from control board circuits
7	N.C.	
8	A-Line	Negative RxD/TxD according to RS 485 specifications
9	N.C.	

11.8.2. Configuration of the Profibus-DP Communications Board

PROFIBUS-DP communications board is provided with one DIP-switch and two rotary-switches used to set the operating mode.

The DIP-switch located next to the fieldbus connector allows activating the line terminator. The terminator is activated by pushing the lever downwards, as shown below.



The termination of the fieldbus line should be cut in only with the first and last device of a chain, as illustrated in Figure 97.

The figure shows a common configuration where the first device is the Master (PLC, Bus Bridge or Repeater), but this device can be connected also in central position. Anyway, the rule stating that termination should always be connected to first or last device, is always valid.




Figure 97: Example of a Profibus network (the correct setting of the line terminators is highlighted)

Each device in the network must have its own Profibus address. The addresses of the drives are set through the rotary-switches installed in the interface board. Each rotary-switch is provided with a pin that can be turned to position 0-9 using a small screwdriver.

The rotary-switch on the left sets the tenths of the Profibus address, while the rotary switch on the right sets the units. Figure 98 shows an example of the correct position to set address "19".




Figure 98: Example of the rotary-switch position to set Profibus address "19"



NOTE

The rotary-switches allow setting Profibus addresses ranging from 1 to 99. Addresses exceeding 99 are not yet allowed.

11.8.3. Connection to the Fieldbus

Make sure that wiring is correct, especially if the fieldbus operates at high baud rates (higher than or equal to 1.5Mb/s).

Figure 97 is an example of a Profibus link connecting multiple devices.

Use special Profibus cables (“Profibus Standard Bus Cable”, Type A); do not exceed the max. allowable connection length based on the baud rate; use proper connectors.

The table below shows the standard baud rate values and the corresponding max. length of the bus if cables of Type A are used.

<i>Allowable Baudrate</i>	<i>Max. Length for Cable of Type A</i>
9.6 kbits/s	1.2 km
19.2 kbits/s	1.2 km
45.45 kbits/s	1.2 km
93.75 kbits/s	1.2 km
187.5 kbits/s	1 km
500 kbits/s	400 m
1.5 Mbits/s	200 m
3 Mbits/s	100 m
6 Mbits/s	100 m
12 Mbits/s	100 m

We recommend that Profibus FC (FastConnect) connectors be used. They offer the following benefits:

- No welding required for the connections inside the cable
- One ingoing cable and one outgoing cable can be used, so that connections of intermediate nodes can be stubless, thus avoiding signal reflections
- The internal resistors can be connected through a switch located on the connector frame
- Profibus FC connectors are provided with an internal impedance adapting network to compensate for the connector capacity.



NOTE

If you use Profibus FC connectors with internal terminators, you can activate either the connector terminal or the board terminals (in the first/last device only). Do not activate both terminators at a time and do not activate terminators in intermediate nodes.



NOTE

A more comprehensive overview of the Profibus is given at <http://www.profibus.com/>. In particular, you can download the “Installation Guideline for PROFIBUS DP/FMS”, containing detailed wiring information, and the document named “Recommendations for Cabling and Assembly” containing important guidelines to avoid the most common wiring errors.

11.9. Anybus-S PROFIdrive® Board

PROFIdrive® is a registered trademark of PROFIBUS International.

Any detail is given in the PROFIdrive COMMUNICATIONS BOARD – .
As per the board configuration, please refer to the Configuration of the Profibus-DP Communications Board section.

11.10. Anybus-S DeviceNet® Board

DeviceNet is a registered trademark of open DeviceNet Vendor Association.

The DeviceNet® communications board allows interfacing a drive with an external control unit through a communications interface using a CAN protocol of the DeviceNet 2.0 type. The baud rate and the MAC ID can be set through the on-board DIP-switches. Max. 512 bytes for input/output data are available; some of them are used for the interfacing with the inverter. Refer to the Programming Guide for more details on the inverter control modes through the DeviceNet fieldbus board.

The main features of the interface board are the following:

- Baud Rate: 125, 250, 500 kbits/s
- DIP-switch for baud rate and MAC ID selection
- Optically isolated DeviceNet interface
- Max. 512 bytes for input & output data
- Max. 2048 bytes for input & output data through mailbox
- DeviceNet Specification version: Vol 1: 2.0, Vol 2: 2.0
- Configuration test version: A-12




Figure 99: DeviceNet® Fieldbus communications board

11.10.1. DeviceNet® Fieldbus Terminals

The DeviceNet Fieldbus communications board is provided with a removable, screwable terminal board (pitch 5.08). The bus interface circuitry has an external supply of 24VDC ±10%, as prescribed from the CAN DeviceNet specifications.

Terminal arrangement as stated in the table:

Decisive voltage class A according to EN 61800-5-1

N.	Name	Description
1	V-	Negative voltage for bus supply
2	CAN_L	CAN_L bus line
3	SHIELD	Cable shielding
4	CAN_H	CAN_H bus line
5	V+	Positive voltage for bus supply

11.10.2. Board Configuration

The on-board DIP-switches allow setting the baud rate and the MAC ID identifying the device in the DeviceNet network.

DIP-switches 1 and 2 allow setting the baud rate, that must be the same for all the related devices. The DeviceNet standard allows three baud rates: 125, 250 and 500 kbits/s. Possible settings are the following:

Baudrate	Setting of SW.1 & SW.2	
125 kbits/s	sw.1=OFF	sw.2=OFF
250 kbits/s	sw.1=OFF	sw.2=ON
500 kbits/s	sw.1=ON	sw.2=OFF

The MAC ID can be set between 0 and 63 by entering the configuration of the binary number for six DIP-switches, from sw.3 to sw.8. The most significant bit (MSB) is set through sw.3, while the least significant bit (LSB) is set through sw.8.

Some possible settings are shown in the table below:

MAC ID	SW.3 (MSB)	SW.4	SW.5	SW.6	SW.7	SW.8 (LSB)
0	OFF	OFF	OFF	OFF	OFF	OFF
1	OFF	OFF	OFF	OFF	OFF	ON
2	OFF	OFF	OFF	OFF	ON	OFF
3	OFF	OFF	OFF	OFF	ON	ON
.....
62	ON	ON	ON	ON	ON	OFF
63	ON	ON	ON	ON	ON	ON

If multiple devices are connected to the same bus, different MAC IDs are to be set.

11.10.3. Connection to the Fieldbus

The wiring quality is fundamental for the best reliability of the bus operation. The higher the baud rates, the shortest the bus lengths allowed.

Reliability is strongly affected by the type of wiring and the wire topology. The DeviceNet standard allows four types of wires based on the type of related devices. It also allows connecting signal dispatching nodes, line terminators and supply couplers. Two types of lines are defined: the trunk line and the drop lines. The figure below illustrates the topology of a typical DeviceNet trunk line.

P000513-B




Figure 100: Outline of the topology of a DeviceNet trunk line

The inverter equipped with a DeviceNet interface board is typically connected through a drop line consisting of a 5-conductor shielded cable. The DeviceNet standard defines three shielded cables based on their diameter: THICK, MID, and THIN cables. The maximum electric length between two DeviceNet devices depends on the baud rate and the type of cable being used. The table below shows the maximum lengths that are recommended based on these variables. The FLAT cable can be used for the main trunk line if drop lines are connected through a system that does not require welding.

Baud Rate	Max. length with FLAT cable	Max. length with THICK cable	Max. length with MID cable	Max. length with THIN cable
125 kbits/s	420m	500m	300m	100m
250 kbits/s	200m	250m	250m	100m
500 kbits/s	75m	100m	100m	100m



NOTE

Each DeviceNet trunk line must meet some geometric requirements and must provide two terminator nodes and at least one supply node, because devices can be totally or partially powered via the bus. The type of the cable being used also determines the max. supply current available for the bus devices.



NOTE

For a more comprehensive overview of the DeviceNet standard, go to ODVA's home page (<http://www.odva.org>).

In particular, you can refer to the "Planning and Installation Manual" document.



NOTE

In case of failures or disturbance in the DeviceNet communications, please fill in the "DeviceNet Baseline & Test Report" form in the Appendix C of the "Planning and Installation Manual" before contacting the After-sales service.

11.11. Anybus-S CANopen® Fieldbus Board

CANopen® and CiA® are registered trademarks of CAN in Automation e.V.

The CANopen communications board allows interfacing a drive with an external control unit using communications interface operating with a CAN protocol of the CANopen type complying with the CIA DS-301 V3.0 specifications. The baud rate and the Device Address can be set through the on-board rotary switches. Eight baud rate levels can be set, up to 1Mbit/s. Refer to the Programming Guide for more details on the inverter control modes through the CANopen fieldbus board.

The main features of the interface board are the following:

- Unscheduled data exchange support
- Synch & Freeze operating mode
- Possibility of setting Slave Watch-dog time
- Eight baud rate levels, from 10kbits/s to 1Mbit/s
- Possibility of setting different Device Addresses up to max. 99 nodes
- Optically isolated CAN interface
- CANopen conformity: CIA DS-301 V3.0




Figure 101: CANopen® fieldbus communications board

11.11.1. CANopen® Fieldbus Connector

The CANopen® communications board is provided with a 9-pin male “D” connector. The bus interface circuitry is internally supplied, as prescribed by the CANopen® specifications.

Pins are arranged as follows:

Decisive voltage class A according to EN 61800-5-1

N.	Name	Description
Shell	CAN_SHLD	Cable shielding
1	-	
2	CAN_L	CAN_L line
3	CAN_GND	Common terminal of the CAN driver circuit
4	-	
5	CAN_SHLD	Cable shielding
6	GND	Option common terminal internally connected to pin 3
7	CAN_H	CAN_H line
8	-	
9	(reserved)	do not use



CAUTION

The CANopen connector is the same type as the connector fitted in all the drives series for the Modbus serial communications, but the pin layout and the internal circuitry are totally different. Make sure that connectors are not mismatched! A wrong connection of the CANopen connector to the Modbus interface or vice versa can damage the inverter and the other devices connected to the Modbus and CANopen networks.

11.11.2. Board Configuration

The CANopen communications board shall be used with three rotary-switches for configuration, which are required to set up the inverter operating mode. The rotary-switches also allow setting the baud rate and the Device Address. The figure below shows the position of the rotary-switches and a setting example with a baud rate of 125kbits/s and a Device Address equal to 29.




Figure 102: Example of the position of the rotary-switches for 125kbits/s and Device Address 29



NOTE

Device Address = 0 is not allowed by the CANopen specifications. Values ranging from 1 to 99 can be selected.

The table below shows the possible settings of the rotary-switches for the baud rate selection.

Rotary-switch setting	Baudrate
0	setting not allowed
1	10 kbits/s
2	20 kbits/s
3	50 kbits/s
4	125 kbits/s
5	250 kbits/s
6	500 kbits/s
7	800 kbits/s
8	1000 kbits/s
9	setting not allowed

11.11.3. Connection to the Fieldbus

High quality wiring is fundamental for the correct operation of the bus. For CANopen wiring, a shielded twisted pair with known resistance and impedance is recommended. The conductor unit is also fundamental for the quality of the signal. The higher the baud rates, the shortest the bus lengths allowed. The maximum length of the bus is also affected by the number of nodes. The tables below indicate the cable specifications based on the cable length and the variation features of the max. length based on the number of nodes and the cross-section of the conductors.

Tables refer to copper wires with a characteristic impedance of 120Ω and a typical propagation delay of 5ns/m.

Bus length [m]	Max. specific resistance of the cable [mΩ/m]	Recommended cross-section for conductors [mm ²]	Recommended terminator resistance [Ω]	Max. baud rate [Kbit/s]
0÷40	70	0.25÷0.34	124	1000 kbits/s
40÷300	60	0.34÷0.6	150÷300	500 kbits/s (max. 100m)
300÷600	40	0.5÷0.75	150÷300	100 kbits/s (max. 500m)
600÷1000	26	0.75÷0.8	150÷300	50 kbits/s

The total resistance of the cable and number of nodes determine the max. allowable length for the cable as per static features, not for dynamic features. Indeed, the max. voltage delivered by a node with a dominant bus is reduced by the resistive divider consisting of the cable resistor and the terminator resistors. The residual voltage must exceed the dominant voltage of the receiving node. The table below indicates the max. length values based on the cable cross-section, i.e. the cable resistance, and the number of nodes.

Cross-section of the conductors [mm ²]	Max. wiring length [m] based on the number of nodes		
	number of nodes < 32	number of nodes < 64	number of nodes < 100
0,25	200	170	150
0,5	360	310	270
0,75	550	470	410



NOTE

Each CANopen trunk line shall meet particular geometric requirements and shall be equipped with two terminator nodes provided with adequate resistors. Refer to the document CiA DR-303-1 "CANopen Cabling and Connector Pin Assignment" and to all the application notes available from <http://www.can-cia.org>.

11.12. Anybus-S Ethernet Board for Modbus/TCP

Ethernet communications board allows interfacing a drive to an external control unit with a communications interface operating with a Modbus/TCP Ethernet (IEEE 802) protocol complying with the Modbus-IDA V1.0 specifications. The IP rating for the communications board can be configured both through the on-board DIP-switches and automatically (network assignation through a DHCP protocol).

The communications board performs automatic negotiation with the mains if the baud rate is set to 10 or 100 Mbits/s.

The main features of the interface board are the following:

- Parameter configuration for Ethernet connection through DIP-switches, DHCP/BOOTP, ARP or internal Web server
- Modbus/TCP slave functions of class 0, class 1 and partially class 2
- Transparent socket interface for potential implementation of “over TCP/IP” dedicated protocols
- Ethernet interface galvanically isolated through a transformer




Figure 103: Ethernet Fieldbus Communications Board

11.12.1. Ethernet Connector


The board is provided with a standard RJ-45 connector (IEEE 802) for Ethernet connection 10/100 (100Base-T, 10Base-T). The pin arrangement is the same as the one used for each network board computers are equipped with.

Pinout:

Decisive voltage class A according to EN 61800-5-1

N.	Name	Description
1	TD+	Positive signal transmission line
2	TD-	Negative signal transmission line
3	RD+	Line receiving positive signals
4	Term	Terminated pair – not used
5	Term	Terminated pair – not used
6	RD-	Line receiving negative signals
7	Term	Terminated pair – not used
8	Term	Terminated pair – not used

P000517-0



11.12.2. Connection to the Network

Ethernet interface board can be connected to an Ethernet control device with a Modbus/TCP master protocol (computer or PLC) through a LAN (Ethernet business network) or a direct point-to-point connection.

The board connection through a LAN is similar to a computer connection. Use a standard cable for a Switch or Hub connection or a Straight-Through Cable TIA/EIA-568-B of class 5 UTP (Patch cable for LAN).



NOTE

The Ethernet interface board cannot be connected to old LANs using Thin Ethernet (10base2) coaxial cables. Connection to this type of LANs is possible using a Hub provided with both Thin Ethernet (10base2) connectors and 100Base-T or 10Base-T connectors. The LAN topology is a star one, with each node connected to the Hub or the Switch through its cable.

The figure below shows the pair arrangement in a 5 UTP cable and the standard colour arrangement to obtain the Straight-Through cable.

P000518-B





Figure 104: Cable of Cat. 5 for Ethernet and standard colour arrangement in the connector

Direct point-to-point connection is obtained with a Cross-Over Cable TIA/EIA-568-B, cat. 5. This type of cable performs a cross-over of the pairs so that the TD+/TD- pair corresponds to the RD+/RD- pair, and vice versa.

The table below shows the colour matching on the connector pins for the Cross-Over Cable and the cross-over diagram of the two pairs used from 100Base-T or 10Base-T connection.



NOTE

The inverter is typically installed with other electric/electronic devices inside a cubicle. Normally, the electromagnetic pollution inside the cubicle is remarkable and is due to both radiofrequency disturbance caused by the inverters and to bursts caused by the electromechanical devices. To avoid propagating disturbance to Ethernet cables, they must be segregated and kept as far as possible from the other power cables and signal cables in the cubicle.

Disturbance propagation to Ethernet cables may affect the correct operation of the inverter and the other devices (computers, PLCs, Switches, Routers) connected to the same LAN.



NOTE

The maximum length of the LAN cable, cat. 5 UTP allowed by IEEE 802 standards results from the max. transit time allowed from the protocol and is equal to 100m. The longer the cable length, the higher the risk of communications failure.



NOTE

For Ethernet wiring, only use cables certified for LAN cables of 5 UTP category or higher. For standard wiring, avoid creating your own cables; Straight-Through or Cross-Over cables should be purchased from an authorised dealer.



NOTE

For a proper configuration and utilisation of the communications board, the user should know the basics of the TCP/IP protocol and should get familiar with the MAC address, the IP address and the ARP (Address Resolution Protocol). The basic document on the Web is "RFC1180 – A TCP/IP Tutorial".

11.12.3. Configuration of the Ethernet Board for Modbus/TCP

The first step in configuring the Ethernet interface board consists in communicating with the board through a computer in order to update the configuration file (etccfg.cfg) stored to the non-volatile memory of the board. The configuration procedure is different if you use a point-to-point connection to the computer, if the board is connected to a LAN that is not provided with a DHCP server and if the board is connected to a LAN that is provided with a DHCP server. The section below covers these types of connection:

- Point-to-point connection to the PC,
- A board connected to a LAN that does not require a DHCP server and
- A board connected to a LAN that requires the DHCP server.

Those connection modes are detailed below.

**NOTE**

For the connection to the LAN, consult your network administrator, who can tell if the LAN is provided with a DHCP server. If this is not the case, your network administrator will assign the static IP addresses for each inverter.

Point-to-point connection to the computer

If a point-to-point connection to the computer is used, first configure the network board of the computer by setting a static IP address as 192.168.0.nnn, where nnn is any number ranging from 1 to 254.

To set the static IP address with Windows 7, open the Network Properties folder (for example typing “LAN” in the quick search tab: see Figure 106); in the field for the properties of the TCP/IP protocol, set the address value, e.g. 192.168.0.1.

Figure 107 shows the correct setting of the TCP/IP v.4 on the PC when using Windows 7. Settings are very similar for computers running on other Windows versions.





Figure 105: Windows 7 - Accessing directly to the network configuration folder



S000763-B

Figure 106: Setting a computer for a point-to-point connection to the inverter

After configuring your computer as described above, in the DIP-switches of the communications board set a binary number different from 0, different from 255 and different from the number set in the low portion of the IP address of the computer. For example, number 2 can be set by lowering (logic 1) only switch 7 as shown in the figure below.




Figure 107: Setting the DIP-switches to set the IP address 192.168.0.2.

If the computer is connected to the inverter through a Cross-Over Cable, a local network is created, which is composed of two participant nodes (the computer and the inverter), with 192.168.0.1 and 192.168.0.2 as IP addresses respectively. When the inverter is powered on, the LINK LED (see below) in the interface board should turn on. The following command:

```
ping 192.168.0.2
```

launched by a command line window of the computer performs the correct connection to the board.

If the advanced configuration is required, the internal web server may be used. Enter the board IP address in the proper field from a popular browser. A configuration page opens, where different TCP/IP configuration parameters of the board can be set, as shown in Figure 108.

This procedure also allows setting other different IP addresses instead of the default addresses (the format is 192.168.0.nnn).




Figure 108: Internal webserver

Connection with a computer through a LAN without any DHCP server

The network administrator will assign a static IP address for each inverter to be connected to the LAN.

Suppose that the IP address assigned from the administrator to an inverter is 10.0.254.177 and proceed as follows:

- Set all the DIP-switches in the Ethernet interface board to 0 (“up” position)
- Connect the board to a switch in the LAN using a Straight-Through cable and power on the inverter
- Make sure that the green light of the LINK LED (see below) comes on
- Note down the MAC address of the Ethernet board that is written on a label placed at the bottom of the printed circuit.

Suppose that the MAC address of the interface board is 00-30-11-02-2A-02

- In a computer connected to the same LAN (connected to the same sub-network, i.e. with an IP address equal to 10.0.254.xxx), open the command interpreter window and enter the following commands:
 - `arp -s 10.0.254.177 00-30-11-02-2A-02`
 - `ping 10.0.254.177`
 - `arp -d 10.0.254.177`

In the ARP table of the computer, the first command will create a static entry assigning the matching between the MAC address of the board and the static IP address.

The ping command queries the interface board to check the connection and returns the transit time of the data packet between the computer and the board through the network, as shown in Figure 109.




Figure 109: Example of the ping command to the IP address of the inverter interface board

When the interface board is sent the data packet, it gets the MAC address-IP address match as a permanent match, then it compiles and saves an “ethcfg.cfg” file, where the IP address 10.0.254.177 is stored as its own address each time the inverter is turned on.

Command number 3 is optional and removes the static match IP-MAC related to the inverter Ethernet board from the ARP table of the inverter.

Connection with a computer through a LAN equipped with a DHCP server

If an inverter equipped with an Ethernet board is connected to the LAN and if all the DIP-switches are set to zero (“up” position), when the inverter is powered on, automatic negotiation with the DHCP server takes place and the inverter is assigned an IP address chosen among the available ones. This configuration is then stored to the “ethcfg.cfg” file.

The “Anybus IP config” utility, available for download from santerno.com, Software tab of the product sheet concerned, can be used to query all the inverters with an Ethernet interface in the LAN from the same computer and, if required, the network access parameters can be reconfigured. The figure below shows the page of the programme when an inverter is acknowledged. Multiple inverters can be identified from the same network through their own value of the MAC address.





Figure 110: Anybus IP config utility

Query of the inverter data through the ModScan programme

Once configuration is achieved and the IP address of the interface board is available, you can query the inverter variables through the Modbus/TCP protocol. WinTECH’s ModScan application (<http://www.win-tech.com/>) allows displaying the variables read with the Modbus.


The figure below shows the setting shield of ModScan for the connection of a board with the IP address 10.0.254.177. For the Modbus/TCP connection, port 502 is provided by the Ethernet interface. Port 502 is to be used for all the Modbus transactions.



P000524-B

Figure 111: Setting ModScan for a Modbus/TCP connection

Figure 112 shows a ModScan shield related to the 10 output variables of the inverter. These variables are acquired in real time and are provided by the Modbus/TCP protocol. Refer to the Programming Guide, Fieldbus Configuration menu, for any detail about the map and the meaning of the input/output variables.



P000525-B

Figure 112: Display of the output variables of the inverter through the Modbus/TCP protocol



NOTE

Unlike the Modbus RTU connection through the serial link, the Modbus/TCP connection is characterised by an offset of 400h (1024) for write variables, because the Ethernet board dialogues with the inverter and splits a buffer shared for two segments of 1kbyte each. One segment is dedicated to the messages sent from the inverter to the Fieldbus, the other is dedicated to the messages sent from the Fieldbus to the inverter. In order to write Word 1 **M042**-Speed Reference from FIELDBUS (integer part) (refer to the Programming Guide), the Modbus/TCP transaction must be addressed to log 1025, not to log 1.

On the other hand, reading usually occurs without any offset.

11.13. Environmental Requirements Common to All Boards

Operating temperature	-10 to +55°C ambient temperature (contact Enertronica Santerno S.p.A. for higher ambient temperatures)
Relative humidity	5 to 95% (non-condensing)
Max. operating altitude	2000 m a.s.l. For installation above 2000 m and up to 4000 m, please contact Enertronica Santerno S.p.A..

12. ES919 COMMUNICATIONS BOARD (SLOT B)

Product-Accessory Compatibility		
Product	ES919 Communications Board	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	√	
Solardrive Plus	√	

Table 13: Product – ES919 Communications board compatibility

ES919 communications board makes other communications protocol available in addition to the protocols described in Option Boards For Fieldbus (Slot B). These communications boards allow Metasys N2- and BACnet-based systems.



- Metasys® N2,
- BACnet®.

P000973-0



CAUTION

When ES919 board is fitted into slot B, no other board (ES847, ES861, ES870, ES950, ES966, ES988) can be fitted into slot C.



CAUTION

ES919 board behaves as a serial gateway and makes all the **Mxxx** measurements and the **Ixxx** inputs available to the addresses given in the Programming Guide.



CAUTION

The “Fieldbus” section in the Programming Guide does not apply to ES919 comms board.

12.1. Identification Data

<i>Description</i>	<i>Part Number</i>
BACnet/RS485 Module	ZZ0102402
BACnet/Ethernet Module	ZZ0102404
Metasys N2 Module	ZZ0102406

12.2. Environmental Requirements Common to All Boards

Operating temperature	-10 to +55°C ambient temperature (contact Enertronica Santerno S.p.A. for higher ambient temperatures)
Relative humidity	5 to 95% (non-condensing)
Max. operating altitude	2000 m a.s.l. For installation above 2000 m and up to 4000 m, please contact Enertronica Santerno S.p.A..

12.3. Electrical Features Common to All Boards



CAUTION

ES919 is enabled through switch SW1 (factory setting).
If enabled (LED L1 ON), the RS485 serial port located on the inverter (serial link 0 – CN9 in the control board) is automatically disabled.

The operation of ES919 control board is as follows:

SW1	OFF	L3(EN)	OFF
		L1(TX)	OFF
		L2(RX)	OFF
	ON (default)	L3(EN)	ON
		L1(TX)	FLASHING (IF COMMUNICATION IS OK)
		L2(RX)	FLASHING (IF COMMUNICATION IS OK)

12.4. Installing the ES919 Board on the Drive (Slot B)



DANGER

Before gaining access to the components inside the inverter, remove voltage from the inverter and wait at least 20 minutes. Wait for a complete discharge of the internal capacitors to avoid any electric shock hazard.



CAUTION

Electric shock hazard: do not connect/disconnect the signal terminals or the power terminals when the inverter is on. This also prevents the inverter from being damaged.



NOTE

All the screws used to fasten removable parts (terminals cover, serial interface connector, cable plates, etc.) are black, round-head, cross-head screws. When wiring the inverter, remove only this type of screws. If different screws or bolts are removed, the inverter warranty will be no longer valid.



NOTE

If ES919 board is configured as BACnet Ethernet, one of the three fixing screws is located beneath the Ethernet module.

1. Remove voltage from the inverter and wait at least 20 minutes.
2. Remove the inverter cover for accessing the control terminals. The fixing spacers and the signal connector are located on the right.





Figure 113: Position of the slot for ES919 board

3. Fit ES919 board and make sure that all contacts enter the relevant housing in the signal connector. Fasten the encoder board to the fixing spacers using the screws supplied.
4. Enable the communication port with switch SW1.
5. Close the inverter frame by reassembling the cover allowing gaining access to the inverter control terminals.

12.4.1. ES919 Board for Metasys® N2

ES919 board for Metasys® N2 uses RS485 serial port to communicate with the system via the communication protocol “Metasys N2” by Johnson Controls (<http://www.johnsoncontrols.com>). Metasys is a registered trademark of Johnson Controls Inc. Please visit www.johnsoncontrols.com.

ES919 board includes the ProtoCessor ASP-485 module.



P001029-B

Figure 114: ES919 Board for Metasys® N2

12.4.2. Configuration

	Fieldbus Port	Inverter Port
Protocol	MetasysN2	MODBUS RTU
Default Baud	9600 8N1	38400 8N2
Default Station ID	11	1

12.4.3. RS485 Connector

The communications port includes a positive pole (+), a negative pole (-) and the ground (G).




Figure 115: RS485 connector for Metasys® N2

12.4.4. LEDs on the ASP485 ProtoCessor Module

BLUE	ORANGE	YELLOW	RED
[L8] [L7] COMMS	[L6] [L5] RUN	[L4] [L3] NO DEFAULT	[L2] [L1] ERROR

LED	COLOUR	DESCRIPTION
L8	BLUE	ON: Field Port packet received OFF: Field Port response sent
L7	BLUE	ON: Inverter Port Send Poll OFF: Inverter Port Receive Valid Response
L6	ORANGE	ON (flashing 2Hz): ProtoCessor is running normally OFF: ProtoCessor is not running
L5	ORANGE	Not Used
L4	YELLOW	ON: MODBUS Slave address set by DIP-switch OFF: MODBUS Default Address at factory default = 11
L3	YELLOW	ON: Baud Rate set by DIP-switch OFF: Baud Rate at factory default = 9600
L2	RED	ON: Bad Poll, No Map Descriptor found OFF: Once Exception response has been sent [*]
L1	RED	ON: Panic OFF: No Panic has occurred

[*] If you receive a poll for data that does not exist, you turn that LED on briefly. Basically, the system received a valid poll, but could not find a corresponding data point.

12.4.5. Baud Rate DIP-switches

B1	
0	Use factory default Baud Rate = 9600 (L3 = OFF)
1	Use Baud from Switches as per table below (L3 = ON)

B2	B3	B4	Baud Rate
0	0	0	1200
1	0	0	2400
0	1	0	4800
1	1	0	9600
0	0	1	19200
1	0	1	38400
0	1	1	57600
1	1	1	115200

12.4.6. Address DIP-Switches

A1-A8	
	Corresponds to the Metasys N2 Address L4 will indicate that the DIP-switch address is being used


12.5. ES919 Board for BACnet/Ethernet

The Module BACnet/Ethernet board uses the Ethernet port to communicate with the system using the BACnet communications protocol.

BACnet - A Data Communication Protocol for Building Automation and Control Networks. Developed under the auspices of the American Society of Heating, Refrigerating and Air-Conditioning Engineers (ASHRAE), BACnet is an American national standard, a European standard, a national standard in more than 30 Countries, and an ISO global standard (**ISO 16484-5**). The protocol is supported and maintained by ASHRAE Standing Standard Project Committee 135 (SSPC 135).

Please see <http://www.bacnet.org>.

This board is composed of the ProtoCessor FFP-485 communications module.



P001030-B

Figure 116: ES919 Board for BACnet/Ethernet


12.5.1. Ethernet Connector

The standard RJ45 connector (IEEE 802) located on the module can be used only for an Ethernet 10/100 (100Base-T, 10Base-T) connection. Pins are located as in any computer card. Pins are as follows:

P000517-0


Decisive voltage class A according to EN 61800-5-1

N.	Name	Description
1	TD+	Positive signal transmission line
2	TD-	Negative signal transmission line
3	RD+	Positive signal reception line
4	Term	Terminated pair - not used
5	Term	Terminated pair - not used
6	RD-	Negative signal reception line
7	Term	Terminated pair - not used
8	Term	Terminated pair - not used



12.5.2. LEDs on the FFP485 ProtoCessor Module

LED	COLOUR	DESCRIPTION
PWR	YELLOW	ON: Module powered OFF: Module not powered
LA	RED	ON (flashing 1Hz): Normal operation OFF: PANIC
LB	RED	ON (flashing 1Hz): Normal operation OFF: PANIC
GP105	RED	ON (goes solid after 45-60s): Normal operation OFF: during the first 45-60s
Rx	YELLOW	Flashing when a message is received on the field port
Tx	YELLOW	Flashing when a message is sent on the field port



P001031-B

Figure 117: BACnet LEDs

12.5.3. Troubleshooting Tips

If **PWR** LED does not come on and **LA** and **LB** do not flash, please contact ENERTRONICA SANTERNO's Customer Service.

If **PWR** LED does not come on but the **LA** and **LB** flash, then the **PWR** LED is faulty.

If **LA** and **LB** do not start flashing, this may indicate a problem with the ProtoCessor. Contact ENERTRONICA SANTERNO's Customer Service.

If **GP105** never comes on, please contact ENERTRONICA SANTERNO's Customer Service.

If **TX** and or **RX** do not flash, this may indicate a problem with the field wiring; the configuration in the ProtoCessor on the field side; incorrect polling parameters (such as COMM properties like baud, parity, etc).

12.5.4. Board Configuration

The BACnet configuration software is available for download from santerno.com, Software tab of the product sheet concerned. To install the software, just run the “Sinus Penta BacNet Setup.exe” file. After installation, run the “Sinus Penta BACnet configurator.exe” file, which will load the BACnet configuration software.




Figure 118: BACnet IP Configuration


To configure and download the settings follow the steps below:

1. Set up a connection on IP address 192.168.1.X from the host PC (Default IP address of the BACnet fieldbus card is 192.168.1.24). DISABLE ANY OTHER NETWORK CARD, ANY FIREWALL OR ANITIVIRUS programs.
2. Connect the host PC to the BACnet device using an Ethernet crossover cable or straight-through cable if connecting from a Hub/Switch.
3. Ping the BACnet device using the “Ping BACnet gateway” button within the BACnet configurator software to ensure communication has been achieved. A command window will appear, containing the IP address of any BACnet fieldbus devices that the host PC can detect.
4. Select your choice of BACnet IP within the BACnet configuration software.
5. Enter a desired IP address, Subnet mask and BACnet port, and select DHCP if required.
6. Enter the BACnet device instance and the Network Number.
7. Click on “Create Files”.
8. Click on “Download config file” to configure the BACnet fieldbus network card.
9. Click on “Download IP data file” to configure the BACnet fieldbus network card.
10. Click on “Restart BACnet Device” after the download has completed.

12.6. ES919 Board for BACnet/RS485

The BACnet/RS485 Module card uses RS485 serial port to communicate with the system via the BACnet MSTP communications protocol.

The card is composed of the ProtoCessor FFP-485 module (see LEDs on the FFP485 ProtoCessor Module and Troubleshooting Tips) and of support/interface board ES919.



P001033-B

Figure 119: ES919 Board for BACnet/RS485



CAUTION

Although communication is made through RS485 serial port, the board shall be configured through the Ethernet port, as explained in the Board Configuration section.

12.6.1. RS485 Connector

The communications port includes the positive pole, the negative pole and the ground.




Figure 120: RS485 connector for BACnet/RS485

12.6.2. Board Configuration

The BACnet fieldbus communication kit contains BACnet configuration software. This software allows the user to set parameters for a specific BACnet installation

After installation, run the “Sinus Penta BACnet configurator.exe” file which will load the BACnet configuration software.




Figure 121: BACnet MSTP Configuration

To configure and download the settings follow the steps below:

1. Mount the BACnet device in the way shown in Figure 116.
2. In order to configure a BACnet MSTP network, you need to configure each module through Ethernet interface.
3. Set up a connection on IP address 192.168.1.X from the host PC (the default IP address of the BACnet fieldbus card is 192.168.1.24). DISABLE ANY OTHER NETWORK CARD, ANY FIREWALL OR ANITIVIRUS program.
4. Connect the host PC to the BACnet device using an Ethernet crossover cable or straight through cable if connecting from a Hub/Switch.
5. Ping the BACnet device using the “Ping BACnet gateway” button within the BACnet configurator software to ensure communication has been achieved. A command window will appear, containing the IP address of any BACnet fieldbus devices that the host PC can detect.
6. Select your choice of BACnet MSTP within the BACnet configuration software.
7. Enter the MAC address, baud rate, parity, # stop bits, # data bits and highest MAC address on the network.
8. Enter the BACnet device instance and the Network Number.
9. Click on “Create Files”.
10. Click on “Download config file” to configure the BACnet fieldbus network card.
11. Click on “Restart BACnet Device” after the download has completed.
12. Mount the BACnet device in the way shown in Figure 119.
13. Connect the device to the BACnet MSTP network and test if the device can be achieved.

13. BRIDGE MINI (SLOT B)

Accessory-Product Compatibility		
Product	Bridge Mini	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	√	
Solardrive Plus	√	

Table 14: Product – Bridge Mini compatibility

The Bridge Mini is a product designed for remote monitoring and remote servicing: its easy-to-use interface running on any Web browser allows you to straightforwardly acquire measurements and operation indicators, display the main trends, upgrade the inverter firmware and download data logs.

The Bridge Mini is able to control devices of any brand and model both via IoT standard protocols and via industrial protocols.

Compact yet highly-performing, it comes in two versions:

- Embedded: installed inside the equipment and powered directly by the inverter for optimum convenience and ease of installation.
- Stand-alone: featuring DIN support for in-cabinet installation.

The Bridge Mini interconnects to the system devices via serial links on two RS485 ports, called COM1 and COM2, and one Ethernet port. USB flash drives may be connected to the Bridge Mini to download data logs.

It is connected to Santerno Cloud via secure and encrypted Internet connections for remote monitoring and remote servicing.



Figure 122: Bridge Mini Embedded



Figure123: Bridge Mini Stand alone

13.1. Identification Data

<i>Description</i>	<i>Part Number</i>
Bridge Mini Embedded	ZZR1007A0
Bridge Mini Stand alone	ZZ4600600

13.2. Installing the Board on the Inverter (Slot B)

Please refer to the **BRIDGE MINI – User Manual**.

13.3. Connectivity

Please refer to the **BRIDGE MINI – User Manual**.

14. ES847 I/O EXPANSION BOARD (SLOT C)

Product-Accessory Compatibility		
Product	ES847 I/O Expansion board	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	√	
Solardrive Plus	√	

Table 15: Product - ES847 I/O Expansion board compatibility

ES847 Board allows implementing an additional I/O set for any product compatible with this accessory. Additional functionality includes:

- XAIN4: One “fast” sampling analog input, 12 bit $\pm 10V$ f.s;
- XAIN5: One “fast” sampling analog input for 0-20mA f.s. sensor measurement, resolution 11 bits
- XAIN7: One “fast” sampling analog input for $\pm 160mA$ f.s. sensor measurements; resolution: 12 bits (Energy Counter option);
- XAIN8/9/10/11: Four “slow” sampling inputs, 12-bit, configurable as 0-10V f.s., 0-20 mA f.s., 0-100 mV f.s., temperature acquisition via two-wire thermistor PT100;
- XAIN12/13: Two “slow” sampling analog inputs, 12-bit, 0-10V f.s.;
- VAP/VBP/VCP: Three voltage inputs for ADE (Energy Counter option);
- IAP/IBP/ICP: Three current inputs for ADE (Energy Counter option);
- XMDI1/2/3/4/5/6/7/8: Eight PNP, 24V multifunction digital inputs; three of them are “fast propagation” inputs and can be used for the acquisition of a PUSH-PULL, 24V encoder;
- XMDO1/2/3/4: Six multifunction digital outputs, OC outputs free from potential to be used both as PNP and NPN inputs, $V_{omax}=48V$, $I_{omax}=50mA$, providing short-circuit protection through a resettable fuse.



CAUTION

Not all I/Os are controlled from all the products. Please refer to the DIP-switch/Note column in ES847 Board Terminals and to the Guide to the Regenerative Application).



CAUTION

If ES847 board is mounted in slot C, ES919 cannot be mounted in slot B (see ES919 Communications Board (Slot B)).

P000266-B




Figure 124: Signal conditioning and additional I/Os board (ES847)

14.1. **Identification Data**

Description	Part Number
ES847/1 Signal conditioning	ZZ0101814

14.2. **Installing ES847 Board on the Inverter (Slot C)**



DANGER

Before gaining access to the components inside the inverter, remove voltage from the inverter and wait at least 20 minutes. Wait for a complete discharge of the internal capacitors to avoid any electric shock hazard.



CAUTION

Electric shock hazard: do not connect/disconnect the signal terminals or the power terminals when the inverter is on. This also prevents the inverter from being damaged.



NOTE

All the screws used to fasten removable parts (terminals cover, serial interface connector, cable plates, etc.) are black, round-head, cross-head screws. When wiring the inverter, remove only this type of screws. If different screws or bolts are removed, the inverter warranty will be no longer valid.

1. Remove voltage from the inverter and wait at least 20 minutes.
2. Remove the whole inverter covering by loosening the four hexagonal screws located on the top side and bottom side of the inverter to reach the fixing spacers and the signal connector (Figure 125 – Slot C.)



CAUTION

Before removing the inverter cover, draw out the keypad and disconnect the cable connecting the keypad to the control board to avoid damaging the link between the keypad and the control board.




Figure 125: Removing the inverter cover; location of slot C

3. Insert the two contact strips supplied in the bottom part of ES847 board; make sure that each contact enters its slot in the connector. Insert ES847 board over the control board of the drive; make sure that each contact enters its slot in the signal connector. Use the screws supplied to fasten board ES847 to the fixing spacers (Figure 126).




Figure 126: Fitting the strips inside ES847 board and fixing the board on slot C

4. Configure the DIP-switches located on board ES847 based on the type of signals to be acquired (see relevant section).
5. For the terminal board wiring, follow the instructions given in the section below.
6. Close the inverter frame by reassembling the cover allowing gaining access to the inverter control terminals.

14.3. ES847 Board Terminals

Screwable terminal board including 12 sections (each section can be individually removed) for 0.08 to 1.5mm² (AWG 28-16) cables.

Decisive voltage class A according to EN 61800-5-1.

N.	Name	Description	I/O Features	DIP-switch/Notes
1-2	XAIN1+ XAIN1-	"Fast" differential auxiliary analog input, $\pm 10V$ f.s., number 1	Vfs = $\pm 10V$, Rin= 10k Ω ; Resolution: 12 bits	n.u.
3	CMA	0V for analog inputs (common to control 0V)	Control board zero Volt	
4-5	+15VM -15VM	Stabilized, bipolar output protected from short-circuits for auxiliary circuits.	+15V, -15V; Iout max: 100mA	
6	CMA	0V for analog inputs (common to control 0V)	Control board zero Volt	
7-8	XAIN2+ XAIN2-	"Fast" differential auxiliary analog input, $\pm 10V$ f.s. number 2	Vfs = $\pm 10V$, Rin= 10k Ω ; Resolution: 12 bits	n.u.
9-10	XAIN3+ XAIN3-	"Fast" differential auxiliary analog input, $\pm 10V$ f.s. number 3	Vfs = $\pm 10V$, Rin= 10k Ω ; Resolution: 12 bits	n.u.
11-12	XAIN4+ XAIN4-	"Fast" differential auxiliary analog input, $\pm 10V$ f.s. number 4	Vfs = $\pm 10V$, Rin= 10k Ω ; Resolution: 12 bits	PD
13	XAIN5	"Fast" auxiliary analog input (current input), number 5	I _{fs} = $\pm 20mA$, Rin= 200 Ω ; Resolution: 12 bits	PD
14	CMA	0V for analog inputs for XAIN5 return	Control board zero Volt	
15	XAIN6	"Fast" auxiliary analog input (current input), number 6	I _{fs} = $\pm 20mA$, Rin= 200 Ω ; Resolution: 12 bits	n.u.
16	CMA	0V for analog inputs for XAIN6 return	Control board zero Volt	
17	XAIN7	"Fast" auxiliary current analog input, number 7 (Energy Counter option)	I _{fs} = $\pm 160mA$, Rin= 33 Ω ; Resolution: 12 bits	PR
18	CMA	0V for analog inputs (common with control 0V)	Control board zero Volt	
19	VAP	Voltage analog input from ES917 – phase R (Energy Counter Option)	Vfs = $\pm 10V$, Rin= 50k Ω ; Resolution: 12 bits	PR
20	VBP	Voltage analog input from ES917 – phase S (Energy Counter Option)	Vfs = $\pm 10V$, Rin= 50k Ω ; Resolution: 12 bits	PR
21	VCP	Voltage analog input from ES917 – phase T (Energy Counter Option)	Vfs = $\pm 10V$, Rin= 50k Ω ; Resolution: 12 bits	PR
22	CMA	0V for analog inputs (common with control 0V)	Control board zero Volt	
23	IAP	Current analog input from CT – phase R (Energy Counter Option)	I _{fs} = $\pm 150mA$, Rin= 33 Ω ; Resolution: 12 bits	PR
24	IBP	Current analog input from CT – phase S (Energy Counter Option)	I _{fs} = $\pm 150mA$, Rin= 33 Ω ; Resolution: 12 bits	PR
25	ICP	Current analog input from CT – phase T (Energy Counter Option)	I _{fs} = $\pm 150mA$, Rin= 33 Ω ; Resolution: 12 bits	PR
26	CMA	0V for analog inputs (common with control 0V)	Control board zero Volt	

PD: Used by the firmware of all the products compatible with this accessory.

PR: Used by the Sinus Penta/Penta Marine featuring the Regenerative application when the Energy Counter option is installed.

N.	Name	Description	I/O Features	DIP-switch/Notes
27	XAIN8/T1+	"Slow" configurable auxiliary analog input, number 8	Vfs = 10V, Rin = 30kΩ	SW1.3 = ON SW1.1-2-4 = OFF
			Vfs = 100mV, Rin = 1MΩ	SW1.4 = ON SW1.1-2-3 = OFF
			I fs = 20mA, Rin = 124.5Ω	SW1.2 = ON SW1.1-3-4 = OFF
		Thermistor temperature measurement, number 1	Temperature measurement with PT100 Compliant with IEC 60751 or DIN 43735	SW1.1-4 = ON SW1.2-3 = OFF (default)
28	CMA/T1-	0V for analog inputs for XAIN8 return	Control board zero Volt	
29	XAIN9/T2+	"Slow" configurable auxiliary analog input, number 9	Vfs = 10V, Rin = 30kΩ	SW1.7 = ON SW1.5-6-8 = OFF
			Vfs = 100mV, Rin = 1MΩ	SW1.8 = ON SW1.5-6-7 = OFF
			I fs = 20mA, Rin = 124.5Ω	SW1.6 = ON SW1.5-7-8 = OFF
		Thermistor temperature measurement, number 2	Temperature measurement with PT100 Compliant with IEC 60751 or DIN 43735	SW1.5-8 = ON SW1.6-7 = OFF (default)
30	CMA/T2-	0V for analog inputs for XAIN9 return	Control board zero Volt	
31	XAIN10/T3+	"Slow" configurable auxiliary analog input, number 10	Vfs = 10V, Rin = 30kΩ	SW2.3 = ON SW2.1-2-4 = OFF
			Vfs = 100mV, Rin = 1MΩ	SW2.4 = ON SW2.1-2-3 = OFF
			I fs = 20mA, Rin = 124.5Ω	SW2.2 = ON SW2.1-3-4 = OFF
		Thermistor temperature measurement, number 3	Temperature measurement with PT100 Compliant with IEC 60751 or DIN 43735	SW2.1-4 = ON SW2.2-3 = OFF (default)
32	CMA/T3-	0V for analog inputs for XAIN10 return	Control board zero Volt	
33	XAIN11/T4+	"Slow" configurable auxiliary analog input, number 11	Vfs = 10V, Rin = 30kΩ	SW2.7 = ON SW2.5-6-8 = OFF
			Vfs = 100mV, Rin = 1MΩ	SW2.8 = ON SW2.5-6-7 = OFF
			I fs = 20mA, Rin = 124.5Ω	SW2.6 = ON SW2.5-7-8 = OFF
		Thermistor temperature measurement, number 4	Temperature measurement with PT100 Compliant with IEC 60751 or DIN 43735	SW2.5-8 = ON SW2.6-7 = OFF (default)
34	CMA/T4-	0V for analog inputs for XAIN11 return	Control board zero Volt	
35	XAIN12	"Slow" voltage auxiliary analog input, number 12	Vfs = 10V, Rin = 30kΩ	n.u.
36	CMA	0V for analog inputs for XAIN12 return	Control board zero Volt	n.u.
37	XAIN13	"Slow" voltage auxiliary analog input, number 13	Vfs = 10V, Rin = 30kΩ	n.u.
38	CMA	0V for analog inputs for XAIN13 return	Control board zero Volt	n.u.

N.	Name	Description	I/O Features	DIP-switch/Notes
39	XMDI1	Multifunction auxiliary digital input 1	24Vdc Opto-isolated digital inputs; positive logic (PNP): active with high level signal in respect to CMD (terminals 43 and 50). In compliance with EN 61131-2 as type 1 digital inputs (24Vdc rated voltage).	Maximum response time to processor: 500µs
40	XMDI2	Multifunction auxiliary digital input 2		
41	XMDI3	Multifunction auxiliary digital input 3		
42	XMDI4	Multifunction auxiliary digital input 4		
43	CMD	0 V digital input isolated to control 0 V		
44	+24V	Auxiliary supply output for opto-isolated multifunction digital inputs		
45	XMDI5	Auxiliary multifunction digital input 5		
46	XMDI6 / ECHA / FINA (*)	Auxiliary multifunction digital input 6 / Single-ended, push-pull 24V encoder input, phase A / Frequency input A		Maximum response time to processor: 600ns
47	XMDI7 / ECHB (*)	Auxiliary multifunction digital input 7 / Single-ended, push-pull 24V encoder input, phase B		
48	XMDI8 / FINB	Auxiliary multifunction digital input 8 / Frequency input B		
49	+24V	Auxiliary supply output for opto-isolated multifunction digital inputs	+24V±15%; I _{max} : 200mA Protected by resettable fuse	
50	CMD	0 V digital input isolated to control 0 V	Opto-isolated digital input zero volt	
51	XMDO1	Multifunction auxiliary digital output 1 (collector)	Open collector isolated digital outputs, V _{omax} = 48V; I _{omax} = 50mA	
52	CMDO1	Multifunction auxiliary digital output 1 (emitter)		
53	XMDO2	Multifunction auxiliary digital output 2 (collector)		
54	CMDO2	Multifunction auxiliary digital output 2 (emitter)		
55	XMDO3	Multifunction auxiliary digital output 3 (collector)		
56	CMDO3	Multifunction auxiliary digital output 3 (emitter)		
57	XMDO4	Multifunction auxiliary digital output 4 (collector)		
58	CMDO4	Multifunction auxiliary digital output 4 (emitter)		
59	XMDO5	Multifunction auxiliary digital output 5 (collector)		
60	CMDO5	Multifunction auxiliary digital output 5 (emitter)		
61	XMDO6	Multifunction auxiliary digital output 6 (collector)		
62	CMDO6	Multifunction auxiliary digital output 6 (emitter)		



NOTE

All digital outputs are inactive under the following conditions:

- inverter off;
- inverter initialization stage after power on;
- firmware updating.

Consider this when choosing the inverter application.



(*) CAUTION





Terminals **MDI6/ECHA/FINA** and **MDI7/ECHB** on the control board are no longer active when ES847 is fitted and are automatically replaced by the relevant **XMDI6** and **XMDI7** terminals.





14.4. Configuration DIP-switches




ES847 board is provided with three configuration DIP-switches (Figure 124) setting the operating mode as in the table below.



SW1	Sets the operating mode for “slow” analog inputs XAIN8 and XAIN9
SW2	Sets the operating mode for “slow” analog inputs XAIN10 and XAIN11
SW3	Factory-setting: SW3.2=SW3.5=SW3.7=ON; the other DIP-switches are OFF – Do not change factory-setting–

14.5. Possible Settings for DIP-switches SW1 and SW2

Configuring Slow Analog Channel XAIN8			
Mode: 0-10V f.s. (Default configuration)	Mode: 0-100mV f.s.	Mode: 0-20mA f.s.	Temperature Reading with Thermistor PT100 (default)
			

Setting Slow Analog Channel XAIN9			
Mode: 0-10V f.s. (Default configuration)	Mode: 0-100mV f.s.	Mode: 0-20mA f.s.	Temperature Reading with Thermistor PT100 (default)
			

Setting Slow Analog Channel XAIN10			
Mode: 0-10V f.s. (Default configuration)	Mode: 0-100mV f.s.	Mode: 0-20mA f.s.	Temperature Reading with Thermistor PT100 (default)
			

Setting Slow Analog Channel XAIN11			
Mode: 0-10V f.s. (Default configuration)	Mode: 0-100mV f.s.	Mode: 0-20mA f.s.	Temperature Reading with Thermistor PT100 (default)
			

Five acquisition modes are available (see the Programming Guide) corresponding to four hardware settings (see table below).

Type of Preset Acquisition	Mode Set for SW1 and SW2	Full-scale Values and Notes
Voltage: 0÷10V	Mode: 0-10V f.s.	0÷10V
Voltage: 0÷100mV	Mode: 0-100mV f.s.	0÷100mV
Current: 0÷20 mA	Mode: 0-20mA f.s.	0mA ÷ 20mA
Current: 4÷20 mA	Mode: 0-20mA f.s.	4mA ÷ 20mA. Alarm for measurement < 2mA (cable disconnection) or for measurement > 25mA.
Temperature	Temperature Reading with Thermistor PT100 (default)	-50°C ÷ 125°C. Disconnection alarm or short-circuit sensor if resistance measurement is lower/higher than the preset range.



NOTE

Parameter settings must be consistent with DIP-switch settings. Otherwise, unpredictable results for real acquisition are produced.



NOTE

A voltage/current value exceeding the input range will be saturated at minimum or maximum value.



CAUTION

Inputs configured as voltage inputs have high input impedance and must be closed when active. The disconnection of the conductor relating to an analog input configured as a voltage input does not ensure that the channel reading is “zero”. Proper “zero” reading occurs only if the input is connected to a low-impedance signal source or is short-circuited. Do not series-connect relay contacts to inputs to obtain “zero” reading.

14.6. Wiring Diagrams

14.6.1. Connection of “Fast” Differential Analog Inputs

A differential input allows weakening disturbance due to “ground potentials” generated when the signal is acquired from remote sources. Disturbance is weaker only if wiring is correct.

Each input is provided with a positive terminal and a negative terminal of the differential amplifier. They are to be connected to the signal source and to its ground respectively. Common voltage for the signal source ground and the ground of the CMA auxiliary inputs must not exceed the maximum allowable value.

To reduce noise for a differential input, do the following:

- ensure a common path for the differential torque
- connect the source common to CMA input in order not to exceed the common mode input voltage
- use a shielded cable and connect its braiding to the terminal located next to the inverter terminal boards.

ES847 Board is also provided with an auxiliary supply output protected by a fuse which can be used to power external sensors. Do not exceed the max. current ratings.

Wiring is shown in the figure below:




Figure 127: Connection of a bipolar voltage source to a differential input



NOTE

Connecting terminal CMA to the signal source ground ensures better acquisition standards. Wiring can be external to the shielded cable or it can consist of the optional common connection of the auxiliary supply.



NOTE

Auxiliary supply outputs are electronically protected against temporary short-circuits. After wiring the inverter, check output voltage, because a permanent short-circuit can damage the inverter.

14.6.2. Connection of “Fast” Current Inputs

Three “fast” low-impedance analog inputs are available, which are capable of acquiring sensors with current output. The correct wiring is shown in the diagram below.




Figure 128: Connection of 0÷20mA (4÷20mA) sensors to “fast” current inputs



NOTE

Do not use +24V power supply, available on terminals 44 and 49 in ES847 board, to power 4÷20mA sensors, because it is to be used for the common of the digital inputs (CMD – terminals 43 and 50), not for the common of the analog inputs (CMA). Terminals 44 and 49 are galvanically isolated and must be kept galvanically isolated.

14.6.3. Connecting “Slow” Analog Inputs to Voltage Sources

Use a shielded pair data cable and connect its braiding to the side of ES847 board. Connect the cable braiding to the inverter frame using the special conductor terminals located next to the terminal boards. Although “slow” acquisition analog channels have a cut-off frequency slightly exceeding 10Hz and the mains frequency, which is the main disturbance source, is weakened, make sure that wiring is correct, particularly if the full-scale value is 100mV and if wires are longer than 10 m. The figure below shows a wiring example for the acquisition of a voltage source.

Properly set the DIP-switches for the configuration of the analog channel being used: set the full-scale value to 10V or to 100mV. The setting of the programming parameter must be consistent with the hardware setting.




Figure 129: Connecting a voltage source to a “slow” analog input

14.6.4. Connecting “Slow” Analog Inputs to Current Sources

Figure 128 shows how to connect “slow” analog inputs to current sources. Channels XAIN8, XAIN9, XAIN10, XAIN11—corresponding to terminals 27, 29, 31, 33—are capable of acquiring current signals with a full-scale value of 20mA. Properly set the DIP-switches for the configuration of the analog channel being used: set the full-scale value to 20mA and set the relevant programming parameter to 0÷20mA or 4÷20mA.

14.6.5. Connecting “Slow” Analog Inputs to Thermistor PT100

ES847 board allows reading temperatures directly from the connection of standard thermistors PT100 complying with DIN EN 60751. Two-wire connection is used for easier wiring. Use relatively short cables and make sure that cables are not exposed to sudden temperature variations when the inverter is running. Proper wiring is shown in Figure 130: use a shielded cable and connect its braiding to the inverter metal frame through the special conductor terminals.

If a cable longer than approx. 10 metres is used, measurement calibration is required. For example, if a 1mm² (AWG 17) shielded pair data cable is used, this results in a reading error of approx. +1°C every 10 metres.

To perform measurement calibration, instead of the sensor connect a PT100 sensor emulator set to 0°C (or a 100Ω 0.1% resistor) to the line terminals, then zeroing the measurement offset. More details are given in the Programming Guide.

PT100 emulator allows checking the measurement before connecting the sensor.




Figure 130: Connecting thermoresistors PT100 to analog channels XAIN8–11 / T1–4



NOTE

Parameter settings must be consistent with DIP-switch settings. Otherwise, unpredictable results for real acquisition are produced.



NOTE

A voltage/current value exceeding the input range will be saturated at minimum or maximum value.



CAUTION

Inputs configured as voltage inputs have high input impedance and must be closed when active. The disconnection of the conductor relating to an analog input configured as a voltage input does not ensure that the channel reading is zero. Proper “zero” reading occurs only if the input is connected to a low-impedance signal source or is short-circuited. Do not series-connect relay contacts and inputs to obtain “zero” reading.

14.6.6. Connecting Isolated Digital Inputs

All digital inputs are galvanically isolated from zero volt of the inverter control board. To activate isolated digital inputs, use either isolated supply delivered to terminals 44 and 49 or 24Vdc auxiliary supply. Figure 131 shows the digital input control mode exploiting power inside the inverter and exploiting the output of a control device, such as a PLC. Internal supply (+24 Vdc, terminals 44 and 49) is protected by a 200mA resettable fuse.




Figure 131: PNP input wiring

- A: PNP Command (active to +24V) sent via a voltage free contact
- B: PNP Command (active to +24V) sent from a different device (PLC, digital output board, etc.)

14.6.7. Connection to an Encoder or a Frequency Input

Auxiliary digital inputs XMDI6, XMDI7, XMDI8 may acquire fast digital signals and may be used for the connection to a push-pull single-ended incremental encoder or for the acquisition of a frequency input. Important: When ES847 board is fitted, encoder B functions are no more implemented by the basic terminal board of the control board, but are implemented by ES847 board.



NOTE

When installing ES847 board, encoder B functions are to be shifted from the basic terminal board of the control board to the terminal board of ES847 board.

The incremental encoder must be connected to “fast” digital inputs XMDI6 and XMDI7, as shown in Figure 132.




Figure 132: Connecting the incremental encoder to fast inputs XMDI7 and XMDI8

The encoder shall have PUSH-PULL outputs; its 24V power supply is delivered directly by the isolated supply internal to the inverter—terminals +24V (49) and CMD (50). The maximum allowable supply current is 200mA and is protected by a resettable fuse.

Only encoders described above can be acquired directly by the terminal board of the SINUS PENTA/PENTA MARINE; encoder signals shall have a maximum frequency of 155kHz, corresponding to 1024 pulse/rev at 9000 rpm.

Input XMDI8 can also acquire a square-wave frequency signal ranging from 10kHz to 100kHz, which is converted into an analog value to be used as a reference. Frequency values corresponding to the min. and max. reference can be set up as parameters. Do not exceed the allowable duty-cycle ratings for the frequency inputs.

Signals are sent from a 24V Push-pull output with a reference common to terminal CMD (50), as shown in Figure 133).




Figure 133: Signal sent from a 24V, Push-pull frequency output

14.6.8. Connection to Isolated Digital Outputs

Multifunction outputs XMDO1..8 (terminals 51..62) are all provided with a common terminal (CMDO1..8) which is isolated from the other outputs. They can be used to control both PNP and NPN loads, based on the wiring diagrams shown in Figure 134 and Figure 135.

Electrical conductivity (similar to a closed contact) is to be found between terminal MDO2 and CMDO2 when the output is active, i.e. when the ■ symbol is displayed next to the output. Loads connected as PNP or as NPN are activated.

Outputs can be powered by the inverter isolated power supply or by an external source (24 or 48V – see dashed lines in the figure below).




Figure 134: XMD0x output connection as PNP for relay command with internal power supply




Figure 135: XMD0x output connection as PNP for relay command with external power supply




Figure 136: XMD0x output connection as NPN for relay command with internal power supply




Figure 137: XMD0x output connection as NPN for relay command with external power supply



CAUTION

When inductive loads (e.g. relay coils) are connected, always use the freewheel diode, which is to be connected as shown in the figure.



NOTE

Do not simultaneously connect the isolated internal supply and the auxiliary supply to power the isolated digital outputs. Dashed lines in the figures are alternative to standard wiring.



NOTE

Digital outputs XMD01..8 are protected from a temporary short-circuit by a resettable fuse. After wiring the inverter, check the output voltage, as a permanent short-circuit can cause irreversible damage.

14.7. Environmental Requirements

Operating temperature	-10 to +55°C ambient temperature (contact Enertronica Santerno S.p.A. for higher ambient temperatures)
Relative humidity	5 to 95% (non-condensing)
Max. operating altitude	2000 m a.s.l. For installation above 2000 m and up to 4000 m, please contact Enertronica Santerno S.p.A..

14.8. Electrical Ratings**14.8.1. Analog Inputs**

<i>Fast Sampling Analog Inputs, ±10V f.s.</i>	Value			
	Min.	Type	Max.	Unit
Input impedance		10		kΩ
Offset cumulative error and gain in respect to full-scale value		0.5		%
Temperature coefficient of the gain error and offset			200	ppm/°C
Digital resolution			12	bit
Value of voltage LSB		5.22		mV/LSB
Common mode maximum voltage over differential inputs	-15		+15	V
Permanent overload over inputs with no damage	-30		+30	V
Input filter cut-off frequency (2nd order Butterworth filter)		5.1		kHz
Sampling time (depending on the software being used)	0.2		1.2	ms

<i>Fast Sampling Analog Inputs for Current Measurement</i>	Value			
	Min.	Type	Max.	Unit
Input impedance		200		Ω
Offset cumulative error and gain in respect to full-scale value		0.5		%
Temperature coefficient of the gain error and offset			200	ppm/°C
Digital resolution			12	bit
Value of current LSB		13		μA/LSB
Equivalent resolution in 0-20mA acquisition mode			10.5	bit
Permanent overload over inputs with no damage	-5		+5	V
Input filter cut-off frequency (2nd order Butterworth filter)		5.1		kHz
Sampling time (depending on the software being used)	0.2		1.2	ms

<i>Slow Sampling Analog Inputs Configured in 0-10V mode</i>	<i>Value</i>			
	<i>Min.</i>	<i>Type</i>	<i>Max.</i>	<i>Unit</i>
Input impedance		40		kΩ
Offset cumulative error and gain in respect to full-scale value		0.5		%
Temperature coefficient of the gain error and offset			200	ppm/°C
Digital resolution			12	bit
Value of voltage LSB		2.44		mV/LSB
Permanent overload over inputs with no damage	-30		+30	V
Input filter cut-off frequency (1st order low pass filter)		13		Hz
Sampling time (depending on the software being used)	10		1000	ms

<i>Slow Sampling Analog Inputs Configured in 0-20mA mode</i>	<i>Value</i>			
	<i>Min.</i>	<i>Type</i>	<i>Max.</i>	<i>Unit</i>
Input impedance		124.5		Ω
Offset cumulative error and gain in respect to full-scale value		0.5		%
Temperature coefficient of the gain error and offset			200	ppm/°C
Digital resolution			12	bit
Value of current LSB		4.90		μA/LSB
Permanent overload over inputs with no damage	-3.7		+3,7	V
Input filter cut-off frequency (1st order low pass filter)		13		Hz
Sampling time (depending on the software being used)	10		1000	ms

<i>Slow Sampling Analog Inputs Configured in 0-100mV mode</i>	<i>Value</i>			
	<i>Min.</i>	<i>Type</i>	<i>Max.</i>	<i>Unit</i>
Input impedance	1			MΩ
Offset cumulative error and gain in respect to full-scale value		0.2		%
Temperature coefficient of the gain error and offset			50	ppm/°C
Digital resolution			12	bit
Value of voltage LSB		24.7		μV/LSB
Permanent overload over inputs with no damage	-30		+30	V
Input filter cut-off frequency (1st order low pass filter)		13		Hz
Sampling time (depending on the software being used)	10		1000	ms

<i>Slow Sampling Analog Inputs Configured in PT100 Temperature Measurement Mode</i>	<i>Value</i>			
	<i>Min</i>	<i>Type</i>	<i>Max</i>	<i>Unit .</i>
Type of probe	Two-wire PT100 Thermistor			
Measurement range	-50		260	°C
Polarization current for PT100		0.49		mA
Measurement temperature coefficient			50	ppm/°C
Digital resolution			11	bit
Measurement max. cumulative error for temperature ranging from -40 to +55°C		0.5	1.5	°C
Mean value of temperature LSB (linearization SW function)		0.135		°C/LSB
Permanent overload over inputs with no damage	-10		+10	V
Input filter cut-off frequency (1st order low pass filter)		13		Hz
Sampling time (depending on the software being used)	10		1000	ms

14.8.2. Digital Inputs

<i>Features of the Digital Inputs</i>	<i>Value</i>			
	<i>Min.</i>	<i>Type</i>	<i>Max.</i>	<i>Unit</i>
Input voltage for XMDIx in respect to CMD	-30		30	V
Voltage corresponding to logic level 1 between XMDIx and CMD	15	24	30	V
Voltage corresponding to logic level 0 between XMDIx and CMD	-30	0	5	V
Current absorbed by XMDIx at logic level 1	5	9	12	mA
Input frequency over “fast” inputs XMDI6..8			155	kHz
Allowable duty-cycle for frequency inputs	30	50	70	%
Min. time at high level for “fast” inputs XMDI6..8	4.5			µs
Isolation test voltage between terminals CMD (43 and 50) in respect to terminals CMA (3-6-14-16-18-28-30-32-34-36-38)	500Vac, 50Hz, 1min.			

14.8.3. Digital Outputs

<i>Features of the Digital Outputs</i>	<i>Value</i>			
	<i>Min.</i>	<i>Type</i>	<i>Max.</i>	<i>Unit</i>
Working voltage range for outputs XMDO1..6	20	24	50	V
Max. current that can be switched from outputs XMDO1..6			50	mA
Voltage drop of outputs XMDO1..6, when active			2	V
Leakage current of outputs XMDO1..6, when active			4	μA
Isolation test voltage between terminals CMDO1..6 and CMA	500Vac, 50Hz, 1min.			

14.8.4. Supply Outputs

<i>Features of the Analog Supply Outputs</i>	<i>Value</i>			
	<i>Min.</i>	<i>Type</i>	<i>Max.</i>	<i>Unit</i>
Voltage available on terminal +15V (4) in respect to CMA (6)	14.25	15	15.75	V
Voltage available on terminal -15V (5) in respect to CMA (6)	-15.75	-15	-14.25	V
Max. current that can be delivered from +15V output and that can be absorbed by output -15V			100	mA

<i>Features of the Digital Supply Outputs</i>	<i>Value</i>			
	<i>Min.</i>	<i>Type</i>	<i>Max.</i>	<i>Unit</i>
Voltage available on +24V terminals (44, 49) in respect to CMD (43, 50)	21	24	27	V
Max. current that can be delivered from +24V output			200	mA



CAUTION

Irreversible faults occur if the min./max. input/output voltage ratings are exceeded.



NOTE

The isolated supply output and the analog auxiliary output are protected by a resettable fuse capable of protecting the power supply unit inside the inverter against short-circuits. Nevertheless, in case of short-circuit, it can happen that the inverter does not temporarily lock and does not stop the motor.


15. ES870 RELAY I/O EXPANSION BOARD (SLOT C)

Product-Accessory Compatibility		
Product	ES870 I/O Expansion board	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	√	
Solardrive Plus	√	

Table 16: Product – ES870 I/O Expansion board compatibility

The ES870 board is an expansion board for the digital I/Os of all the products compatible with this accessory. The ES870 board includes:

- XMD11/2/3/4/5/6/7/8: Eight 24V multifunction digital inputs, type PNP. Three inputs are “fast propagation” inputs that can be used also for PUSH-PULL 24V encoder acquisition;
- XMDO1/2/3/4/5/6: Six multifunction relay digital outputs (Vomax = 250 VAC, Iomax = 5A, Vomax = 30 VDC, Iomax = 5A).



P001036-B

Figure 138: Relay I/O expansion board ES870



CAUTION

If ES870 board is fitted into slot C, ES919 cannot be mounted in slot B (see ES919 Communications Board (Slot B)).

15.1. Identification Data

Description	Part Number
Relay I/O Board	ZZ0101840

15.2. Installing ES870 Board on the Inverter (Slot C)



DANGER

Before gaining access to the components inside the inverter, remove voltage from the inverter and wait at least 20 minutes. Wait for a complete discharge of the internal capacitors to avoid any electric shock hazard.



CAUTION

Electric shock hazard: do not connect/disconnect the signal terminals or the power terminals when the inverter is on. This also prevents the inverter from being damaged.



NOTE

All the screws used to fasten removable parts (terminals cover, serial interface connector, cable plates, etc.) are black, round-head, cross-head screws. When wiring the inverter, remove only this type of screws. If different screws or bolts are removed, the inverter warranty will be no longer valid.

1. Remove voltage from the inverter and wait at least 20 minutes.
2. Remove the whole inverter covering by loosening the four hexagonal screws located on the top side and bottom side of the inverter to reach the fixing spacers and the signal connector (Figure 139 – Slot C.)



CAUTION

Before removing the inverter cover, draw out the keypad and disconnect the cable connecting the keypad to the control board to avoid damaging the link between the keypad and the control board.




Figure 139: Removing the inverter cover; location of slot C

3. Insert the two contact strips supplied in the bottom part of ES870 board; make sure that each contact enters its slot in the connector. Insert ES870 board over the control board of the drive; make sure that each contact enters its slot in the signal connector. Use the screws supplied to fasten board ES870 to the fixing spacers.
4. For the terminal board wiring, follow the instructions given in the section below.
5. Close the inverter frame by reassembling the cover allowing gaining access to the inverter control terminals.

15.3. ES870 Board Terminals

Screwable terminal board in two extractable sections suitable for cross-sections 0.08 ÷ 1.5mm² (AWG 28-16)

Decisive voltage class A according to EN 61800-5-1.

N.	Name	Description	I/O Features	Notes	
1	XMDI1	Multifunction auxiliary digital input 1	Opto-isolated digital inputs 24 VDC; positive logic (PNP): active with positive input in respect to 0VE (terminals 6 or 12). In compliance with EN 61131-2 as type-1 digital inputs with rated voltage equal to 24 VDC.	Maximum response time to microprocessor: 500µs	
2	XMDI2	Multifunction auxiliary digital input 2			
3	XMDI3	Multifunction auxiliary digital input 3			
4	XMDI4	Multifunction auxiliary digital input 4			
5	+24VE	Auxiliary supply output/input for opto-isolated multifunction digital inputs/relay coils (*)	+24V±15% ; I _{max} output: 125mA; I _{max} input: 75mA Protected with resettable fuse.	Maximum response time to microprocessor: 600ns	
6	0VE	0V for digital inputs isolated in respect to control 0V	Opto-isolated zero volt for digital inputs; test voltage 500Vac 50Hz 1' in respect to inverter CMA inputs		
7	XMDI5	Multifunction auxiliary digital input 5	Opto-isolated digital inputs 24 VDC; positive logic (PNP): active with positive input in respect to 0VE (terminals 6 or 12). In compliance with EN 61131-2 as type-1 digital inputs with rated voltage equal to 24 VDC.		...500µs
8	XMDI6 / ECHA / FINA (*)	Multifunction auxiliary digital input 6 /Push-pull 24V single-ended phase A encoder input/Frequency input A			
9	XMDI7 / ECHB (*)	Multifunction auxiliary digital input 7/ Push-pull 24V single-ended phase B encoder input			
10	XMDI8 / FINB	Multifunction auxiliary digital input 8/ Frequency input B			
11	+24VE	Auxiliary supply output/input for opto-isolated multifunction digital inputs/relay coils (**)	+24V±15% ; I _{max} output: 125mA; I _{max} input: 75mA Protected with resettable fuse.		
12	0VE	0V for digital inputs isolated in respect to control 0V	Opto-isolated zero volt for digital inputs; test voltage 500Vac 50Hz 1' in respect to inverter CMA inputs		



(*)
CAUTION

Terminals **MDI6/ECHA/FINA** and **MDI7/ECHB** on the control board are no longer active when ES847 is fitted and are automatically replaced by the relevant **XMDI6** and **XMDI7** terminals.



(**)
NOTE

The total load on +24VE inverter connection must not exceed 200mA. The total load is referred to all +24VE connections available on the main terminal board and the option terminal board. The relay coils fitted on ES870 option board can sink up to 75mA from +24VE. Coil consumption must be subtracted from the 200mA rated current capability.

By opening jumper J1, terminal n. 5 and 11 can be used as +24Vdc supply input for relay coils, unloading the inverter internal power supply.

Screwable terminal board in three extractable sections suitable for cross-sections 0.2 ÷ 2.5mm² (AWG 24-12)

Decisive voltage class C according to EN 61800-5-1

N.	Name	Description	I/O Features
13	XDO1-NC	Multifunction, relay digital output 1 (NC contact)	Change-over contact: with low logic level, common terminal is closed with NC terminal; with high logic level, common terminal is open with NO; Resistive load capability: Vomax = 250 VAC, Iomax = 5A Vomax = 30 VDC, Iomax = 5A Inductive load capability (L/R=7ms): Vomax = 250 VAC, Iomax = 1.5A Vomax = 30 VDC, Iomax = 1.5A Isolation test voltage between contacts and coil 2500Vac 50Hz, 1' Min. load: 15mA, 10Vdc
14	XDO1-C	Multifunction, relay digital output 1 (common)	
15	XDO1-NO	Multifunction, relay digital output 1 (NO contact)	
16	XDO2-NC	Multifunction, relay digital output 2 (NC contact)	
17	XDO2-C	Multifunction, relay digital output 2 (common)	
18	XDO2-NO	Multifunction, relay digital output 2 (NO contact)	
19	XDO3-NC	Multifunction, relay digital output 3 (NC contact)	
20	XDO3-C	Multifunction, relay digital output 3 (common)	
21	XDO3-NO	Multifunction, relay digital output 3 (NO contact)	
22	XDO4-NC	Multifunction, relay digital output 4 (NC contact)	
23	XDO4-C	Multifunction, relay digital output 4 (common)	
24	XDO4-NO	Multifunction, relay digital output 4 (NO contact)	
25	XDO5-NC	Multifunction, relay digital output 5 (NC contact)	
26	XDO5-C	Multifunction, relay digital output 5 (common)	
27	XDO5-NO	Multifunction, relay digital output 5 (NO contact)	
28	XDO6-NC	Multifunction, relay digital output 6 (NC contact)	
29	XDO6-C	Multifunction, relay digital output 6 (common)	
30	XDO6-NO	Multifunction, relay digital output 6 (NO contact)	

15.4. Connection to an Encoder or a Frequency Input

Auxiliary digital inputs XMDI6, XMDI7, XMDI8 may acquire fast digital signals and may be used for the connection to a push-pull single-ended incremental encoder or for the acquisition of a frequency input.



NOTE

When ES847 board is fitted, encoder B functions are no more implemented by the basic terminal board of the control board, but are implemented by ES847 board.

The electrical ratings of the aux digital inputs above are the same as the corresponding inputs in optional control board ES847.

For more details, please refer to Connection to an Encoder or a Frequency Input and ES847 Board Terminals.

16. I/O EXPANSION BOARD 120/240VAC ES988 (SLOT C)

Product-Accessory Compatibility		
Product	ES988 I/O Expansion board	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	√	
Solardrive Plus	√	

Table 17: Product – ES988 I/O Expansion board compatibility

The ES988 option board 120/240Vac allows incrementing the digital I/O set of all the products compatible with this accessory.

The additional functions made available by ES988 option board are the following:

- N. 8 multifunction opto-isolated digital inputs. Each input features:
120 Vac ÷ 240 Vac +10% / -15% supply voltage; 50 / 60 Hz frequency
- N. 4 relay multifunction digital outputs. Each output features:

N.1 changeover contact (Vomax = 250 VAC, Iomax = 6 A, Vomax = 30 VDC, Iomax = 6 A)

The digital inputs are divided into four groups; each group features three terminals: two terminals as the inputs and one terminal as the common for the whole group.

The two inputs of each group are to be powered by a single-phase circuit, with the neutral connected to the common of the group.

The four groups are isolated from each other, so that they can be powered also by four different power supply sources.

All digital inputs and relay outputs are programmable. For the programming parameters related to ES988 option board, please refer to the Programming Guide.

Figure 140 shows ES988 option board including the description of the terminal blocks:




Figure 140: ES988 option board, DIGITAL I/O 120/240 Vrms

16.1. Identification Data

Description	Part Number
ES988 DIGITAL I/O 120/240 Vrms	ZZR0988A0

16.2. Installing the ES988 Option Board on the Drives (SLOT C)

1. Remove voltage from the inverter and wait at least 20 minutes.
2. The electronic components of the inverter and the board are sensitive to the electrostatic discharges. Take all the necessary safety measures before accessing the inverter and handling the board. The board should be installed in a workstation equipped with proper grounding and provided with an antistatic surface. If this is not possible, the installer must wear a ground bracelet properly connected to the PE conductor.

 <p>P000099-0</p>	<p>ATTENTION Static Sensitive Devices. Handle Only at Static Safe Work Stations.</p>	<p>ATTENTION Circuits sensibles à l'électricité statique. Manipulation uniquement autorisée sur un poste de travail protégé.</p>	<p>ACHTUNG Elektrostatisch gefährdete Bauelemente. Handhabung daher nur an geschützten Arbeitsplätzen erlaubt.</p>
--	---	---	---

3. Loosen the two front screws located in the lower part of the inverter cover to remove the covering of the terminal board. You can then reach slot C in the control board where the ES988 is to be installed, as shown in Figure 141.




Figure 141: Location of slot C inside the terminal board cover

4. Insert the communications board into slot C. Make sure that the terminal strips with the two connectors in slot C (CN7A and CN7B) are correctly aligned See Figure 142. If the board is correctly installed, the four fastening holes will match with the housings of the fastening screws for the fixing spacers. Tighten the board fixing screws as shown in Figure 177.





Figure 142: Terminal strips inserted into SLOT C



S000508

Figure 143: Fastening ES988 option board inside the inverter

5. Apply voltage to the inverter and check if LED L1 (+5V voltage correctly applied to board ES988) comes on. Program the parameters related to auxiliary board ES988 following the instructions given in the Programming Guide.



DANGER

Before gaining access to the components inside the inverter, remove voltage from the inverter and wait at least 20 minutes. Wait for the complete discharge of the internal capacitors to avoid electric shock hazard.



CAUTION

Do not connect or disconnect signal terminals or power terminals when the inverter is powered to avoid electric shock hazard and to avoid damaging the inverter and/or the connected devices.



NOTE

All fastening screws for removable parts (terminal cover, serial interface connector, cable path plates, etc.) are black, rounded-head, cross-headed screws.

Only these screws may be removed when connecting the equipment. Removing different screws or bolts will void the product guarantee.

16.3. Digital Input Terminals and Relay Output

Loose terminal blocks, 5.08 mm pitch.



Figure 144 shows the pin layout seen from the cable entry.




Figure 144: Input-output signal terminal blocks

Decisive voltage class C according to EN 61800-5-1

N.	Name	Description
1	COM1	Relay output 1 common
2	NC1	NC Relay output 1
3	NO1	NO Relay output 1
4	COM2	Relay output 2 common
5	NC2	NC Relay output 2
6	NO2	NO Relay output 2
7	COM3	Relay output 3 common
8	NC3	NC Relay output 3
9	NO3	NO Relay output 3
10	COM4	Relay output 4 common
11	NC4	NC Relay output 4
12	NO4	NO Relay output 4
13	MDI1	Digital input 1
14	COM1-2	Digital inputs 1-2 common
15	MDI2	Digital input 2
16	MDI3	Digital input 3
17	COM3-4	Digital inputs 3-4 common
18	MDI4	Digital input 4
19	MDI5	Digital input 5
20	COM5-6	Digital inputs 5-6 common
21	MDI6	Digital input 6
22	MDI7	Digital input 7
23	COM7-8	Digital inputs 7-8 common
24	MDI8	Digital input 8



CAUTION

The cable cross-section required for wiring the digital inputs is 0.5 ÷ 2.5 mm². The operating voltage must not be lower than the digital input supply voltage.



CAUTION

The cable cross-section required for wiring the relay outputs is 0.5 ÷ 2.5 mm². The operating voltage must not be lower than the relay output supply voltage. The cable cross-section required for the relay outputs is based on the operating current in the relay output contacts.



NOTE

The cable path of the digital input cables must not be parallel to the motor cables and must not be close to disturbance sources (relays, motors, inverters, solenoids): the minimum clearance required is over 100 mm.

16.4. ES988 Operating Mode

Figure 145 shows the block diagram of ES988 board as per the digital inputs acquired from the field, the activation of the relay digital outputs to the field and the interface to the control board.

Figure 145 shows the position of LED L1 indicating that +5 V supply voltage is present.




Figure 145: Block diagram for ES988 interfacing

Figure 146 shows an example of how to use digital inputs MDI1-2 and MDI3-4 energized via the same 120 ÷ 240 Vrms single-phase source.




Figure 146: Utilization example of digital inputs on ES988 option board

16.5. Main Features

Santerno drives compatible with this accessory equipped with ES988 option board meet the requirements of EMC Directive 2004/108/CE and LVD 2006/95/CE issued by the European Union. They also comply with the relevant Harmonized Standards.

ES988 option board is made of 'UL approved' materials and components.



NOTE

The installer is responsible for the observance of all the local regulations in force concerning wiring, health and safety and electromagnetic compatibility.
Carefully consider the conductor cross-sections, the fuses or other safety devices to be installed, as well as the Protective Earthing connection.

16.6. Environmental Conditions

Operating temperature	-10 to +55°C ambient temperature (contact Enertronica Santerno S.p.A. for higher ambient temperatures)
Relative humidity	5 to 95% (non-condensing)
Max. operating altitude	2000 m a.s.l. For installation above 2000 m and up to 4000 m, please contact Enertronica Santerno S.p.A..

16.7. Electrical Specifications

Decisive voltage class C according to EN 61800-5-1

<i>Digital Input Static Specs</i>	<i>Value</i>			
	<i>Min.</i>	<i>Typ.</i>	<i>Max.</i>	<i>Unit</i>
Type of input signal MDI1-2 (MDI1, MDI2 in respect to COM1-2) MDI3-4 (MDI3, MDI4 in respect to COM3-4) MDI5-6 (MDI5, MDI6 in respect to COM5-6) MDI7-8 (MDI7, MDI8 in respect to COM7-8)	Digital inputs from the field			
Input voltage range		120/240	265	V AC
Voltage level for signal "1"	90			V AC
Voltage level for signal "0"			20	V AC
Input current range @ 50 Hz	1.5	1.8 / 3.6	4	mA AC
Input current range @ 60 Hz	1.8	2.2 / 4.4	4.8	mA AC



CAUTION

Exceeding the maximum allowable input voltage ratings will result in irreparable damage to the apparatus.

<i>Digital Input Electrical Isolation</i>	<i>Value</i>
Isolation of digital inputs MDI1-2 (MDI1, MDI2 in respect to COM1-2)	NO galvanic isolation
Isolation of digital inputs MDI3-4 (MDI3, MDI4 in respect to COM3-4)	NO galvanic isolation
Isolation of digital inputs MDI5-6 (MDI5, MDI6 in respect to COM5-6)	NO galvanic isolation
Isolation of digital inputs MDI7-8 (MDI7, MDI8 in respect to COM7-8)	NO galvanic isolation
Isolation between contiguous sets of digital inputs: MDI1-2 in respect to MDI3-4 MDI3-4 in respect to MDI5-6 MDI5-6 in respect to MDI7-8	1.5 kV AC @ 50 Hz, 60 s
Isolation between digital inputs and Protective Earthing MDI1-2 in conjunction with MDI3-4, MDI5-6, MDI7-8 in respect to Hole H4 for fixing Protective Earthing to control board	1.5 kV AC @ 50 Hz, 60 s
Isolation between digital inputs and control logics MDI1-2 in conjunction with MDI3-4, MDI5-6, MDI7-8 in respect to GND	2.5 kV AC @ 50 Hz, 60 s
Isolation between digital inputs and relay outputs MDI1-2 in conjunction with MDI3-4, MDI5-6, MDI7-8 in respect to MDO1 in conjunction with MDO2, MDO3, MDO4	2.5 kV AC @ 50 Hz, 60 s

<i>Relay Output Static Specs</i>	<i>Value</i>			
	<i>Min.</i>	<i>Typ.</i>	<i>Max.</i>	<i>Unit</i>
Type of output signals MDO1 - MDO2 - MDO3 - MDO4	Relay digital signal to field			
AC voltage range / continuous AC current applicable to the contacts (resistive load)			250 / 6	V/A
AC1 Nominal load applicable to contacts (resistive load)			1500	VA
AC15 Nominal load applicable to contacts (inductive load)			300	VA
DC1 Breaking capacity applicable to the contacts (resistive load)			30 / 6 110 / 0.2 220 / 0.12	V/A
DC switchable minimum load			500 (12 / 10)	mW V/A



CAUTION

Exceeding the maximum allowable output current and voltage will result in irreparable damage to the apparatus.

<i>Relay Output Electrical Isolation</i>	<i>Value</i>
Isolation between contiguous sets of relay outputs MDO1 in respect to MDO2 MDO2 in respect to MDO3 MDO3 in respect to MDO4	1.5 kV AC @ 50 Hz, 60 s
Isolation between relay outputs and Protective Earthing MDO1 in conjunction with MDO2, MDO3, MDO4 in respect to Hole H3 for fixing Protective Earthing to control board	1.5 kV AC @ 50 Hz, 60 s
Isolation between relay outputs and control logics MDO1 in conjunction with MDO2, MDO3, MDO4 in respect to GND	2.5 kV AC @50 Hz, 60 s

17. ES861 RESOLVER AND INCREMENTAL ENCODER BOARD (SLOT C)

Product-Accessory Compatibility		
Product	ES861 Resolver and Encoder board	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	-	
Solardrive Plus	-	

Table 18: Product – ES861 Resolver and incremental encoder board compatibility

The ES861 board acquires resolver signals and converts them into 12-bit digital signals that can be used as speed and/or position feedback for the products compatible with this accessory.



NOTE Please refer to the Programming Guide and the Guide to the Synchronous Motor Application to check the available control algorithms.

The ES861 board also generates the sinusoidal signal for the resolver excitation and features dedicated logics for the acquisition of differential signals sent from incremental encoders and for the control of opto-isolated digital inputs and outputs.

Main features of the ES861 board:

- Resolver to Digital (RtD) conversion allowing selecting motor position readout or speed readout.
- Configurable frequency and amplitude of the excitation signal to acquire the Resolver encoder with different voltage ratios between excitation and sin/cos signals.
- Encoder input compatible with opto-isolated line-driver (TIA/EIA-422) encoders.
- Line Driver (TIA/EIA-422) incremental encoder output compatible with opto-isolated line-driver (TIA/EIA-422) encoders. It is possible to program the input for encoder repetition or the Resolver input at 1024 pulse/rev.
- Possibility of enabling a frequency divider (by 2, 4, 8) for incremental encoder signals coming from line-driver encoders, or for signals obtained from RtD conversion.
- Configurable encoder supply output (5V, 12V, 24V) allowing output voltage fine-tuning.
- Acquisition of No.3 opto-isolated digital inputs.
- Control of No.3 opto-isolated digital outputs.
- Segregated sections of individually repeated encoder input and encoder output.




Figure 147: ES861 Incremental Encoder and Resolver expansion board



CAUTION If ES861 board is fitted into slot C, ES919 board cannot be fitted into slot B (see ES919 Communications Board (Slot B)).

Features of the encoder inputs:

- 77kHz (1024pls @ 4500rpm) for max. input frequency with digital filter enabled
- 155kHz (1024pls @ 9000rpm) for max. input frequency with digital filter disabled
- Input with differential or single-ended signals
- Input signal error detection.

Features of the resolver inputs:

- Configurable excitation frequency ranging from 10kHz to 20 kHz
- Maximum 30 mA RMS current at excitation output
- Maximum 14.4 Vpp (5 VRMS) voltage at excitation output
- Detection of the PTC signal from the Resolver
- 12-bit RtD for positioning (0.0879° x LSB) or speed acquisition range [-60000 ÷ 60000] rpm.

17.1. Identification Data

Description	Part Number	RESOLVER and COMPATIBLE ENCODERS
ES861 Resolver and Incremental Encoder Interface	ZZ0101860	<ul style="list-style-type: none"> • Sin/Cos resolver inputs, 3.6Vpp ± 10% ranging from 10 kHz to 20 kHz. • Incremental encoders with signals on balanced line according to standard TIA/EIA-422 and power supply ranging from 5 to 24V.

17.2. Installing ES861 Board on the Inverter (Slot C)

1. Remove voltage from the inverter and wait at least 20 minutes.
2. The electronic components of the inverter and the board are sensitive to electrostatic discharges. Take any safety measure before operating inside the inverter and before handling the board. The board should be installed in a workstation equipped with proper grounding and provided with an antistatic surface. If this is not possible, the installer must wear a ground bracelet properly connected to the PE conductor.

	ATTENTION	ATTENTION	ACHTUNG
	Static Sensitive Devices. Handle Only at Static Safe Work Stations.	Circuits sensibles à l'électricité statique. Manipulation uniquement autorisée sur un poste de travail protégé.	Elektrostatisch gefährdete Bauelemente. Handhabung daher nur an geschützten Arbeitsplätzen erlaubt.

3. Remove the protective cover of the inverter terminal board by unscrewing the two screws on the front lower part of the cover. Slot C where ES861 board will be installed is now accessible, as shown in the figure below.
4. Insert the ES861 board into Slot C. Make sure that the terminal strips with the two connectors in slot C (CN7A and CN7B) are correctly aligned. If the board is properly installed, the four fixing holes are aligned with the housing of the relevant fixing spacers screws. Check if alignment is correct, then fasten the four fixing screws as show in the figure below.




Figure 148: Location of slot C inside the terminal board cover of the drives




Figure 149: Terminal strips inserted into SLOT C




Figure 150: Fitting the ES861 board inside the drive

5. Configure the supply voltage for the incremental encoder (please refer to the relevant User Manual) by setting the configuration jumper accordingly.
6. Power the inverter and check if the supply voltage delivered to the encoder is appropriate. Set up the parameters relating to "Encoder A" as described in the Programming Guide.
7. Remove voltage from the inverter, wait until the inverter has come to a complete stop and connect the encoder/resolver cable.



DANGER

Before gaining access to the components inside the inverter, remove voltage from the inverter and wait at least 20 minutes. Wait for the complete discharge of the internal capacitors to avoid electric shock hazard.



CAUTION

Do not connect or disconnect signal terminals or power terminals when the inverter is powered to avoid electric shock hazard and to avoid damaging the inverter.



NOTE

All fastening screws for removable parts (terminal cover, serial interface connector, cable path plates, etc.) are black, rounded-head, cross-headed screws.

Only these screws may be removed when connecting the equipment. Removing different screws or bolts will void the product guarantee.

17.2.1. Resolver Connector

D-sub 9-pin female connector. The figure shows a front view of the PIN layout.




Figure 151: Pin layout on the D-sub 9-pin female connector

Decisive voltage class A according to EN 61800-5-1

N.	Name	Description
1	EXC+	Resolver excitation output (direct signal)
2	EXC-	Resolver excitation output (complementary signal)
3	SIN+	Sine signal input (direct)
4	SIN-	Sine signal input (complementary)
5	COS+	Cosine signal input (direct)
6	COS-	Cosine signal input (complementary)
7	PTC1	Terminal 1 of the Resolver PTC
8	PTC2	Terminal 2 of the Resolver PTC
9	0V	Board logics power supply common

17.2.2. Incremental Encoder and Digital Lines Connectors




Figure 152: Input-output signal terminal boards

Decisive voltage class A according to EN 61800-5-1

N.	Name	Description
1	+VEOUT	Incremental encoder power supply output (referred to 0VE)
2	0VE	Isolated power supply common
3	0VE	Isolated power supply common
4	0VE	Isolated power supply common
5	+5V_EXT	Input for external power supply for repeated encoder output* (referred to 0V_EXT)
6	+5VE_INT	Isolated 5V power supply generated internally (referred to 0VE)
7	0V_EXT	External power supply common for repeated encoder output*
8	0VE	Isolated 5V power supply
9	CHA	Channel A input for positive incremental encoder
10	/CHA	Channel A input for inverted incremental encoder (negated)
11	CHB	Channel B input for positive incremental encoder
12	/CHB	Channel B input for inverted incremental encoder (negated)
13	CHZ	Zero index signal
14	/CHZ	Zero index signal (negated)
15	CHA_U	Incremental encoder A signal output from resolver conversion or from encoder input (CHA pin 9) – asserted signal
16	/CHA_U	Incremental encoder A signal output from resolver conversion or from encoder input (/CHA pin 10) – negated signal
17	CHB_U	Incremental encoder B signal output from resolver conversion or from encoder input (CHB pin 11) – asserted signal
18	/CHB_U	Incremental encoder B signal output from resolver conversion or from encoder input (/CHB pin 12) – negated signal
19	CHZ_U	Incremental encoder Z signal output from resolver conversion or from encoder input (CHZ pin 13) – asserted signal
20	/CHZ_U	Incremental encoder Z signal output from resolver conversion or from encoder input (/CHZ pin 14) – negated signal
21	XMDI1	Digital input
22	XMDI2	Digital input
23	XMDI3	Digital input
24	n.c.	
25	n.c.	
26	CMD	Common for digital inputs
27	XMDO1	Digital output 1 (collector)
28	CMDO1	Digital output 1 (emitter)
29	XMDO2	Digital output 2 (collector)
30	CMDO2	Digital output 2 (emitter)
31	XMDO3	Digital output 3 (collector)
32	CMDO3	Digital output 3 (emitter)

(*) In order to get internal power supply of the repeated encoder output, link together terminals 5-6 (+5V_EXT) and 7-8 (0V_EXT).

17.3. ES861 Configuration and Operating Modes

The ES861 board may power both 5V to 24V encoders and allows acquiring signals coming from the Resolver in order to convert the position/speed data into a 12-bit word.

17.4. Configuring and Adjusting the Encoder Supply Voltage

The ES861 board may power encoders having different power supply voltage ratings. A selection jumper and a power supply voltage regulation trimmer are available as shown in the figure below. The jumpers and the trimmer are located on the top side of the board. The possible configurations are given in the table below:

Incremental encoder power supply: VE OUT				No VE OUT
	24V	12V	5V	
J1	X	OFF	ON	X
J2	2-3	1-2	1-2	X
J3	ON	ON	ON	OFF

In 24V mode, the output voltage is fixed and cannot be adjusted. In 5 and 12V mode, the output voltage can be fine-tuned: in 5V mode, the no-load voltage may range from 4.5 to 7V by adjusting each individual trimmer accordingly; in 12V mode, the no-load voltage may range from 10.5 to 17V.

Turn the trimmer clockwise to increase output voltage.

Power supply voltage is to be measured at the encoder supply terminals, thus taking account of cable voltage drops, particularly if a long cable is used.




Figure 153: Jumpers and trimmer for power supply configuration



CAUTION

Supplying the encoder with inadequate voltage may damage the component. Before connecting the cable and after configuring the ES861 board, always use a tester to check the voltage supplied by the board itself.



CAUTION

The repeated encoder output section must be power supplied **ONLY** with $5V \pm 10\%$ voltage to terminals 5 (+5V_EXT) and 7 (0V_EXT). It is recommended that the supply voltage generated by the board is applied. That voltage is available at terminals 6 (+5VE_INT) and 8 (0VE). This configuration is obtained by linking terminals 5-6 and 7-8 together. If the signal receiver of the repeated encoder requires a potential-free signal source, an external power supply source is required ($5V \pm 10\%$ rated).



NOTE

The encoder power supply circuit is provided with an electronic current limiter and a resettable fuse. Should a short-circuit occur in the supply output, shut down the inverter and wait a few minutes to give the resettable fuse time to reset.

17.5. Connecting the Resolver Cable

State-of-the-art connections are imperative. Use shielded cables approved by the Resolver and correctly connect cable shielding.

The recommended connection diagram consists in a multipolar, dual shielded cable with four internal pairs individually shielded and isolated external shield. The inner shields are to be connected to the connector case (SH) connected to ES861 board, while the outer shield shall be connected to the encoder frame, usually in common with the motor case.

The motor must always be earthed as instructed with a dedicated conductor attached directly to the inverter earthing point and routed parallel to the motor power supply cables.

It is not advisable to route the encoder cable parallel to the motor power cables. It is preferable to use a dedicated signal cable conduit.

The figure below illustrates the recommended connection method.




Figure 154: Recommended dual shielded connection for resolver cable



NOTE

The encoder supply output and the encoder signal common are isolated in respect to the common of the analog signals fitted in the inverter terminal board (CMA). Do not connect any conductors in common between the encoder signals and the signals in the inverter terminal board. This prevents isolation from being adversely affected.



CAUTION

The connector of ES861 board shall be connected exclusively to the encoder using one single cable. Do not feed back the cable on terminal boards or DC-link connectors.

Correctly fasten the cable and the connectors both on the encoder side and on ES860 board side. The disconnection of one cable or even a single conductor may lead to inverter malfunction and may cause the motor to run out of control.

17.6. Environmental Requirements

Operating temperatures	-10 to +55°C ambient temperature (contact Enertronica Santerno S.p.A. for higher ambient temperatures)
Relative humidity	5 to 95% (non-condensing)
Max. allowable operating altitude	2000 m a.s.l. For installation above 2000 m and up to 4000 m, please contact Enertronica Santerno S.p.A..

17.7. Electrical Ratings

Decisive voltage class A according to EN 61800-5-1

<i>Incremental encoder power supply output</i>	Value			
	Min	Typ	Max	Unit
Encoder output current, +24V configuration			150	mA
Encoder output current, +12V configuration			200	mA
Encoder output current, +5V configuration			500	mA
24VE Short-circuit protection level			300	mA
Encoder supply voltage adjusting range in 5V mode (no-load voltage)	4.5	5.3	7	V
Encoder supply voltage adjusting range in 12V mode (no-load voltage)	10.5	12.0	17	V

<i>Static characteristics for signal inputs</i>	Value			
	Min	Typ	Max	Unit
Type of input signals, SIN, COS	Resolver signals			
Differential input voltage (between SIN+ and SIN-; between COS+ and COS-)		3.6		V
Input common mode voltage range in respect to AGND	0.2		5	V
Input impedance	1			Mohm
Type of input signals, CHA, CHB, CHZ	Standard TIA/EIA-422			
Differential input voltage range			±7	V
Input common mode voltage range			±7	V
Input impedance	150			ohm
Type of input signals MDI1, MDI2, MDI3 in respect to COM_MDI	Digital signals from the field			
Input voltage range	15	24	30	V

<i>Max. absolute values</i>	<i>Value</i>			
	<i>Min</i>	<i>Typ</i>	<i>Max</i>	<i>Unit</i>
Maximum allowable common mode voltage amplitude for channels CHA, CHB, CHZ	-25		+25	V



CAUTION

Exceeding the maximum differential input or common mode voltages will result in irreparable damage to the apparatus.

<i>Dynamic characteristics of the Resolver to Digital converter</i>	<i>Value</i>			
	<i>Min</i>	<i>Typ</i>	<i>Max</i>	<i>Unit</i>
Band (signal amplitude modulating frequency)	1.5	1.7	2	kHz
Tracking Rate			60000	rpm



CAUTION

Exceeding the input signal frequency limits will result in a wrong measurement of the encoder position and speed. Depending on the control method selected for the inverter, it may also cause the motor to run out of control.

<i>Static characteristics of the digital outputs and the encoder outputs</i>	<i>Value</i>			
	<i>Min</i>	<i>Typ</i>	<i>Max</i>	<i>Unit</i>
Type of input signals CHA_U, CHB_U, CHZ_U	Standard TIA/EIA-422			
High logic level voltage	2.5			V
Low logic level voltage			0.5	V
Limited common mode voltage	±5.6			V
Maximum current	50			mA
Type of output signals, MDOC-E1, MDOC-E2, MDOC-E3	"Open Collector" switch			
Voltage applicable to MDOC without static absorption in "open" configuration			5	V
Maximum current that can be absorbed in "closed" configuration			50	mA



CAUTION

Exceeding the range in the table may cause irreparable damage to the equipment.

<i>Static and dynamic characteristics for resolver signal excitation</i>	<i>Value</i>			
	<i>Min</i>	<i>Typ</i>	<i>Max</i>	<i>Unit</i>
EXC, /EXC Output Voltage (load max. 30 mA, self-adjusted)			14.4	Vpp
EXC, /EXC Frequency	10, 12, 15, 20			kHz

18. ES950 BISS/ENDAT ENCODER BOARD (SLOT C)

Product-Accessory Compatibility		
Product	ES950 BISS/EnDat Encoder board	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	-	
Solardrive Plus	-	

Table 19: Product – ES950 BISS/EnDat Encoder board compatibility



The ES950 BiSS/EnDat encoder board allows connecting absolute encoders with digital serial interface using mutually exclusive BiSS and EnDat 2.2 protocols and allows using them to provide speed feedback and/or position feedback for the products compatible with this accessory.



NOTE

Please refer to the Programming Guide and the Guide to the Synchronous Motor Application.

The absolute measurement allows detecting the exact position of the motor as soon as the inverter is started, thus avoiding demanding alignment checks.

The ES950 board also features control logics for additional functions, such as the acquisition of differential incremental signals from external encoders and the control of opto-isolated digital inputs/outputs.




Figure 155: ES950 encoder BiSS/EnDat board



CAUTION

If ES950 board is fitted into slot C, ES919 board cannot be fitted into slot B (see ES919 Communications Board (Slot B)).

Features of the ES950 board:

- Acquisition of absolute position from SingleTurn/MultiTurn Encoder with balanced digital output (TIA/EIA-485) according to EnDat 2.2 protocol, up to max. 8MHz transmission frequency and variable resolution depending on the type of encoder.
- Acquisition of absolute position from SingleTurn/MultiTurn Encoder with balanced digital output (TIA/EIA-485) according to BiSS protocol, up to max. 10MHz transmission frequency and variable resolution depending on the type of encoder.
- Acquisition of differential incremental encoder signals compatible with opto-isolated line-driver (TIA/EIA-422) encoders.
- Galvanic isolation on all the lines.
- Configurable 5V, 12V, 24V output for BiSS/EnDat encoder supply allowing fine-tuning, isolated from the control logics.
- Configurable 5V, 12V, 24V output for external incremental encoders allowing fine-tuning, isolated from the control logics.
- Possibility to repeat the acquired incremental signals over line-driver (TIA/EIA-422) standard.
- Possibility to enable a frequency divider (by 2, 4, 8) for incremental encoder signals coming from line-driver encoders.
- Acquisition of No.3 opto-isolated digital inputs.
- Control of No.3 opto-isolated digital outputs.

The features for the incremental encoder inputs are as follows:

- 77kHz (1024pls @ 4500rpm) max. input frequency when the digital filter is enabled
- 155kHz (1024pls @ 9000rpm) max. input frequency when the digital filter is disabled
- Input with differential or single-ended signals
- Input signal error detection.

18.1. Identification Data

<i>Description</i>	<i>Part Number</i>	<i>COMPATIBLE ENCODERS</i>
ES950 EnDat Encoder Interface	ZZ0101880	<ul style="list-style-type: none"> • Absolute encoders with balanced digital EnDat interface according to TIA/EIA-485 standard and power supply voltage ranging from 5 to 24V. • Incremental encoders with balanced line signals according to TIA/EIA-422 standard and power supply voltage ranging from 5 to 24V
ES950 BiSS Encoder Interface	ZZ0101890	<ul style="list-style-type: none"> • Absolute encoders with balanced digital BiSS interface according to TIA/EIA-485 standard and power supply ranging from 5 to 24V. • Incremental encoders with balanced line signals according to TIA/EIA-422 standard and power supply voltage ranging from 5 to 24V.

18.2. Installing ES950 Board on the Inverter (Slot C)

1. Remove voltage from the inverter and wait at least 20 minutes.
2. The electronic components in the inverter and the communications board are sensitive to electrostatic discharge. Take any safety measure before operating inside the inverter and before handling the board. The board should be installed in a workstation equipped with proper grounding and provided with an antistatic surface. If this is not possible, the installer must wear a ground bracelet properly connected to the PE conductor.

	ATTENTION	ATTENTION	ACHTUNG
	Static Sensitive Devices. Handle Only at Static Safe Work Stations.	Circuits sensibles à l'électricité statique. Manipulation uniquement autorisée sur un poste de travail protégé.	Elektrostatisch gefährdete Bauelemente. Handhabung daher nur an geschützten Arbeitsplätzen erlaubt.

3. Remove the protective cover of the inverter terminal board by unscrewing the two screws on the front lower part of the cover. Slot C housing the control board of the inverter where ES950 board will be installed is now accessible, as shown in the figure below.
4. Insert ES950 board into Slot C. Make sure that the terminal strips with the two connectors in slot C (CN7A and CN7B) are correctly aligned. If the board is properly installed, the three fixing holes are aligned with the housing of the relevant fixing spacers screws. Check if alignment is correct, then fasten the three fixing screws as show in the figure below.




Figure 156: Location of slot C inside the terminal board cover in the drives




Figure 157: Terminal strips inserted into SLOT C




Figure 158: Fitting the ES950 board inside the inverter

5. Configure the supply voltage for the incremental encoder (please refer to the relevant User Manual) by setting the configuration jumper accordingly.
6. Power the inverter and check if the supply voltage delivered to the encoder is appropriate. Set up the parameters relating to the encoder as described in the Programming Guide.
7. Remove voltage from the inverter, wait until the inverter has come to a complete stop and connect the encoder cable.



DANGER

Before gaining access to the components inside the inverter, remove voltage from the inverter and wait at least 20 minutes. Wait for the complete discharge of the internal capacitors to avoid electric shock hazard.



CAUTION

Do not connect or disconnect signal terminals or power terminals when the inverter is powered to avoid electric shock hazard and to avoid damaging the inverter.



NOTE

All fastening screws for removable parts (terminal cover, serial interface connector, cable path plates, etc.) are black, rounded-head, cross-headed screws.

Only these screws may be removed when connecting the equipment. Removing different screws or bolts will void the product guarantee.

18.2.1. BiSS/EnDat Encoder Connector

D-sub 15-pin female connector (two rows). The figure shows a front view of the pin layout.




Figure 159: Pin layout on CN7 D-sub 15-pin female connector

Decisive voltage class A according to EN 61800-5-1

N.	Name	Description
1	0VE	Common for power supply and signals
2	0VE	Common for power supply and signals
3	+VEOUT_EB	Encoder power supply output
4	+VEOUT_EB	Encoder power supply output
5	DATA+	Positive data signal
6	Earth	Earth connection (PE conductor) if J7 is closed
7	n.c.	
8	TCLK+	Positive clock signal
9	reserved	
10	reserved	
11	n.c.	
12	n.c.	
13	DATA-	Negative data signal
14	n.c.	
15	TCLK-	Negative clock signal
Shell	PE	Connector shield connected to PE conductor of the inverter

18.2.2. Incremental Encoder and Digital Line Connectors




Figure 160: Input-output signal terminal board

Decisive voltage class A according to EN 61800-5-1

N.	Name	Description
1	+VEOUT	Incremental encoder power supply output
2	0VE	Isolated power supply common
3	0VE	Isolated power supply common
4	0VE	Isolated power supply common
5	+5V_EXT	External power supply input for incremental encoder
6	+5V_INT	Isolated 5V power supply generated from ES950 board
7	+0V_EXT	External power supply common
8	0VE	Isolated power supply common
9	CHA	Channel A input for positive incremental encoder
10	/CHA	Channel A input for negative incremental encoder
11	CHB	Channel B input for positive incremental encoder
12	/CHB	Channel B input for negative incremental encoder
13	CHZ	Positive zero index signal
14	/CHZ	Negative zero index signal
15	CHA_U	Encoder simulation (CHA pin 9) - positive signal
16	/CHA_U	Encoder simulation (/CHA pin 10) - negative signal
17	CHB_U	Encoder simulation (CHB pin 11) - positive signal
18	/CHB_U	Encoder simulation (/CHB pin 12) - negative signal
19	CHZ_U	Encoder simulation (CHZ pin 13) - positive signal
20	/CHZ_U	Encoder simulation (/CHZ pin 14) - negative signal
21	XMDI1	Digital input
22	XMDI2	Digital input
23	XMDI3	Digital input
24	n.c.	
25	n.c.	
26	CMD	Common for digital inputs
27	XMDO1	Digital output 1
28	CMDO1	Common for digital input 1
29	XMDO2	Digital output 2
30	CMDO2	Common for digital output 2
31	XMDO3	Digital output 3
32	CMDO3	Common for digital output 3

18.3. ES950 Configuration and Operating Modes

The ES950 encoder interface board may power both 5V to 24V encoders and allows absolute encoders readout via two different protocols based on the same types of signals: one data line and one clock line.

1	BiSS mode	Biss Encoder (differential lines DATA+/ DATA-, TCLK+/ TCLK-)
2	EnDat mode	EnDat Encoder (differential lines DATA+/ DATA-, TCLK+/ TCLK-)

The figure shows the block diagram of the ES950 board for encoder interfacing (independently of whether using the Biss or EnDat protocol) and for interfacing with the control board. The figure also shows the acquisition logics for the digital lines from/to the field and the interface with external incremental encoders (if any).




Figure 161: Block diagram for ES950 board interface

BiSS/EnDat absolute encoders are power supplied via the ES950 board according to their own specifications. Power supply is isolated in respect to the control logics. BiSS/EnDat absolute encoders interface with a Master implemented on FPGA controlling the different protocols to send absolute position information to the control board via parallel interface.

Through the FPGA Master via parallel interface, the control board may read/write additional information internally to the encoder.

The states of the opto-isolated digital inputs/outputs can be accessed via parallel interface as well, whereas the incremental lines coming from the relevant encoder, even if going through the FPGA Master, reach the control board via dedicated lines.

The ES950 board also features an error detecting mechanism for the signals sent from the incremental encoder.

Dedicated outputs make it possible to repeat the acquired encoder signals possibly applying a frequency divider by 2, 4, 8.

The protocol is chosen by programming the board (in off-line mode) accordingly and by setting proper parameters in the control board software.

18.3.1. BiSS Operating Mode

BiSS is an open source serial protocol developed by IC-HAUS. The configuration adopted for the products compatible with this accessory uses the point-point version B allowing reading the encoder absolute position (divided into SingleTurn and MultiTurn depending on the encoder being used) and allowing R/W of the logs internal to the encoder.

18.3.2. EnDat Operating Mode

EnDat is a serial protocol proprietary of Heidenhain. It is dedicated to point-to-point connections with absolute encoders (absolute position information divided by SingleTurn and MultiTurn depending on the encoder). In the products compatible with this accessory, the EnDat protocol allows reading the encoder absolute position and allows R/W of the logs internal to the encoder.

18.3.3. Configuring and Adjusting the Encoder Supply Voltage

The ES950 board may power encoders having different power supply voltage ratings. A selection jumper and a power supply voltage regulation trimmer are available as shown in Figure 162. The jumpers and the trimmer are located on the top side of the board. The possible configurations are given in the table below.

Incremental encoder supply: VE OUT				No VE OUT
	24V	12V	5V	
J1	X	OFF	ON	X
J2	2-3	1-2	1-2	X
J3	ON	ON	ON	OFF




Figure 162: Jumpers and trimmer for power supply configuration

BiSS/EnDat encoder supply: VE OUT EB				No VE OUT EB
	24V	12V	5V	
J6	X	OFF	ON	X
J5	2-3	1-2	1-2	X
J3	ON	ON	ON	OFF

In 24V mode, the output voltage is fixed and cannot be adjusted. In 5 and 12V mode, the output voltage can be fine-tuned: in 5V mode, the no-load voltage may range from 4.5 to 7V by adjusting each individual trimmer accordingly; in 12V mode, the no-load voltage may range from 10.5 to 17V.

Turn the trimmer clockwise to increase output voltage.

This allows meeting the Biss/EnDat encoder requirements by taking account of voltage drops in cables and connector contacts.

- Encoder EnDat (Heidenhain): power supply typically ranges from [3.6÷14]V, [3.6÷5.25]V, [5±5%]V depending on the type of encoder being used. The latest standard, EnDat 2.2, covers [3.6÷14]V.
- Encoder BiSS: [7÷30]V, [10÷30]V, [5±10%]V

Power supply voltage is to be measured at the encoder supply terminals, thus taking account of cable voltage drops, particularly if a long cable is used.



CAUTION

Supplying the encoder with inadequate voltage may damage the component. Before connecting the cable and after configuring the ES950 board, always use a tester to check the voltage supplied by the board itself.



NOTE

The encoder power supply circuit is provided with an electronic current limiter and a resettable fuse. Should a short-circuit occur in the supply output, shut down the inverter and wait a few minutes to give the resettable fuse time to reset.

18.4. Connecting the Encoder Cable

State-of-the-art connections are imperative. Use shielded cables and correctly connect cable shielding. Connect the external shielding directly to the connector plug (ES950 side) and to the connector or to a pin (if any) connected to the encoder frame (motor side). The CN7 connector plug is internally grounded.

If the cable has multiple shieldings, connect the internal shieldings to each other and connect them to the common 0V power supply and signals in ES950 (pin 1 or 2 in 15-pin CN7 connector). Do not connect the internal and external shieldings to each other, either along the cable or to the encoder.

The recommended connection diagram consists in a multipolar, dual shielded cable. The inner shield shall be connected to the connector case connected to ES950 board, while the outer shield shall be connected to the encoder frame, usually in common with the motor frame. If the inner shield is not connected to the encoder frame, this can be connected to the inner braid.

The motor must always be earthed as instructed with a dedicated conductor attached directly to the inverter earthing point and routed parallel to the motor power supply cables.

It is not advisable to route the Encoder cable parallel to the motor power cables. It is preferable to use a dedicated signal cable conduit.

The welding jumper J7 enables grounding pin 6 in CN7 connector:

J7	ON	Pin 6 connected to PE conductor through ES950
	OFF	Pin 6 <i>not</i> connected to PE conductor through ES950

The figure below illustrates the recommended connection method.




Figure 163: Recommended dual shielded connection for encoder cable



NOTE

The encoder supply output and the encoder signal common are isolated in respect to the common of the analog signals fitted in the inverter terminal board (CMA). Do not connect any conductors in common between the encoder signals and the signals in the inverter terminal board. This prevents isolation from being adversely affected.

The connector of ES950 board shall be connected exclusively to the encoder using one single cable.



CAUTION

Correctly fasten the cable and the connectors both on the encoder side and on ES950 board side. The disconnection of one cable or even a single conductor can lead to inverter malfunction and may cause the motor to run out of control.

18.4.1. Environmental Requirements

Operating temperatures	-10 to +55°C ambient temperature (contact Enertronica Santerno S.p.A. for higher ambient temperatures)
Relative humidity	5 to 95% (non-condensing)
Max. allowable operating altitude	2000 m a.s.l. For installation above 2000 m and up to 4000 m, please contact Enertronica Santerno S.p.A..

18.4.2. Electrical Ratings

Decisive voltage class A according to EN 61800-5-1

<i>Encoder supply output</i>	<i>Value</i>			
	<i>Min</i>	<i>Typ</i>	<i>Max</i>	<i>Unit</i>
Encoder output current, +24V configuration			150	mA
Encoder output current, +12V configuration			200	mA
Encoder output current, +5V configuration			500	mA
24VE Short-circuit protection level			300	mA
Encoder supply voltage adjusting range in 5V mode (no-load voltage)	4.5	5.3	7	V
Encoder supply voltage adjusting range in 12V mode (no-load voltage)	10.5	12.0	17	V

<i>Static characteristics of the input signals</i>	<i>Value</i>			
	<i>Min</i>	<i>Typ</i>	<i>Max</i>	<i>Unit</i>
Type of input signals DATA+, DATA-, TCLK+, TCLK-	Standard TIA/EIA-485			
Differential input voltage range			12/-7	V
Input common mode voltage range			12/-7	V
Input impedance (termination)	120			ohm
Type of input signals CHA, CHB, CHZ	Standard TIA/EIA-422			
Differential input voltage range			±7	V
Input common mode voltage range			±7	V
Input impedance	150			ohm
Type of input signals MDI1, MDI2, MDI3 in respect to COM_MDI	Digital signals from the field			
Input voltage range	15	24	30	V

<i>Max. absolute values</i>	<i>Value</i>			
	<i>Min</i>	<i>Typ</i>	<i>Max</i>	<i>Unit</i>
Maximum allowable common mode voltage amplitude causing no damage on inputs DATA+, DATA-, TCLK+, TCLK-	-7		+12	V
Maximum allowable differential voltage amplitude on channels CHA, CHB, CHZ	-25		+25	V



CAUTION

Exceeding the maximum differential input or common mode voltages will result in irreparable damage to the apparatus.

<i>Dynamic characteristics of the input signals</i>	<i>Value</i>
Max. frequency of Biss protocol digital signals	10 MHz
Max. frequency of EnDat protocol digital signals	8 MHz



CAUTION

Exceeding the input signal frequency limits will result in a wrong measurement of the encoder position and speed. Depending on the control method selected for the inverter, it may also cause the motor to run out of control.

<i>Static characteristics of the digital outputs and the encoder outputs</i>	<i>Value</i>			
	<i>Min</i>	<i>Typ</i>	<i>Max</i>	<i>Unit</i>
Type of input signals CHA_U, CHB_U, CHZ_U	Standard TIA/EIA-422			
High logic level voltage	2.5			V
Low logic level voltage			0.5	V
Limited common mode voltage	±5.6			V
Maximum current	50			mA
Type of input signals MDOC-E1, MDOC-E2, MDOC-E3	"Open Collector"			
Voltage applicable to MDOC with no static absorption in "open" configuration			5	V
Maximum current that can be absorbed in "closed" configuration			50	mA



CAUTION

Exceeding the maximum differential input or common mode voltages will result in irreparable damage to the apparatus.

19. ES966 ENCODER BOARD HIPERFACE (SLOT C)

Product-Accessory Compatibility		
Product	ES966 Encoder Hiperface Board	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	-	
Solardrive Plus	-	

Table 20: Product – ES966 Hiperface Encoder board compatibility



The encoder board Hiperface ES966 enables interfacing absolute encoders with digital serial outputs based on Hiperface protocol that can be used as speed feedback and/or position feedback on the products compatible with this accessory.



NOTE

Please refer to the Programming Guide and to the Guide to the Synchronous Motor Application to check the available control algorithms.

The absolute measurement allows getting the exact position of the motor when the system is started; in addition, the current delivered at start is such as to ensure the maximum torque, with no need to perform complex alignment adjustments at start.

The ES966 encoder board features additional functions, such as the acquisition of differential incremental signals from external encoders and the control of opto-isolated digital inputs and outputs.

It is possible to use the ES966 encoder board for Sin/Cos 5ch absolute encoders or Sin/Cos 3ch incremental encoders.

ES966 board also features additional functions:

- Acquisition of differential incremental signals from external encoders.
- Acquisition/implementation of opto-isolated digital links from/to the field.
- Acquisition of a temperature sensor.

The board features are given below:

- Acquisition of absolute position of Hiperface Encoder (RS485 and Sin/Cos) and variable resolution depending on the encoder model.
- Acquisition of differential, incremental encoder signals coming from external sources and compatible with opto-isolated, Line Driver (TIA/EIA-422) encoders.
- Galvanic isolation on all lines from/to external sources.
- Output for Hiperface encoder power supply configurable via hardware at 5V, 12V, 24V with fine-tuning option, isolated from the control logic.
- Output for external incremental encoder power supply configurable at 5V, 12V, 24V with fine-tuning option, isolated from the control logics.
- Possibility of re-addressing the acquired signals (even processed) from incremental encoders to external sources over Line Driver (TIA/EIA-422) standard.
- Acquisition of 3 opto-isolated digital lines coming from the field.
- Implementation of 3 opto-isolated digital lines to the field.
- Acquisition of motor temperature sensor, type PTC, KTY84 or PT100, selectable via DIP-switch.

The features related to the incremental encoder inputs are as follows:

- 77KHz (1024imp @ 4500rpm): max. input frequency with digital filter enabled.

- 155KHz (1024imp @ 9000rpm): max. input frequency with digital filter disabled.
- Input with Differential or Single-Ended signals.
- Error detection over input signals.

The figure below shows the ES966 board including the description of the terminal boards and the components to be used for the board setting:




Figure 164: ES966 Hiperface Encoder Board

19.1. Part Number

<i>Description</i>	<i>Part Number</i>
ES966 Encoder Hiperface	ZZ0101895

19.2. Installing the ES966 Board on the Inverter (SLOT C)

1. Remove voltage from the inverter and wait at least 20 minutes.
2. The electronic components of the inverter and the board are sensitive to electrostatic discharges. Take any safety measure before operating inside the inverter and before handling the board. The board should be installed in a workstation equipped with proper grounding and provided with an antistatic surface. If this is not possible, the installer must wear a ground bracelet properly connected to the PE conductor.



3. Remove the protective cover of the inverter terminal board by unscrewing the two screws on the front lower part of the cover. Slot C where the ES966 board will be installed is now accessible, as shown in the figure below.
4. Insert the ES966 board into Slot C. Make sure that the terminal strips with the two connectors in slot C (CN7A and CN7B) are correctly aligned. See Figure 165, Figure 166 and following figures. If the board is properly installed, the four fixing holes are aligned with the housing of the relevant fixing spacers screws. Check if alignment is correct, then fasten the four fixing screws as show in Figure 167.




Figure 165: Location of slot C inside the terminal board cover of the drive




Figure 166: Inserting terminal strips to slot C




Figure 167: Fixing the ES966 board inside the drive

5. Configure the supply voltage for the incremental encoder (please refer to the relevant User Manual) by setting the configuration jumper accordingly.
6. Power the inverter and check if the supply voltage delivered to the encoder is appropriate. Set up the parameters relating to the encoder as described in the Programming Guide.
7. Remove voltage from the inverter, wait until the inverter has come to a complete stop and connect the encoder cable.



DANGER

Before gaining access to the components inside the inverter, remove voltage from the inverter and wait at least 20 minutes. Wait for the complete discharge of the internal capacitors to avoid electric shock hazard.



CAUTION

Do not connect or disconnect signal terminals or power terminals when the inverter is powered to avoid electric shock hazard and to avoid damaging the inverter.



NOTE

All fastening screws for removable parts (terminal cover, serial interface connector, cable path plates, etc.) are black, rounded-head, cross-headed screws.

Only these screws may be removed when connecting the equipment. Removing different screws or bolts will void the product guarantee.

19.3. HIPERFACE® Encoder Connector

High-density female D-sub 26 connector (three rows): Reference Designator CN4.
Figure 168 shows the location of the pins from the front side.




Figure 168: Pin layout on HD female D-sub 26 connector

The pin layout of High-density female D-sub 26 connector is given in the table below:

Decisive voltage class A according to EN 61800-5-1

N.	Name	Description
1	n.c.	
2	n.c.	
3	DATA-	Inverted RS485 data signal
4	DATA+	Positive RS485 data signal
5	CHB_5-	Incremental encoder, inverted channel B (fast signal B for 5 CH encoder)
6	CHB_5+	Incremental encoder, positive channel B (fast signal B for 5 CH encoder)
7	+VEOUT_EB	Encoder supply output
8	COS+	Hiperface encoder, positive cosine (D+ slow signal for 5 CH encoder)
9	COS-	Hiperface encoder, inverted cosine (D+ slow signal for 5 CH encoder)
10	n.c.	
11	n.c.	
12	n.c.	
13	n.c.	
14	CHA_5+	Incremental encoder, positive channel A (A fast signal for 5 CH encoder)
15	CHA_5-	Incremental encoder, inverted channel A (A fast signal for 5 CH encoder)
16	0VE	Power supply and signal common
17	SIN+	Hiperface encoder, positive sine (C+ slow signal for 5 CH encoder)
18	SIN-	Hiperface encoder, inverted sine (C+ slow signal for 5 CH encoder)
19	Earth	Earth connector (PE conductor) if J7 closed
20	n.c.	
21	n.c.	
22	CHZ_5+	Incremental encoder positive index (fast signal Z for 5 CH encoder)
23	CHZ_5-	Inverted index incremental encoder (fast signal Z for 5 CH encoder)
24	0VE	Power supply and signal common
25	PTC+	Motor temperature sensor, positive signal
26	PTC-	Motor temperature sensor, negative signal
Shell	PE	Connector shield connected to PE conductor of the inverter

19.4. Incremental Encoder Connectors and Digital Lines

Disconnection terminals, 3.81 mm pitch.

Figure 169 shows the pin layout of the terminals from the cable entry front side.




Figure 169: Input-output signal terminals

Decisive voltage class A according to EN 61800-5-1

N.	Name	Description
1	+VEOUT	Incremental encoder power supply output
2	+VEOUT	Incremental encoder power supply output
3	0VE	Isolated power supply output
4	0VE	Isolated power supply output
5	CHA	Incremental encoder positive channel A input
6	/CHA	Incremental encoder inverted channel A input
7	CHB	Incremental encoder positive channel B input
8	/CHB	Incremental encoder inverted channel B input
9	CHZ	Positive mark reference signal
10	/CHZ	Inverted mark reference signal
11	CHA_U	Incremental encoder, positive channel A reproduction output
12	/CHA_U	Incremental encoder, inverted channel A reproduction output
13	CHB_U	Incremental encoder, positive channel B reproduction output
14	/CHB_U	Incremental encoder, inverted channel B reproduction output
15	CHZ_U	Positive mark reference signal reproduction output
16	/CHZ_U	Inverted mark reference signal reproduction output
17	MDI1	Digital input from the field
18	MDI2	Digital input from the field
19	MDI3	Digital input from the field
20	n.c.	
21	n.c.	
22	COM_MDI	Digital input common from the field
23	MDOC1	Digital output 1
24	MDOE1	Digital output 1 common
25	MDOC2	Digital output 2
26	MDOE2	Digital output 2 common
27	MDOC3	Digital output 3
28	MDOE3	Digital output 3 common

19.5. Operating Mode and Configuration of Hiperface Encoder Board

The ES966 encoder board voltage range is from 5 to 24 V and allows the acquisition of Hiperface absolute encoders. It also acquires absolute Sin/Cos 5ch encoders or Sin/Cos 3ch encoders.

Figure 170 shows the operating mode of the ES966 board in terms of interfacing to the encoder device and the control board. The acquisition logic of digital lines to/from the field and the interfacing with external incremental encoders.




Figure 170: Block diagram of ES966 interface board

The Hiperface absolute encoders are supplied by the ES966 control board (isolated in respect to the control logics) and are interfaced with a counterpart implemented onto FPGA controlling the serial protocol and the sin/cos signals decoding. The control board may read/write additional information internally to the encoder by way of the parallel interface through the FPGA.

The states of the opto-isolated digital outputs/inputs may be accessed via parallel interface as well, while the incremental lines coming from the relative encoder, although passing through the FPGA, reach the control board by way of dedicated lines.

The board also implements a mechanism detecting signal errors from the signals coming from the incremental encoder.

Dedicated outputs may re-send the encoder channels externally acquired, also processed by frequency divider (factor 2, 4 and 8).

The protocol is selected by downloading a special firmware to the board FPGA at an off line programming level and by setting up dedicated parameters in the control board software.

The implemented protocols are detailed in the sections below.

19.6. HIPERFACE® Operating Mode

Hiperface is a protocol developed by Sick-Stegmann for the transmission of information on the encoder position for motor control functionality. This protocol extends the ordinary sine/cosine operation through a slow RS485 interface.

During initialization, the slow serial link is used to detect the encoder absolute position; the sensor is then utilized as an ordinary sine/cosine sensor with two differential tracks 1Vpp.

The Hiperface systems offers different benefits, such as redundancy of the position information sent via serial link and unencrypted signal and the utilization of relatively slow signal bands. This makes the Hiperface encoder a robust encoder suitable as a position feedback for brushless drives.

The serial protocol is a request/response one, and each packet includes a checksum allowing checking the integrity of the information contained. The RS485 comms baudrate is 9600bps by default.

When started, the drive sends a READ_POSITION command to the encoder: if no response is detected or a failure in data consistency is found, the drive triggers an encoder error alarm, otherwise, if the motor position is correctly detected, the drive switches to sine/cosine control starting from the initial position read by the RS485 protocol.

The sine/cosine control consists in decoding the position starting from the arctangent of the angle represented by the sine and cosine signals. In order to ensure the correct operation of the sensor even at relatively high speed, the sine/cosine information is controlled at a digital level as well by way of a quadrature decoder.

The maximum allowable bandwidth controlled by the ES966 is 100 kHz, corresponding to 3000 rpm of an encoder at 2048 sinusoids/rev.

19.7. Configuring and Adjusting the Encoder Supply Voltage

The ES966 board may supply encoders with different voltage ratings. For the incremental encoder, the voltage selection jumpers are J1-2-3 and the adjusting trimmer is RV1. For encoder Hiperface, the voltage selection jumpers are J3-5-6 and the adjusting trimmer is RV2.

The possible configurations are given in the tables below:

Incremental encoder power supply: VE OUT				No VE OUT
	24V	12V	5V	
J1	X	OFF	ON	X
J2	2-3	1-2	1-2	X
J3	ON	ON	ON	OFF

Table 21: Configuration of incremental encoder power supply

Hiperface encoder power supply: VE OUT EB				No VE OUT EB
	24V	12V	5V	
J6	X	OFF	ON	X
J5	2-3	1-2	1-2	X
J3	ON	ON	ON	OFF

Table 22: Configuration of Hiperface encoder power supply

In 24V configuration, the output voltage is fixed and cannot be adjusted, while in 5V and 12V configuration, the output voltage may be fine-tuned: in 5V configuration, each trimmer allows adjusting the no-load voltage ranging from 4.5 to 7V; in 12V configuration, the no-load range is from 10.5 to 17V.

The voltage increase may be obtained by adjusting the trimmer clockwise.

In this way, the Hiperface encoders requirements may be met, also considering the voltage drops on the cable and the connector contacts; the typical power supply range is 7 to 12V.

The supply voltage is to be measured directly on the encoder power supply terminals, also considering the voltage drops in the connection cable, especially if this is rather long.



CAUTION

Inadequate voltage ratings for the encoder power supply may cause the encoder malfunction. Use a tester to check the voltage supplied by the ES966 board once it has been configured and before connecting the power supply cable.



NOTE

The power supply circuit of the encoder envisages an electronic current limiter and a resetting fuse. If accidental short-circuits occur on the power supply output, power off the drive and wait a few minutes so that the fuse may be reset.

The jumpers and trimmers are on the top side of the board, see Figure 171.




Figure 171: Location of the jumpers, trimmers and DIP-switches of ES966

19.8. Temperature Sensor Configuration

The ES966 encoder board may acquire the most popular temperature sensors in the electric motors. Two DIP-switches (SW1 and SW2 in Figure 171) are available for the selection of the type of sensor being used.



NOTE

For a correct acquisition of the sensor, set the DIP-switches and the relative parameters accordingly. See the Programming Guide.

The DIP-switches are on the top side of the board. See Figure 171.

The possible configurations are given in Table 23:

	PTC	KTY84	PT100
SW1.1	OFF	ON	OFF
SW1.2	OFF	ON	OFF
SW2.1	OFF	OFF	ON
SW2.2	OFF	OFF	ON

Table 23: DIP-switch configuration for the temperature sensor on ES966

19.9. Connecting the Encoder Cable

It is necessary to carefully connect the drive to the encoder, even if the bandwidths of the Hiperface encoders are typically low (particularly the sine/cosine signals). Typically, shielded CAT 5 cables with twisted pair signal lines are used with capacities lower than 100 pF/m and length lower than 100 m.

It is recommended that double-shielded cables be used by connecting the internal shield to the case of CN4 type D-sub 26 connected to the ES966 board (pin 19) and the external shield to the encoder case, typically in common with the motor case. If the encoder is provided with an external shield that is not connected to the case, the external shield may be connected to the internal one.

In compliance with the applicable standards, the motor must always be earthed with a Y/G safety conductor directly to the earthing point of the drive. In order to meet the EMC requirements related to emissions and immunity for the whole equipment, it is advisable to use a shielded cable for the connection between the drive and the motor. The cable shield is to be connected to the earthing point of the drive. If no shielded cable is used, the Y/G safety conductor shall run in parallel to the motor power supply cables.

Do not run the encoder cable in parallel to the motor power supply cables and close to other disturbance sources (relays, motors, drives, solenoids): in particular, a minimum clearance exceeding 100 mm must be observed. If switching feeder inductors are located in proximity to the motor cable, the minimum allowable clearance must exceed 200 mm. Where possible, use a metal conductor dedicated to the signal cables and connected to earth.

Failure to observe the instructions above may lead to wrong reception of the position information sent from the encoder and encoder malfunction.

Figure 172 shows the recommended connection.

- Drive/motor connection shielded cable (blue), with the shield connected to the drive earthing point (shield orange in colour).
- Drive/motor connection double shielded cable (red in colour): internal shield connected to the case of CN4 connector, D-sub 26 connector on the ES966 board (pin 19); external shield to the encoder case, typically in common with the motor case.




Figure 172: Connection method recommended for the double-shield encoder cable on ES966

The welded jumper J7 (bottom side in the ES966 close to CN4 connector) allows connecting the internal and external shielding of the drive/encoder cable:

- Internal shield of the drive/encoder cable connected to pin 19 in connector CN4.
- External shield of the drive/encoder cable connected to the encoder case, typically in common with the motor case.

J7	ON	Connection of the internal shielding of the drive/encoder cable to PE conductor via ES966
	OFF	NO Connection of the internal shielding of the drive/encoder cable to PE conductor via ES966

Table 24: Configuration of jumper J7

If J7 is OFF (default condition) the external shielding is connected to earth via the encoder case and the motor case, while the internal shield is connected to the case of the D-sub 26 connector but is not connected to the conductor by way of the ES966 board.



NOTE

The encoder supply output and the encoder signal common are isolated in respect to the common of the analog signals fitted in the inverter terminal board (CMA). Do not connect any conductors in common between the encoder signals and the signals in the inverter terminal board. This prevents isolation from being adversely affected.



CAUTION

The connector of the ES966 board shall be connected exclusively to the encoder using one single cable. Correctly fasten the cable and the connectors both on the encoder side and on the ES966 board side. The disconnection of one cable or even a single conductor can lead to inverter malfunction and may cause the motor to run out of control.

19.10. Environmental Requirements

Operating temperature	-10 to +55°C ambient temperature (contact Enertronica Santerno S.p.A. for higher ambient temperatures)
Relative humidity	5 to 95% (non-condensing)
Max. operating altitude	2000 m a.s.l. For installation above 2000 m and up to 4000 m, please contact Enertronica Santerno S.p.A..

19.11. Electrical Specifications

Decisive voltage class A according to EN 61800-5-1

<i>Encoder power supply output</i>	Value			
	Min	Typ	Max	Unit
Encoder power supply output current, +24V configuration			150	mA
Encoder power supply output current, +12V configuration			200	mA
Encoder power supply output current, +5V configuration			500	mA
Short-circuit safety protection device trip level, 24VE			300	mA
Adjusting range of encoder power supply, 5V mode (no-load mode)	4.5	5.3	7	V
Adjusting range of encoder power supply, 12V mode (no-load mode)	10.5	12.0	17	V

<i>Relay Output Static Specs</i>	Value			
	Min	Typ	Max	Unit
Type of input signals, DATA+, DATA-	Standard TIA/EIA-485			
Differential input voltage range			12/-7	V
Input common mode voltage range			12/-7	V
Input impedance (termination)	120			Ohm
Type of input signals, SIN+/SIN-/COS+/COS-	Sincos 1Vpp			
Differential input voltage range	0,9		1,1	V
Input common mode voltage range	1,5	2,5	3,5	V
Input impedance (termination)	120			Ohm
Type of input signals, CHA, CHB, CHZ	Standard TIA/EIA-422			
Differential input voltage range			±7	V
Input common mode voltage range			±7	V
Input impedance (termination)	150			Ohm
Type of input signals, MDI1, MDI2, MDI3 in respect to COM_MDI	Digital from the field			
Input voltage range	10		34	V
Type of PTC input signals	Passive sensor			
Differential input voltage range			1.7	V

<i>Maximum absolute values</i>	<i>Value</i>			
	<i>Min</i>	<i>Typ</i>	<i>Max</i>	<i>Unit</i>
Maximum allowable common mode failure-free voltage amplitude for inputs DATA+, DATA-	-7		+12	V
Maximum allowable common mode and differential mode voltage amplitude for inputs CHA, CHB, CHZ, CHA_5, CHB_5, CHZ_5,	-25		+25	V
Common mode voltage, PTC inputs	0		4	V
Common mode voltage, SIN/COS inputs	0		32	V
Incremental encoder output voltage	0		5	V
Incremental encoder output current (resettable fuse trip threshold)	0		500	mA



CAUTION

Exceeding the maximum differential input or common mode voltages will result in irreparable damage to the apparatus.

<i>Dynamic characteristics of signal inputs</i>	<i>Value</i>
Maximum frequency of Sin/Cos Hiperface signals	100 kHz



CAUTION

Exceeding the input signal frequency limits will result in a wrong measurement of the encoder position and speed. Depending on the control method selected for the inverter, it may also cause the motor to run out of control.

<i>Static characteristics of the digital outputs and the encoder outputs</i>	<i>Value</i>			
	<i>Min</i>	<i>Typ</i>	<i>Max</i>	<i>Unit</i>
Type of input signals, CHA_U, CHB_U, CHZ_U	Standard TIA/EIA-422			
High logic level voltage	2.5			V
Low logic level voltage			0.5	V
Limited common mode voltage	±5.6			V
Maximum current	50			mA
Type of output signals MDOC-E1, MDOC-E2, MDOC-E3	"Open Collector" switch			
Voltage applicable to MDOC with no static absorption in "open" configuration			5	V
Maximum current that can be absorbed in "closed" configuration			50	mA



CAUTION

Exceeding the input signal frequency limits will result in a wrong measurement of the encoder position and speed. Depending on the control method selected for the inverter, it may also cause the motor to run out of control.

20. ES914 POWER SUPPLY UNIT BOARD

Product-Accessory Compatibility		
Product	ES914 Power Supply Unit board	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	√	
Solardrive Plus	√	

Table 25: Product – ES914 Power Supply Unit board compatibility





Figure 173: ES914 Power supply unit board

Description of ES914 board

The ES914 board provides insulated power supply to the drives through the RS485 connector (see Auxiliary Power Supply in the Installation Guide). It is supplied on a board-holder support with a rear plug connector for DIN rail type OMEGA 35mm. Width is 97mm. Cross dimensions are given in the figure below.



S000841

Figure 174: Dimensions of ES914 board

The ES914 board also provides insulation of RS485 signals on the inverter connector. Using the ES914 board is recommended for galvanic insulation between the control circuits of the inverter and the external communication circuits.

3-zone insulation is provided: the 24Vdc supply input section, the RS485 section on the Master side and RS485 + 9Vdc supply output on the inverter side are electrically isolated (see Figure 176).


The ES914 board transmits data in just one direction at a time (half-duplex transmission).

Transmission is typically started by the Master device, that transmits a poll packet. When receiving the start bit and the poll packet, the communication channel of the Master port opens towards the inverter port and it is kept open until the whole packet is received for a time over 4 byte-time at allowable minimum baud-rate. When the transmission time is over, both ports go idle.

The inverter then transmits the response packet. When the start bit of the response packet is received, the communications channel opens on the inverter side towards the Master port; when a second delay time has elapsed, the transmission cycle is complete.

The ES914 board is equipped with two indicator LEDs indicating RS485 communication failures. Wiring mismatch (if any) is also detected.

The ES914 board is provided with transient voltage suppressors (TVS) for the suppression of surge transients caused by bad weather events affecting RS485 serial communication cable reaching the Master device (the external device dialoguing with the inverter via the ES914 board). ES914 board complies with EN 61000-4-5: Level 4, Criterion B.



SHIELDED CABLE FOR RS485 LINK

PE-SHIELD Connection:

- Optional on inverter-side
- On master-side, it makes the signal discharger totally ineffective

Figure 175: Basic wiring diagram for ES914 board




Figure 176: Block-diagram with 3-zone insulation

20.1. **Identification Data**

Description	Part Number
ES914 Adaptor for aux. power supply	ZZ0101790

20.2. **Wiring ES914 Board**

ES914 board includes three terminal boards and two connectors. The signal connections going to the RS485 Master and to the inverter are available both on the screwable terminals and to DB9 connectors. This allows maximum wiring flexibility. The SHIELD and PE conductors are located on the power supply input terminals. The PE conductor is to be connected to the safety conductor of the cabinet where the equipment is installed. The SHIELD connector is the shield of the communication cable reaching the RS485 Master. You can then decide whether and where to connect the cable shield. The specifications of the terminals and the connectors are given below.

- M1 Terminals: power supply of ES914 board – separable terminals, 3.81mm pitch, suitable for 0.08 ÷ 1.5mm² (AWG 28-16) cables.

Decisive voltage class A according to EN 61800-5-1


Terminal N.	Name	Description
1	+24VS	ES914 Power supply input
2	0VS	ES914 Power supply common
3	SHD	Shield of RS485 wire for external connections
4	PE	Protective Earth

- M2 Terminals: RS485 connection to the Master: separable terminals, 3.81mm pitch, suitable for 0.08 ÷ 1.5mm² (AWG 28-16) cables.

Decisive voltage class A according to EN 61800-5-1

Terminal N.	Name	Description
5	RS485 Am	RS485 signal (A) – Master
6	RS485 Bm	RS485 signal (B) – Master
7	0VE	Common for connections to the Master
8	SHD	Shield of RS485 wire
9	PE	Protective Earth

- CN1 Connector: RS485 connection to the Master: male DB9 connector




- M3 Terminals: RS485 connection to the inverter: separable terminals, 3.81mm pitch, suitable for 0.08 ÷ 1.5mm² (AWG 28-16) cables.

Decisive voltage class A according to EN 61800-5-1

Terminal N.	Name	Description
10	RS485 Ai	RS485 (A) signal – Inverter
11	RS485 Bi	RS485 (B) signal – Inverter
12	0VM	Common for connections to the inverter
13	+9VM	Inverter power supply output

- CN2 connector: RS485 connection to the inverter: female DB9 connector



Recommended connection to the inverter

It is recommended that a shielded cable with DB9 connectors be used. Connect both ends of the cable shield so that it is the same PE voltage as the inverter. The shielded cable shall have at least one twisted pair for signals RS485 A and B. Two additional conductors and one additional twisted pair for the conductors of the inverter auxiliary power supply +9VM and 0VM are also required. Make sure that the cable length and cross-section are adequate, thus avoiding excessive voltage drop. For cable length up to 5m, the recommended minimum cross-section is 0.2mm² (AWG24) for the signal conductors and the power supply conductors.

Recommended connection to the Master

It is recommended that a shielded cable with at least one twisted pair be used. The cable shield shall be connected to the SHIELD terminal of the connector. The connection of the cable shield allows full exploitation of the suppressors located on the Master conductors.

The shielded cable shall have at least one twisted pair for signals RS485 A and B and shall propagate the common signal (0VE).

The following specifications are recommended for the shielded cable:

Type of cable	Shielded cable composed of a balanced pair named D1/D0 + common conductor ("Common").
Recommended cable model	Belden 3106 (distributed from Cavitec)
Min. cross-section of the conductors	AWG24 corresponding to 0.25mm ² . For long cable length, larger cross-sections up to 0.75mm ² are recommended.
Max. cable length	500 metres (based on the max. distance between two stations)
Characteristic impedance	Better if exceeding 100Ω (120Ω is typically recommended)
Standard colours	Yellow/brown for D1/D0 pair, grey for "Common" signal

Power Supply LEDs

ES914 board is equipped with three indicator LEDs for indicating the status of the power supply voltage.

LED	Colour	Function
L1	Green	Presence of power supply voltage (5V) in inverter-side RS485 circuits
L2	Green	Presence of inverter power supply voltage (9V)
L3	Green	Presence of power supply voltage (5V) in Master-side RS485 circuits

RS485 FAULT Signals

ES914 board is equipped with two LEDs indicating the fault status for the RS485 signals both on the inverter side and to the Master side. The FAULT indication is valid only when the line is properly terminated, i.e. DIP-switches SW1 and SW2 are “ON”.

LED	Colour	Function
L5	Red	Inverter-side RS485 signal fault
L6	Red	Master-side RS485 signal fault

The following faults can be detected:

- Differential voltage between A and B lower than 450mV
- A or B exceed the common mode voltage range [-7V; 12V]
- A or B connected to fixed voltage (this condition can be detected only when communication is in progress).

Diagnostic Display

Figure 177 shows the indicator LEDs and the configuration DIP-switches of ES914 board.

Configuration of ES914 board

ES914 board includes two 2-position DIP-switches. These DIP-switches allow RS485 line termination to be configured both on inverter-side and on master-side.

DIP-switch	Function	Notes
SW1	Master-side RS485 termination	ON: 150Ω resistor between A and B; 430Ω resistor between A and +5VE; 430Ω resistor between B and 0VE (default) OFF: no termination and polarisation resistor
SW2	Inverter-side RS485 termination	ON: 150Ω resistor between A and B; 430Ω resistor between A and +5VM; 430Ω resistor between B and 0VM (default) OFF: no termination and polarisation resistor

<i>Electrical Specifications</i>	<i>Value</i>			
	<i>Min.</i>	<i>Typ.</i>	<i>Max.</i>	<i>Unit</i>
Operating temperature range of the components (standard version)	0		70	°C
Max. relative humidity (non-condensing)			95	%
Environment pollution degree (according to EN 61800-5-1)			2	

Degree of protection of the plastic case	IP20			
Insulation test voltage between the encoder signals and the power supply ground	500Vac 1'			
Connection to the inverter	Value			
	Min.	Typ.	Max.	Unit
Input voltage	19	24	30	V
Power supply voltage to the inverter	8.5	9.16	11.1	V
Inverter power supply output current			830	mA
Input lines	Two lines: signals A and B, RS485 bus			
Type of input signals	RS485 Standard (from 4800bps to 115200bps)			
Connection to the power supply line	Value			
	Min.	Typ.	Max.	Unit
+24V Power supply absorption			700	mA
Compliance				
EN 61000-4-5	Level 4, Criterion B			



P001040-B

Figure 177: Position of the LEDs and DIP-switches in ES914 board

21. “LOC-0-REM” KEY SELECTOR SWITCH AND EMERGENCY PUSH-BUTTON FOR IP54 MODELS

Product-Accessory Compatibility		
Product	Key selector switch and Emergency push-button for IP54 models	Comments
Sinus Penta	√	
Penta Marine	√	
Iris Blue	√	
Solardrive Plus	-	

Table 26: Product – Key selector switch and Emergency push-button for IP54 models compatibility

The IP54 models can be provided with a key selector switch and an emergency push-button (optional devices supplied by request).

The key selector switch selects the following operating modes:

POSITION	OPERATING MODE	DESCRIPTION
LOC	INVERTER IN LOCAL MODE	The inverter operates in “Local” mode; the Start command and the frequency/speed reference are sent via display/keypad.
0	INVERTER DISABLED	Inverter disabled
REM	INVERTER IN REMOTE MODE	The control mode is defined by programming in parameters C140 ÷ C147 of the Control Method menu.

When pressed, the emergency push-button immediately stops the inverter.

An auxiliary terminal board with voltage-free contacts is provided for the selector switch status, the emergency push-button status and the Enable command.

Decisive voltage class C according to EN 61800-5-1


TERMINALS	FEATURES	FUNCTION	DESCRIPTION
1	Opto-isolated digital input	ENABLE	Connect terminal 1 to terminal 2 to enable the inverter (terminals 1 and 2 are connected together—factory-setting)
2	0 V digital inputs	CMD	digital input ground
3-4	voltage-free contacts (230V - 3A, 24V - 2.5A)	STATUS OF LOC-0-REM SELECTOR SWITCH	contacts closed: selector switch in position LOC; contacts open: selector switch in position 0 or REM
5-6	voltage-free contacts (230V - 3A, 24V - 2.5A)	STATUS OF LOC-0-REM SELECTOR SWITCH	contacts closed: selector switch in position REM; contacts open: selector switch in position 0 or LOC
7-8	voltage-free contacts (230V - 3A, 24V - 2.5 A)	STATUS OF EMERGENCY PUSH-BUTTON	contacts closed: emergency push-button not depressed contacts open: emergency push-button depressed



NOTE

When the key selector switch and the emergency push-button are installed, multifunction digital input MDI4 (terminal 12) cannot be used. The ground of multifunction digital inputs is available also on terminal 2 in the auxiliary terminal board.

21.1. Wiring IP54 Inverters with Optional “LOC-0-REM” Key Selector Switch and Emergency Push-button



S000009

Figure 178: Wiring diagram for IP54 inverters



CAUTION

The wiring shown in this schematic does not allow to implement the STO function (see the Safe Torque Off Function – Application Manual).

22. INDEX**A**

Anybus-S	174
Auxiliary Power Supply	85

B

B40	174
BACNet/Ethernet	220
BACNet/RS485	224
BiSS	272
Board	
Encoder	142; 144
Fieldbus	173
I/O Expansion	2; 228
I/O Expansion 120/240Vrms	251
Line Driver Encoder	153; 155
Power Supply Unit	301
Relay I/O Expansion	247
BRIDGE MINI	226
BU1440	86
BU200	47
BU600	61

D

DeviceNet®	174; 199
------------------	----------

E

Earth Bonding	96
Encoder	240; 250
Configuration	146
Configuration examples	147
Terminals	145
Wiring	152
ES822	169
ES836	142
ES847	228
ES860	159
ES861	261
ES870	247
ES913	153
ES914	301
ES919	216
ES950	272
ES966	286
ES988	251
EtherCAT	188
Ethernet/IP	188

F

Feedback	
Encoder	155
Speed	142; 153
Filteri	
toroidal	141

H

Hiperface	286
HTL	153

I

I/O Expansion	
Wiring	236
Input	
inductors	122
Inputs	
Analog	237; 238; 239; 243
Digital	245

K

Key selector switch	308; 310
Keypad	
Remoting	121

L

Line Driver Encoder	
Configuration	157
Terminal board	156
LOC	308; 310

M

Metasys® N2	218
MODBUS/TCP®	188; 205

N

NEMA 1	118
--------------	-----

O

Output	
Inductors	125
Outputs	
Digital	241; 246

P

Power	
Cables	30
Power Cables	31; 56; 74
PROFIBUS-DP®	174; 185; 195
PROFIdrive	174; 199
Profinet IRT	188

R

REM	308; 310
Resolver	261

S

Scheduled Maintenance	31
Serial board	169
Serial Communications	82

SIN/COS Encoder	159	Slot B	171; 176; 217; 227
Sine filters	140	Slot C	229; 248
Slot A.....	144; 153; 155		